

# Manitowoc

## OPERATOR'S MANUAL

This manual has been prepared for and is considered part of -

**16000**

Model Number

**16001Ref**

Serial Number

This Manual is divided into the following sections:

<b>SECTION 1</b>	<b>INTRODUCTION</b>
<b>SECTION 2</b>	<b>SAFETY INFORMATION</b>
<b>SECTION 3</b>	<b>OPERATING CONTROLS AND PROCEDURES</b>
<b>SECTION 4</b>	<b>SET-UP AND INSTALLATION</b>
<b>SECTION 5</b>	<b>LUBRICATION</b>
<b>SECTION 6</b>	<b>MAINTENANCE CHECKLIST</b>

### NOTICE

The serial number of the crane and applicable attachments (i.e. luffing jib, MAX-ER™) is the only method your Manitowoc distributor or Manitowoc Crane Care at factory has of providing you with correct parts and service information.

The serial number is located on a crane identification plate attached to the operator's cab and each attachment. Refer to the Nameplate and Decal Assembly Drawing (in Section 2 of Operator's Manual) for the exact location of the crane identification plate.

***Always furnish serial number of crane and its attachments*** when ordering parts or discussing service problems with your Manitowoc distributor or the factory.



## ! WARNING

### To prevent death or serious injury:

- Avoid unsafe operation and maintenance.  
Crane and attachments must be operated and maintained by trained and experienced personnel. Manitowoc is not responsible for qualifying these personnel.
- Do not operate or work on crane or attachments without first reading and understanding instructions contained in Operator Information Manual and Service Manual supplied with crane and applicable attachments.
- Store Operator Information Manual and Service Manual in operator's cab.

If Operator Information Manual or Service Manual is missing from cab, contact your Manitowoc distributor for a new one.

***THIS PAGE BLANK***

*See end of this manual for Alphabetical Index*

## **SECTION 1 ..... Introduction**

Crane Data .....	1-1
Crane/Attachment Identification .....	1-1
Change of Ownership Registration .....	1-1
Crane Orientation .....	1-1
Identification and Location of Components .....	1-2
Outline Dimensions .....	1-4
English and Metric Conversions .....	1-6
Direct Conversion .....	1-6
Inverse Conversion .....	1-6
Manitowoc Distributors .....	1-7

## **SECTION 2 ..... Safety Information**

Nameplates and Decals .....	2-1
Safety Messages .....	2-1
General .....	2-1
Safety Alert Symbol .....	2-1
Signal Words .....	2-1
Safety Symbols .....	2-1
Crane Access Points .....	2-7
General .....	2-7
Getting On or Off Crane .....	2-7
Operator's Manual/Capacity Chart Storage .....	2-8
General .....	2-8
Storing Manuals .....	2-8
Deploying Swing Radius Barrier .....	2-9
Storing Swing Radius Barrier .....	2-9
Safe Operating Practices .....	2-10
General .....	2-10
Read Operator's Manual .....	2-10
Operator Qualifications .....	2-10
Operator Conduct .....	2-10
Handling Load .....	2-12
Signals .....	2-15
Operational Aids .....	2-15
Operating Near Electric Power Lines and Transmission Lines .....	2-16
Electrocution Hazard .....	2-16
Set-Up and Operation .....	2-16
Electrocution Hazard Devices .....	2-17
Electrical Contact .....	2-17
Refueling .....	2-18
Fire Extinguishers .....	2-18
Accidents .....	2-18
Safe Maintenance Practices .....	2-18
Maintenance Instructions .....	2-18
Safe Maintenance Practices .....	2-18
Environmental Protection .....	2-21
Boom Disassembly Safety .....	2-23
General .....	2-23
Location .....	2-23
Pin Removal .....	2-23
Disassembly Precaution .....	2-23
Personnel Handling Policy .....	2-24
Pedestal/barge Mounted Cranes .....	2-25
Pedestal Mounted Crane .....	2-25

Barge Mounted Crane . . . . .	2-26
Capacity Charts . . . . .	2-27
Shock Loading . . . . .	2-27
Operation On Barge . . . . .	2-28
Crane Inspection . . . . .	2-28
Transporting Crane on Barge . . . . .	2-29
Safety and Information Signs . . . . .	2-29
Maintaining Signs . . . . .	2-29
Ordering Signs . . . . .	2-29

### **SECTION 3. . . . . Operating Controls And Procedures**

Standard Hand Signals for Controlling Crane Operations . . . . .	3-1
Symbol Identification . . . . .	3-3
Front Window Operation . . . . .	3-8
Closing Window . . . . .	3-8
Opening Window For Ventilation . . . . .	3-8
Opening Window For Emergency Exit . . . . .	3-8
Operating Controls . . . . .	3-8
General . . . . .	3-8
Cab Door Damper Adjustment . . . . .	3-9
Closing Cab Door . . . . .	3-9
Damper Adjustment . . . . .	3-9
Controls Identification And Function . . . . .	3-11
A – Engine Controls . . . . .	3-11
B – Accessory Controls . . . . .	3-12
C – Indicators . . . . .	3-15
D – Special Controls . . . . .	3-16
E – Boom/Mast Hoist Controls . . . . .	3-19
F – Load Drum Controls . . . . .	3-19
G – Swing Controls . . . . .	3-20
H – Travel Controls . . . . .	3-21
J – Winch Controls . . . . .	3-21
Limit Devices . . . . .	3-22
1. Boom Up Limit . . . . .	3-22
3. Block-Up Limit . . . . .	3-22
4. Luffing Jib Up Limit . . . . .	3-22
5. Luffing Jib Down Limit . . . . .	3-22
7. Minimum Bail Limit . . . . .	3-23
Seat Controls . . . . .	3-25
Preparing Crane for Operation . . . . .	3-26
Operation . . . . .	3-26
Engine Startup . . . . .	3-26
Boom/Mast Hoist Operation . . . . .	3-28
Luffing Hoist Operation . . . . .	3-29
Swing Operation . . . . .	3-29
Load Drum Operation . . . . .	3-30
Travel Operation . . . . .	3-31
Stopping Engine/ Leaving Crane Unattended . . . . .	3-33
Remote Controls . . . . .	3-34
General . . . . .	3-34
Crane Setup Remote Controls . . . . .	3-34
Carbody Manual Remote Controls . . . . .	3-36
Replacing Wireless Remote Batteries . . . . .	3-37
Displays . . . . .	3-38
Display Controls . . . . .	3-38
Display Brightness and Color Contrast . . . . .	3-38



Factory Default Display Settings . . . . .	3-38
Blank Display . . . . .	3-38
Main GUI Display Format . . . . .	3-38
Screen Prompts . . . . .	3-39
Menu Screen . . . . .	3-39
Information Screen . . . . .	3-40
Diagnostic Screen . . . . .	3-43
Function Mode Screens . . . . .	3-48
CAN Bus Screen . . . . .	3-50
Digital Output Reference Chart . . . . .	3-54
Digital Input Reference Chart . . . . .	3-55
Camera Screen (Optional) . . . . .	3-58
Pressure Test and Calibration Screen . . . . .	3-58
Wind Conditions . . . . .	3-62
Preparation for Cold Weather . . . . .	3-64
Crane Limitations . . . . .	3-64
Wire Rope . . . . .	3-64
Cold Weather Starting Aid . . . . .	3-64
Cooling System . . . . .	3-64
Battery . . . . .	3-64
Engine Oil . . . . .	3-64
Fuel Oil . . . . .	3-64
Gear Oil . . . . .	3-64
Hydraulic Oil . . . . .	3-65
Cold Weather Heater Package . . . . .	3-65
General . . . . .	3-65
Heaters . . . . .	3-65
Turning Heaters On . . . . .	3-65
Turning Heaters Off . . . . .	3-65
Circuit Breakers . . . . .	3-65

## **SECTION 4 . . . . . Set-Up and Installation**

Rigging Drawings . . . . .	4-1
Liftcrane Mast Capacities . . . . .	4-1
Optional Attachments . . . . .	4-1
General Safety . . . . .	4-1
Crane Orientation . . . . .	4-1
Self-Erecting Equipment . . . . .	4-1
Assist Crane Requirements . . . . .	4-2
Assembly and Disassembly Notes . . . . .	4-2
Assembly And Disassembly Area . . . . .	4-2
Accessing Parts . . . . .	4-2
Crane Weights . . . . .	4-2
Handling Components . . . . .	4-2
Retaining Connecting Pins . . . . .	4-2
Cold Weather Mast Operation . . . . .	4-3
Shipping Crane Components . . . . .	4-5
Operating Controls . . . . .	4-5
Pre-Start Checks . . . . .	4-7
Engine . . . . .	4-7
Gear Boxes . . . . .	4-7
Hydraulic System . . . . .	4-7
Crane Assembly . . . . .	4-7
Install Exhaust Pipes . . . . .	4-7
Remove Rotating Bed from Trailer . . . . .	4-9
Remove Carbody and Adapter Frame from Trailer . . . . .	4-13
Lower Crane onto Carbody Pedestals . . . . .	4-16

Connect Hydraulic Hoses and Electric Cables . . . . .	4-16
Raise Live Mast To Operating Position . . . . .	4-19
Install Assembly Block . . . . .	4-21
Install Crawlers . . . . .	4-21
Handling Crawlers . . . . .	4-23
Install Crawler Platforms . . . . .	4-29
Install Crawler Stairways . . . . .	4-29
Install Counterweight . . . . .	4-31
Assemble Boom . . . . .	4-35
Install Boom Butt . . . . .	4-35
Remove Assembly Block . . . . .	4-39
Connect Boom Butt to Boom . . . . .	4-39
Crane Disassembly . . . . .	4-41
Lower Boom . . . . .	4-41
Disconnect Boom Butt from Boom . . . . .	4-41
Install Assembly Block . . . . .	4-42
Remove Boom Butt . . . . .	4-42
Disassemble Boom . . . . .	4-43
Remove Counterweight . . . . .	4-43
Remove Crawler Stairways . . . . .	4-44
Store Crawler Platforms . . . . .	4-44
Remove Crawlers . . . . .	4-44
Remove Assembly Block . . . . .	4-45
Lower Live Mast To Shipping Position . . . . .	4-46
Disconnect Hydraulic Lines and Electric Cables . . . . .	4-46
Raise Crane Off Carbody Pedestals . . . . .	4-46
Place Carbody and Adapter Frame on Trailer . . . . .	4-46
Remove Rotating Bed from Trailer . . . . .	4-47
Remove Exhaust Pipes . . . . .	4-47
Boom Ladder Assembly . . . . .	4-49
General . . . . .	4-49
Removing Ladders from Boom Butt . . . . .	4-49
Installing Ladders on Boom Inserts . . . . .	4-49
Storing Ladders in Boom Butt . . . . .	4-49
Boom Rigging . . . . .	4-50
Assist Crane Requirements . . . . .	4-50
Blocked Crawler . . . . .	4-50
Handling Components . . . . .	4-50
Boom Assembly Drawing . . . . .	4-50
Identifying Boom Sections and Straps . . . . .	4-50
Assemble Boom Sections . . . . .	4-53
Connect Boom Straps . . . . .	4-55
Install Intermediate Suspension . . . . .	4-55
Install Standard Upper Boom Point . . . . .	4-57
Install Extended Upper Boom Point . . . . .	4-57
Install Load Line . . . . .	4-62
Connect Boom Wiring . . . . .	4-62
Perform Pre-Raising Checks . . . . .	4-62
Boom Removal . . . . .	4-62
Wire Rope Installation . . . . .	4-66
Wire Rope Storage . . . . .	4-66
Removing Wire Rope from Shipping Reel . . . . .	4-66
Seizing and Cutting Wire Rope . . . . .	4-66
Anchoring Wire Rope to Drum . . . . .	4-67
Drum Guards . . . . .	4-67
Winding Wire Rope onto Drum . . . . .	4-69
Anchoring Wire Rope to Wedge Socket . . . . .	4-71

Anchoring Wire Rope to Button Socket . . . . .	4-71
Breaking in Wire Rope . . . . .	4-71
Drum Kicker Adjustment . . . . .	4-72
General . . . . .	4-72
Adjustment . . . . .	4-72
Pad Eye Usage for Wire Rope Reeving . . . . .	4-72
General . . . . .	4-72
Safety . . . . .	4-72
Rigging Winch Operation . . . . .	4-74
Selecting Rigging Winch Mode . . . . .	4-74
Operating Rigging Winch . . . . .	4-74
Reeving – Load Block . . . . .	4-76
Load Block Identification . . . . .	4-76
Wire Rope Specifications . . . . .	4-76
Wire Rope Installation . . . . .	4-76
Duplex Hook . . . . .	4-76
Guide Sheaves and Drums . . . . .	4-76
Load Block Reeving . . . . .	4-76
Reeving – Live Mast . . . . .	4-82
General . . . . .	4-82
Wire Rope Specification . . . . .	4-82

## **SECTION 5 . . . . . Lubrication**

Symbol Identification . . . . .	5-1
General Lubrication . . . . .	5-1
Lubrication Intervals . . . . .	5-1
Over-Lubrication . . . . .	5-1
Lubrication Tips . . . . .	5-1
Oil Can Points . . . . .	5-2
Wire Rope Lubrication . . . . .	5-2
Cylinder Rod Lubrication . . . . .	5-2
General . . . . .	5-2
Protecting Cylinder Rods . . . . .	5-2
Environmental Protection . . . . .	5-2
Reference Instructions . . . . .	5-2
CraneLUBE . . . . .	5-2
Approved Lubricants For Normal Operation . . . . .	5-4
Grease . . . . .	5-4
Open Gear Oil . . . . .	5-4
Gear Oil . . . . .	5-4
Hydraulic Oil . . . . .	5-4
Hydraulic Filter Replacement . . . . .	5-5
Lubrication Points . . . . .	5-5
Fluid Capacities . . . . .	5-6
Approved Lubricants For Arctic Operation . . . . .	5-7
Upper and Lower Lubrication Points — Location . . . . .	5-8
Engine Components . . . . .	5-11
Upper and Lower Lubrication Points — Identification . . . . .	5-12
Boom Rigging Lubrication . . . . .	5-18
Automatic Lubrication System . . . . .	5-20
Operation . . . . .	5-20
Daily Inspection . . . . .	5-20
Automatic Lubrication System Troubleshooting . . . . .	5-22

## **SECTION 6 . . . . . Preventive Maintenance Checklist**

Inspection and Maintenance Checks . . . . .	6-1
---	-----

Maintenance Intervals .....	6-1
Maintenance Instructions .....	6-1
Initial Run-In Services.....	6-2
Maintenance Checklist .....	6-2

# SECTION 1

## INTRODUCTION

### TABLE OF CONTENTS

Crane Data .....	1-1
Crane/Attachment Identification .....	1-1
Change of Ownership Registration .....	1-1
Crane Orientation .....	1-1
Identification and Location of Components .....	1-2
Outline Dimensions .....	1-4
English and Metric Conversions .....	1-6
Direct Conversion .....	1-6
Inverse Conversion .....	1-6
Manitowoc Distributors .....	1-7



## SECTION 1

### INTRODUCTION

1

#### CRANE DATA

See end of this section for crane data specific to your crane:

- Basic Specifications.
- EC Declaration (if applicable).

#### CRANE/ATTACHMENT IDENTIFICATION

An identification plate is attached to the outside of the operator's cab (see Figure 1-1) and to the attachments (for example, luffing jibs and MAX-ER's).

The crane or attachment model and serial number are provided on the plate.

For the exact location of the identification labels on your crane and attachments, refer to the Nameplates and Decals Drawing in Section 2 of this manual.

#### CHANGE OF OWNERSHIP REGISTRATION


If you are the new owner of a Manitowoc crane, please register it with Manitowoc Crane Care so we can contact you if the need arises.

Go to [www.manitowoccranes.com/MCG\\_CARE/Includes/EN/changeofownership.cfm](http://www.manitowoccranes.com/MCG_CARE/Includes/EN/changeofownership.cfm) and complete the form.


#### CRANE ORIENTATION

The terms RIGHT, LEFT, FRONT, REAR used in this manual refer to operator's right, left, front, and rear sides when seated in the operator's cab looking forward.

- The boom is on the front of the rotating bed.
- The carbody and crawler controls are on the front of the carbody.



## IDENTIFICATION AND LOCATION OF COMPONENTS



A10740-3

FIGURE 1-2








FIGURE 1-2 continued

A14806-1

OUTLINE DIMENSIONS





Item	Dimension
1	46 ft 4 in (14,20 m)
2	32 ft 5 in (9,88 m)
3	38 ft 1 in (11,60 m)
4	25 ft 11 in (7,90 m)
5	14 ft 6 in (4,43 m) Top of Light on Cab
6	8 ft 9 in (2,68 m)
7	5 ft 0 in (1,52 m)
8a	34 ft 3 in (10,43 m)
8b	36 ft 9 in (11,22 m)
9	17 ft 1 in (5,22 m)
10	24 ft 6 in (7,56 m)
11	36 ft 6 in (11,13 m)
12	32 ft 8 in (10,00 m) Mast Tail Swing OR 27 ft 0 in (8,20 m) Counterweight Tail Swing
13	5 ft 8 in (1,75 m)
14	11 ft 8 in (3,58 m)
15	27 ft 4 in (8,33 m)
16	5 ft 3 in (1,61 m)
17	5 ft 0 in (1,52 m)
18	29 ft 0 in (8,84 m)
19	1 ft 3 in (0,39 m)
20	13 ft 6 in (4,11 m) Series 3 12 ft 9 in (3,88 m) Series 2 11 ft 2 in (3,40 m) Series 1

## ENGLISH AND METRIC CONVERSIONS

## Direct Conversion

MULTIPLY (x) known value by conversion factor to obtain equivalent value in desired units. For example, 12 ft is converted to meters (m), as follows:

$$12 \text{ ft} \times 0.3048 = 3,6576 \text{ m}$$

## Inverse Conversion

DIVIDE (÷) known value by conversion factor to obtain equivalent value in desired units. For example, 3,6576 m is converted to feet, as follows:

$$3,6576 \text{ m} \div 0.3048 = 12$$

To Convert	Symbol	Application	To	Symbol	Multiply By
AREA					
Square Inch	in <sup>2</sup>	Filter Area Clutch Contact	Square Centimeter	cm <sup>2</sup>	6.4516
Square Foot	ft <sup>2</sup>	Ground Contact	Square Meter	m <sup>2</sup>	0.0929
FORCE					
Pound Force	lb	Pedal Effort	KiloNewton Newton	kN N	0.00445 4.4482
Pound Force	lb	Line Pull	KiloNewton	kN	0.00445
Pound Force Per Inch	lb/in.	Spring Force	Newton per millimeter	Nmm	0.1751
Pound Force Per Foot	lb/ft		Newton per meter	Nm	14.5939
LENGTH					
Inch	in.	Adjustments	Millimeter	mm	25.4000
Foot	ft	Outline Dimensions	Meter	m	0.3048
Mile	miles	Travel Distance	Kilometer	km	1.6093
POWER					
Horsepower	hp	Engine	Kilowatt	kW	0.7457
PRESSURE					
Pound/Sq. In.	psi	Hydraulic & Air	Bar		0.0689
TEMPERATURE					
Degrees Fahrenheit	°F	Oil, Air, Etc.	Degrees Centigrade	°C	°F - 32 ÷ 1.8
Degrees Centigrade	°C		Degrees Fahrenheit	°F	°C x 1.8 + 32
TORQUE					
Inch Pound	in lb	Bolt Torque	Newton Meter	Nm	0.1129
Foot Pound	ft lb		Newton Meter	Nm	1.3558
VELOCITY					
Miles Per Hour	mph	Vehicle Speed	Kilometers Per Hour	km/h	1.6093
Miles Per Hour	mph	Wind Speed	Meters Per Second	m/s	0.4470
Feet Per Minute	fpm	Line Speed	Meters Per Minute	m/min	0.3048
VOLUME					
Cubic Yard	yd <sup>3</sup>	Bucket Capacity	Cubic Meter	m <sup>3</sup>	0.7646
Cubic Foot	ft <sup>3</sup>		Cubic Meter	m <sup>3</sup>	0.0283
Cubic Inch	in <sup>3</sup>	Pump Displacement	Cubic Centimeter	cm <sup>3</sup>	16.3871

To Convert	Symbol	Application	To	Symbol	Multiply By
<b>VOLUME (LIQUID)</b>					
Ounce	oz	Fluid Capacities	Milliliter	mL	29.5735
Pint	pt		Liter	L	0.4732
Quart	qt		Liter	L	0.9464
Gallon	gal		Liter	L	3.7854
Gallon Per Minute	gpm	Pump Flow	Liters Per Minute	L/min	3.7854
<b>WEIGHT</b>					
Pound	lb	Unit/Component	Kilogram	kg	0.4536
Ton (2,000 lb.)	USt	Load Ratings	Metric Ton	t	0.9072
Ton (2,000 lb.)	USt		Kilogram	kg	907.1847

## MANITOWOC DISTRIBUTORS

To locate the Manitowoc distributor nearest you:

1. Go to **www.manitowoc.com**.
2. Click on Manitowoc logo.
3. Click on **DEALERS**.
4. Follow on-screen instructions to locate distributor.
5. When calling a distributor with parts or service questions, you need to know the model and serial number of your crane or attachment. This information is located on the Crane Identification Plate on the crane cab or on the attachment.



## SECTION 2

### SAFETY INFORMATION

#### TABLE OF CONTENTS

Nameplates and Decals . . . . .	2-1
Safety Messages . . . . .	2-1
General . . . . .	2-1
Safety Alert Symbol . . . . .	2-1
Signal Words . . . . .	2-1
Safety Symbols . . . . .	2-1
Crane Access Points . . . . .	2-7
General . . . . .	2-7
Getting On or Off Crane . . . . .	2-7
Operator's Manual/Capacity Chart Storage . . . . .	2-8
General . . . . .	2-8
Storing Manuals . . . . .	2-8
Deploying Swing Radius Barrier . . . . .	2-9
Storing Swing Radius Barrier . . . . .	2-9
Safe Operating Practices . . . . .	2-10
General . . . . .	2-10
Read Operator's Manual . . . . .	2-10
Operator Qualifications . . . . .	2-10
Operator Conduct . . . . .	2-10
Handling Load . . . . .	2-12
Size of Load . . . . .	2-12
Attaching Load . . . . .	2-12
Lifting/Moving Load . . . . .	2-12
Multiple Load Line Operation . . . . .	2-14
Holding Load . . . . .	2-14
Signals . . . . .	2-15
Operational Aids . . . . .	2-15
Operating Near Electric Power Lines and Transmission Lines . . . . .	2-16
Electrocution Hazard . . . . .	2-16
Set-Up and Operation . . . . .	2-16
Electrocution Hazard Devices . . . . .	2-17
Electrical Contact . . . . .	2-17
Refueling . . . . .	2-18
Fire Extinguishers . . . . .	2-18
Accidents . . . . .	2-18
Safe Maintenance Practices . . . . .	2-18
Maintenance Instructions . . . . .	2-18
Safe Maintenance Practices . . . . .	2-18
Environmental Protection . . . . .	2-21
Boom Disassembly Safety . . . . .	2-23
General . . . . .	2-23
Location . . . . .	2-23
Pin Removal . . . . .	2-23
Disassembly Precaution . . . . .	2-23
Personnel Handling Policy . . . . .	2-24
Pedestal/barge Mounted Cranes . . . . .	2-25
Pedestal Mounted Crane . . . . .	2-25
Definition . . . . .	2-25
Examples . . . . .	2-25
Barge Mounted Crane . . . . .	2-26
Definition . . . . .	2-26

Examples .....	2-26
Capacity Charts .....	2-27
Shock Loading .....	2-27
Definition .....	2-27
Operation On Barge .....	2-28
General .....	2-28
Definitions .....	2-28
Crane Inspection .....	2-28
Transporting Crane on Barge .....	2-29
Safety and Information Signs .....	2-29
Maintaining Signs .....	2-29
Ordering Signs .....	2-29



## SECTION 2

### SAFETY INFORMATION

#### Safety Alert Symbol



#### WARNING

##### California Proposition 65

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals, and related accessories contain chemical lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects, and other reproductive harm. Wash hands after handling.

##### California Spark Arrestor

Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The owner/operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

#### NAMEPLATES AND DECALS

See drawing at the end of this section.

#### SAFETY MESSAGES

##### General

The importance of safe operation and maintenance cannot be over emphasized. Carelessness or neglect on the part of operators, job supervisors and planners, rigging personnel, and job site workers can result in their death or injury and costly damage to the crane and property.

To alert personnel to hazardous operating practices and maintenance procedures, safety messages are used throughout the manual. Each safety message contains a safety alert symbol and a signal word to identify the hazard's degree of seriousness.



This safety alert symbol means **ATTENTION!** Become alert — **your safety is involved!** Obey all safety messages that follow this symbol to avoid possible death or injury.

#### Signal Words



#### DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



#### WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



#### CAUTION

Used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

#### CAUTION

Without the safety alert symbol, identifies potential hazards that could result in property damage.

**NOTE:** Highlights operation or maintenance procedures.

#### Safety Symbols

Safety symbols used in the decals on this crane are identified in Figure 2-1.


















FIGURE 2-1

 <p><b>Fall Hazards</b></p>	<div>  Engine Coolant         </div> <div>  Engine Coolant Vent         </div> <div>  Engine Oil Level         </div> <div>  Pump Drive Oil Level         </div> <div>  Diesel Fuel         </div> <div>  Hydraulic Filter         </div> <div>  Hydraulic Oil         </div> <p><b>Fluid Symbols</b></p>
 <p><b>Falling Boom Hazards (Crush Hazard)</b></p>	<p><b>Flying Object Hazards</b></p> 
 <p><b>Falling Load Hazards (Crush Hazard)</b></p>	<p><b>Overhead Obstruction Hazard</b></p> 
 <p><b>Fire Extinguisher</b></p>	<p><b>Power Line Hazard (Electrocution)</b></p>  <p><b>FIGURE 2-1 continued</b></p>









	Personal Fall Protection	Sound Power Level	
	Pressure Cleaning	Read Manual	 OR 
	Pressure Release Hazard	Tire Pressure (if applicable)	

FIGURE 2-1 continued

*THIS PAGE BLANK*

A10740-26

**WARNING****Trip Hazard!**

Use caution when walking on carbody counterweights so you do not trip on lifting lugs and fall.

**FIGURE 2-2**

## CRANE ACCESS POINTS



### WARNING

#### Crush Hazard!

Upperworks can swing into and crush personnel climbing on or off crane.

Moving crawlers can crush personnel climbing on or off crane.

To prevent death or serious injury:

- Barricade all accessible areas to crane so personnel cannot be struck or crushed when upperworks is swung. See Swing Radius Barrier topic in this section.
- Do not climb onto or off crane while upperworks is being swung or crane is being traveled.
- Signal operator for permission to climb onto/off crane.
- Operator: do not swing or travel while personnel are climbing onto or off crane. Stop swing and travel motions. Apply swing brake and turn on travel park.
- Operator: Always sound horn to alert personnel before you swing or travel.

## General

Take necessary precaution to prevent slipping and/or falling off the crane during assembly, disassembly, maintenance, or other work. ***Falling from any height could result in serious injury or death.***

Manitowoc has provided stairways, ladders, and platforms at the locations shown in Figure 2-2.

The owner/user must provide workers with approved ladders or aerial work platforms to access those areas of the crane, mast, and boom that cannot be reached from the ground or from steps, ladders, catwalks, and platforms provided by Manitowoc.

*Adhere to local, state, and federal regulations for handling personnel and for personnel fall protection.*

- Access points must be kept clear to prevent personal injury and unsafe operation of crane. Store clothing and

other personal belongings so they do not interfere with with controls in operator's cab or with operation of crane.

- Tools, oil cans, spare parts, and other necessary equipment must be stored in tool boxes or other appropriate locations. Do not allow these items to lie around loose in operators cab or on steps, ladders, catwalks, and platforms.
- To reduce risk of slipping, non-skid material (sand in paint) has been applied to painted walkways and platforms.

Walkways and platforms can be slippery when wet and when oil or is grease is spilled on them. ***Keep walkways and platforms clean and dry to prevent slipping on them.*** When non-skid material wears out, reapply it.

- Wear shoes with a highly slip-resistant sole material. Clean any mud or debris from shoes before entering the crane cab or climbing onto the cab. A shoe that is not clean might slip off a control pedal during operation.
- Do not make modifications or additions to the crane's access system that have not been evaluated and approved by Manitowoc.
- Do not use top of mast, boom, or jib as walkways (unless they have optional catwalks).

**NOTE:** Optional walkways (catwalks) are available for the boom and luffing jib sections, but only for those countries that authorize their use.

Two optional ladders, stored in 40 ft (12 m) insert next to the boom butt, are available for boom assembly and disassembly. See Boom Ladder Assembly in Section 4 of this manual for instructions.

## GETTING ON OR OFF CRANE

Personnel getting on and off crane shall do so only at steps or ladders provided and only ***while crane is parked.***

Never climb onto or off a moving crane. ***Climb onto and off crane only when it is parked and only with operator's permission.***

When personnel use ladders to get on or off the crane, their hands shall be free of any objects. Objects which cannot be carried in pockets or tool belts shall be lifted into place with a hand line or hoist.

## OPERATOR'S MANUAL/CAPACITY CHART STORAGE

### General

Manitowoc provides the following manuals and other important literature with your crane and attachment (Luffing Jib, etc.):

- Operator's Manual (Serial Numbered)  
*Contains safety information, crane specifications, assembly/erection procedures, operating instructions, lubrication and maintenance checks.*
- Parts Manual (Serial Numbered)  
*Contains illustrations and part numbers of replaceable parts.*
- Capacity Chart Manual (Serial Numbered)  
*Contains lifting capacities and related information (wire rope specifications, drum and lagging information, etc.)*
- Maintenance Checks and Lube Guide  
*Contains lists of maintenance checks and lube services and their prescribed intervals.*
- RCI/RCL Operation  
*Contains rated capacity indicator and/or rated capacity limiter operation, limits, and calibration procedures.*
- Service Manual (Serial Numbered)  
*Contains theory of operation, maintenance procedures, troubleshooting information, and shop procedures.*
- Vendor Instructions Manual (Serial Numbered)  
*Contains OEM instructions for servicing purchased components, (engines, pumps, valves, etc.).*

The manuals which must be retained in the operator's cab (Operator's Manual, Capacity Charts, Maintenance Checks and Lube Guide, and RCL Operation) are supplied in a OPERATOR INFORMATION binder. A separate binder is provided for the crane and each applicable attachment.

The Operator's Manuals and Capacity Charts are stamped with the serial number of the crane or attachment. The serial number on the manuals and capacity charts must match the serial number of the crane and attachment in use. **Using any other manual or capacity chart is prohibited.**

- The crane model and serial number is located on the Crane Identification Plate on the crane cab.
- The model and serial number of the attachment (other than standard boom) is located on the Crane Identification Plate on the attachment.

If the serial numbers of your manuals and capacity charts do not match the serial numbers of the crane or attachment, contact your Manitowoc distributor for the proper manual or capacity charts.


**Do not operate crane or attachment if proper Capacity Chart is not in cab.**

### Storing Manuals

Store the Operator Information Manuals for the crane and each applicable attachment on the bookshelf in the Operator's cab (Figure 2-3).

Attach the chain from the manual in use to the link behind the operator's seat.

Keep all other manuals provided with the crane in the crane owner's/user's office so they are readily available when needed.



**FIGURE 2-3**

### SWING RADIUS BARRIER

Manitowoc's optional swing radius barrier is shown in Figure 2-4.




### WARNING

#### Crush Hazard!

To prevent personnel from being crushed by swinging crane, deploy swing radius barrier before operating crane.





### Deploying Swing Radius Barrier

1. Remove pins (2, View C) from shipping position.
2. Rotate barrier arms (1) outward to working position (View A).
3. Install pins (2, View B) in working position.
4. Pull on spring-loaded pins (3, View D), pull extension arms (4) out part way, and release pins.
5. Pull extension arms (4) out fully until they are locked in position by spring-loaded pins (5) as shown in View A.
6. Form a safety perimeter by attaching user supplied high visibility rope or ribbon to hooked ends of extension arms.

### Storing Swing Radius Barrier

1. Remove rope or ribbon from hooked ends of extension arms (4).
2. Pull on spring-loaded pins (3, View D), push extension arms (4) in part way, and release pins.
3. Push extension arms (4) in fully until they are locked in position by spring-load pins (5).
4. Remove pins (2, View B) from working position.
5. Rotate barrier arms (1) inward and install pins (2, View C) in shipping position.

## SAFE OPERATING PRACTICES

### General

The importance of safe operation cannot be over emphasized. Carelessness and neglect on the part of operators, supervisors and planners, rigging personnel and job site personnel can result in their death or injury and costly damage to the crane or property.

The safety information in this publication is intended only as a guide to assist qualified operators in safe operation. Manitowoc cannot foresee all hazards that will arise in the field; therefore, **safety remains responsibility of crane operators and owner.**

Local, state, and other governmental agencies may require stricter operating practices. When a conflict in practices exists, follow the strictest practice.

### Read Operator's Manual

Safe and efficient operation of this crane requires that it be maintained in proper working order and that its operators and maintenance personnel be familiar with the crane's functions and capabilities.

The Operator's Manual supplied with and considered part of your crane must be read and completely understood by each person responsible for operation and maintenance of the crane.

The Operator's Manual must be read to personnel who can not read or understand English or other language the manual is translated into.

Because of a program of continuing improvement in product design, Manitowoc reserves the right to change the information and specifications contained in the Operator's Manual at any time without notice. If you have any questions regarding the crane or its Operator's Manual, please contact your Manitowoc distributor.

### Operator Qualifications

The crane shall be operated only by the following **qualified** personnel:

1. Designated operators.
2. Trainees under direct supervision of a designated operator.
3. Supervisors, inspectors and maintenance or test personnel when necessary in performance of their duties. Operation of the crane by these personnel shall be limited to the crane functions needed to perform the inspection or to verify the crane's performance after maintenance procedures.

***No personnel shall be allowed to climb onto the crane or enter the crane cab unless performance of***

***their duties require them to do so, and then only with knowledge of the operator or other qualified person.***

**Qualified person** is defined as one who by reason of training and experience is thoroughly familiar with crane operations and the hazards involved. Such a person shall meet the operator qualifications specified in OSHA Regulations (United States Federal Law), in ASME B30.5 American Nation Standard, or in any other applicable federal, state, or local laws.

**Operator training and qualification is crane owner's responsibility.**

**NOTE:** The regulations and standards mentioned above and later in this section can be obtained from:

**US DOL/OSHA** Rules and Regulations are available by mail from the Superintendent of Documents, PO Box 371954, Pittsburgh, PA, 15250-7954 or by:

- Phone 202-512-1899
- Fax 202-512-2250
- Electronically via GPO Access at docs or from [www.osha.gov](http://www.osha.gov).

**ASME** (formerly ANSI) B30 Series American National Standards are available by mail from the ASME, 22 Law Drive, Fairfield, New Jersey, 0700-2900 or by:

- Phone US & Canada 800-843-2763
- Phone Mexico 95-800-843-2763
- Phone Universal 973-882-1167
- Fax 973-882-1717 or 973-882-5155
- E-mail [infocentral@asme.org](mailto:infocentral@asme.org).

### Operator Conduct

1. Operator shall not engage in any practice which diverts his/her attention while operating crane.
2. Operator shall not operate crane when physically or mentally unfit.
3. Operator shall be responsible for all operations under his/her direct control. When safety of an operation is in doubt, operator shall consult with person supervising lift before lifting load.
4. Operator shall be thoroughly familiar with operation of crane and its proper care. If adjustments or repairs are necessary or if there are known defects that impair safe operation, crane shall not be operated until unsafe conditions have been corrected.

5. If there is a warning sign at start controls, operator shall not start engine until warning sign has been removed by person who installed it.
6. Before starting engine, operator shall make sure that:
  - a. All daily inspection and maintenance services have been performed.
  - b. All controls are in off position and all brakes and locking devices are applied or engaged.
  - c. All personnel are clear of crane. Deploy a swing radius barrier.
7. Operator shall test all controls, limits, and communication systems at start of each shift. Any defects found shall be corrected before operation is begun.

**WARNING**

Operational aids (accessories) such as rated capacity indicator or limiter, boom and jib angle indicator or limiter, anti-two-block device, level indicator, swing limiter, proximity device, etc., may be installed on your crane. Such devices are to be used only as **AIDS TO ASSIST OPERATOR**; their presence on crane in no way substitutes for or lessens requirement that operator knowledge, experience, and judgment are required to ensure safe operation of crane.

**Crane shall not be loaded beyond applicable static or dynamic ratings given on capacity chart for crane.**

- See Size of Load later in this section.
  - See Section 3 of this manual and Operation Aids topic in this section for purpose of each operational aid.
8. Operator shall not start crane movement if the load or designated signal person is not within his/her range of vision or communication.
  9. Operator shall understand and respond to signals from the person directing the lift or from the designated signal person. When a signal person or crane follower is not required, operator is responsible for lift. **Operator shall obey a stop signal at all times, no matter who gives it.**
  10. Operator shall verify that the capacity chart being used is the correct one for how the crane is equipped (boom length, load line reeving, counterweight, etc.).
  11. Operator shall verify that:
    - a. All attachments are properly assembled and attached to the crane according to the rigging drawings called for on the capacity chart.

- b. The counterweight — to include applicable auxiliary counterweight — is in place and of proper weight. **Maximum required counterweight shall not be exceeded.**

**WARNING****Moving Load/Tipping Crane Hazard!**

Changing weather conditions including but not limited to: wind, ice or snow accumulation, precipitation, flooding, lightning, etc. should be considered when determining the location and configuration of a crane when it will be left unattended.

12. Operator shall perform the following operations before leaving operator's cab for any reason:

- a. Park crane and position upperworks so crane does not interfere with operation of other equipment.
- b. Apply travel and swing brakes or locking devices.
- c. Land any attached load.
- d. Lower boom onto blocking at ground level or onto a boom rest if possible.

If the boom cannot be lowered, as determined by a qualified designated person, it must be securely fastened from movement by wind or other outside forces (see Wind Conditions in Capacity Chart Manual).

**NOTE:** The designated person must be familiar with the job site limitations, the crane configuration, and the expected weather conditions.

- e. Move all controls to off.
- f. Apply all drum brakes and pawls.
- g. Disengage master clutch, if equipped.
- h. Stop engine.

**NOTE:** Also read Unattended Crane instructions in Section 3 of the Crane Operator's Manual.

13. Operator shall perform following operations if power or a control function fails during operation:

- i. Land all suspended loads, if possible, under brake or power control.
- j. Apply all brakes and locking devices.
- k. Move all controls to off.

14. If crane will be operated at night, operator shall make sure that there is sufficient lighting for safe operation. Load and landing area shall be illuminated.

15. Operator shall not operate crane during periods of bad weather if his or her ability to see load or signal person is impaired by darkness, fog, rain, snow, etc.

Never operate crane with a snow or ice-covered boom or jib. The extra weight may cause overload or tipping.

Never operate crane during an electrical thunderstorm.

When a local weather storm warning exists (including electrical thunderstorm), stop operation and secure crane. See step 12 under Operator Conduct topic.

**NOTE:** DO NOT depend on grounding. Grounding of a crane affords little or no protection from electrical hazards. The effectiveness of grounding is limited by size of conductor (wire) used, condition of ground, magnitude of voltage and current present, and numerous other factors.

16. Wind can cause crane to tip or boom and other attachments to collapse. Operator or qualified person directing lift shall compensate for effect of wind on load and boom by reducing ratings, reducing operating speeds, or a combination of both.

Unless otherwise specified on Capacity Chart, or in Operator's Manual, stop operation under following wind conditions:

- a. If wind causes load to swing forward past allowable operating radius or sideways past either boom hinge pin, land load and apply drum brakes.
- b. If wind exceeds 35 mph, land all loads and apply drum brakes, lower boom onto blocking at ground level or otherwise restrain it, and apply swing and travel brakes and/or locks.

**NOTE:** "**Land load**" means to set it down on a firm uniformly supporting surface.

17. Booms, jibs, or masts which are being assembled or disassembled on ground (with or without support of boom rigging) shall be securely blocked to prevent dropping of boom, jib, or mast sections.

**Workers shall not go under boom, jib, or mast sections when removing connecting pins or bolts.**

18. Each outrigger shall be visible to operator or signal person during extension and retraction.

## Handling Load

### Size of Load

1. Crane shall not be loaded beyond applicable static or dynamic ratings given on the capacity chart for the crane configuration.

**NOTE:** Capacity charts for Manitowoc cranes show the total weight of freely suspended loads for various boom and jib lengths and operating radii.

**"Freely suspended load"** is a load that is hanging free with no direct external force applied except by the crane's load-line reeving.

To determine actual weight of load which can be lifted at a given radius (working load), operator must deduct weight of certain lifting equipment from total weight given on chart. See specific capacity chart for your crane for a list of lifting equipment which must be deducted.

Operator's judgment must be used to further reduce total weight to allow for dynamic effects of swinging, hoisting, or lowering, and adverse weather conditions to include wind.

2. Operator or other designated person directing the lift shall verify that weight of load is within static or dynamic rating for radius at which load will be lifted.

**Verified weights and measured radii shall take priority over RCI/RCL readings.**

### Attaching Load

1. Attach hook to load with slings, or other suitable rigging. Each hook shall have a latch that is in proper working order. **Hook latches shall not be wired open.**
  - a. Inspect each hook and latch before using.
  - b. Never use a hook or latch that is distorted or bent.
  - c. Make sure spring will force latch against tip of hook.
  - d. Make sure hook supports load. Latch must never support load. Latches are only intended to retain loose slings under slack conditions.
2. Only use slings and other rigging that are in safe operating condition and have a rating equal to or greater than the load to be lifted.
3. Do not wrap load line around load.
4. Use suitable protection between slings and any sharp edges on load.
5. Secure unused legs of a multi-leg sling before handling a load with one leg of sling.

### Lifting/Moving Load

1. Before lifting or moving load, operator or qualified person directing lift shall make following checks:
  - a. Crane has a firm uniformly supporting foundation under both crawlers, all tires, or each outrigger jack pad or float. Unless otherwise specified on capacity chart, foundation shall be *level to within 1% — 1 ft (0,3 m) rise or fall in 100 ft (30,5 m) distance.*

When such a surface is not available, it shall be provided with timbers, cribbing, or other structural members to distribute load such that allowable

bearing capacity of underlying member is not exceeded.

*Contact Manitowoc Crane Care for ground bearing data.*

- b. Load is secured and properly balanced in slings or lifting device before lifting the load more than 3 to 6 in (76 to 152 mm).
  - c. Lift and swing paths are clear of personnel and obstructions.
  - d. Load is free to be lifted.
  - e. Load line is not kinked or otherwise damaged.
  - f. Multiple part load lines are not twisted around each other in such a manner that lines will not separate when load is lifted.
  - g. Hook is brought over load in a manner that will minimize twisting or swinging.
  - h. Load line and boom hoist ropes are properly spooled on drums and seated in sheaves.
  - i. Load drum brakes are in proper working order.  
Operator shall test load drum brakes each time a load approaching rated load is handled. Lift load 3 to 6 in (76 to 152 mm) and fully apply brakes — *load must not lower through applied brakes.*
  - j. Unused load drums are parked (working and parking brakes applied; if equipped, drum pawls engaged).
  - k. All personnel are clear of swing radius of crane's counterweight.
2. While lifting or moving load, operator shall take following precautions:
- a. Accelerate and decelerate load smoothly to avoid excessive stress on crane boom and machinery.
  - b. Avoid sudden starts and stops while swinging. Keep swing speed under control to prevent load from swinging out beyond radius at which load can be handled and to minimize the pendulum action of load.
  - c. Use taglines or other restraints to control load when necessary.
  - d. Do not exceed any swing limitations (areas of operation) given on capacity chart.
  - e. Do not allow load, boom, or any other part of crane to contact obstructions.
  - f. Do not use crane to drag a load.

- g. Do not hoist, lower, or swing load while personnel are on load or hook. See Personnel Handling in this section.

- h. Avoid carrying load over personnel. Loads which are suspended shall be blocked or cribbed before personnel are allowed to work under or between them.

- i. Before lifting a load which requires use of outriggers (or anytime outriggers are used), fully extend outrigger beams and jacks so the truck tires do not bear any load.

Securely fasten outrigger jack pads or floats to jacks and set them on a flat, firm surface that will support load placed on pads or floats. Do not set jack pads or floats in holes, on rocky ground, or on extremely soft ground.

When dictated by ground conditions, install wood blocking or steel plates under jack pads or floats to properly distribute loading on the supporting surface.

Wood blocking or steel plates used under jack pads or floats shall be:

- Free of defects.
- Strong enough to prevent crushing, bending, or shear failure.
- Of sufficient thickness, width, and length to completely support the jack pad or float, transmit the load to the supporting surface, and prevent shifting, toppling, or excessive settlement under load.

- j. Fully retract and lock jacks and outrigger beams so they cannot extend when not in use.

- k. Operate with extreme caution when using two or more cranes to lift same load.

One designated person shall be responsible for operation when two or more cranes are used to lift same load. Designated person shall analyze lift and instruct all personnel involved in proper rigging and positioning of load and all movements to be made. Decisions such as necessity to reduce crane ratings, load position, boom position, ground support, and speed of movements shall be in accordance with designated person's decision.

- l. Do not lower load or boom to a point where less than two full wraps of wire rope remain on the respective drum (or as otherwise indicated in local, state, or federal regulations).
- m. Engage boom hoist pawl when operating with boom at a fixed radius.

3. While traveling, operator shall take following precautions:
  - a. Sound signal horn before traveling and intermittently while traveling, especially when approaching personnel.
  - b. Carry boom in-line with lowerworks and facing direction of travel.
  - c. Do not position boom so high that it could bounce over backwards whether traveling with or without load.
  - d. Lock upperworks against rotation except when it is necessary to negotiate a turn, and then only when operator is seated at controls or the boom is supported on a dolly.
  - e. Lash or otherwise restrain unused hooks so they cannot swing freely.
4. Before traveling with a load, operator shall take following additional precautions:
  - a. A designated person shall be responsible for operation. Decisions such as necessity to reduce crane ratings, load position, boom position, ground support, and speed of movements shall be in accordance with designated person's decision.
  - b. Maintain specified tire pressures (truck cranes).
  - c. Avoid sudden starts and stops. Use taglines or other restraints to control position of load.
4. Crane shall be thoroughly inspected for load line interference caused by routing and reeving of multiple load lines. If interference is found, it shall be eliminated.
5. For cranes produced before 2003, Rated Capacity Indicators/Limiters were not required by ASME B30.5 for non-personnel lifting.
 

To aid operator in staying within crane's capacity chart with total applied load, Manitowoc recommends that its cranes be equipped with Rated Capacity Indicators/Limiters to monitor load on each load line.

***Operator is still responsible knowing load and radius whether or not crane is equipped with load indicator(s).***
6. Manitowoc also recommends that each load line be equipped with an anti two-block device.
7. Manitowoc's Capacity Charts are based on freely suspended loads. To prevent side load damage to boom, jib, and sheaves:
  - Load lines must hang as near vertical as possible to minimize side and forward loads.
  - Load must remain centered on boom and jib point shafts unless special lift approval is granted by Manitowoc.
  - Load lines should be located over load's center of gravity as it is supported on a trailer, barge, or ground.
8. Crane operator must be familiar with operational characteristic of crane as it relates to multiple drum operation (simultaneous operation, same or opposite direction, or individual operation).
9. When using tandem drums, maximum operating layers may be limited depending on whether crane was initially designed for tandem drum operation or not.

### **Multiple Load Line Operation**

Multiple load line operation is becoming common practice for applications like panel tilt-up, pile tilt-up, pile driving, rolling fabricated sections, etc. The multiple lines may be on a common shaft (each with different parts of line) or on multiple shafts (boom and upper point, boom and fixed jib point, etc.).

Manitowoc authorizes multiple load line operation for those applications requiring it, provided following steps are performed:

1. A qualified lift planner and crane operator shall read and become thoroughly familiar with appropriate Capacity Charts and Wire Rope Specification Charts.
2. Lift planner and crane operator shall make sure total load does not exceed rated capacity given in Capacity Chart and Wire Rope Specification Chart for given boom point or jib point.
 

EXAMPLE: If one load line is lifting from jib point, proper jib chart applies.
3. Crane shall be thoroughly inspected by a qualified person prior to setup.



### **WARNING**

#### **Avoid Over Load and Side Load Damage to Crane**

Manitowoc highly recommends that you contact your Manitowoc distributor for lift planning assistance and approval.

### **Holding Load**

When a load is suspended, operator shall take following precautions:

1. Not leave his/her position at controls.
2. Not allow personnel to stand or pass under load.

3. Move all controls to off, apply all drum brakes, engage boom hoist pawl, and apply swing and travel brakes or locks.

## Signals

1. Continuous communication shall be maintained between operator and signal person during all crane movements. If communication is disrupted, **operator shall stop all crane movements**.
2. Signals to operator shall be in accordance with standard signals shown in Section 3, unless communications equipment (telephone, radio, etc.) is used.
3. All signals shall be easily understood by operator at all times. Operator shall not respond to any signal which is not clearly understood.
4. For operations not covered in standard signals, or for special situations or emergencies, additional signals may be required. In those cases, signals used shall be agreed upon in advance by operator and signal person. Signals used shall not conflict with or have potential to be confused with standard signals.
5. When it is necessary to give instructions to operator (other than those established by signal system), all crane motions shall be stopped.
6. Signal person shall:
  - a. Be tested by a designated person and show that he or she has a basic understanding of crane operations and limitations and is thoroughly familiar with the standard hand signals and voice signals if used.
  - b. Be positioned in clear view of operator. Signal person's position should give him or her a clear view of load, crane, and operating area.
  - c. Direct load so it does not pass over personnel.
  - d. Keep unnecessary personnel out of crane's operating area.
7. When moving crane, following audible signals shall be used:
  - a. STOP - one short audible signal.
  - b. GO AHEAD - two short audible signals.
  - c. BACK UP - three short audible signals.

## Operational Aids

Verified weights, measured radii, and Manitowoc's Capacity Charts and instructions shall take precedence over operational aids when handling a load. If it is necessary to temporarily override an operational aid, crane user shall stay within limits of Manitowoc's Capacity Charts and instructions.

A designated, qualified person responsible for directing the lift shall make sure load does not exceed capacity chart.

When operational aids are inoperative or malfunctioning, the following steps shall be taken to ensure safe continued operation of the crane.

1. Steps shall be taken to schedule repairs and calibration immediately. Operational aids shall be put back into service as soon as replacement parts, if required, are available and repairs and calibration can be carried out. Every reasonable effort must be made to expedite repairs and calibration.
2. When **rated capacity indicator/limiter** is inoperative or malfunctioning, designated, qualified person directing lift shall establish procedures for determining load weights and shall make sure that weight of load does not exceed crane rating at radius where load is handled.
3. When **boom angle** or **radius indicator** is inoperative or malfunctioning, radius or boom angle shall be determined by measurement (i.e., measure radius with tape measure; measure boom angle with a protractor-level on centerline of boom).
4. When **boom or jib angle limiter (automatic boom or jib stop)** is inoperative or malfunctioning, qualified person directing lift shall make sure maximum boom angle/radius specified on capacity chart for load being handled is not exceeded. Radius and boom angle shall be determined by measurement (i.e., measure radius with tape measure; measure angle with a protractor-level on centerline of boom).
5. When **anti-two-block device** is inoperative or malfunctioning, qualified person directing lift shall establish procedures to furnish equivalent protection (i.e., assign an additional signal person to observe distance between load and boom or jib point).
 

This practice does not apply when lifting personnel in load line supported baskets. **Personnel shall not be lifted in load line supported baskets when anti-two-block devices are not functioning properly.**
6. When **level indicator** is inoperative or malfunctioning, other means shall be used to level crane within limits specified on capacity chart (i.e., level crane using a carpenter level on rotating bed).
7. When **boom length indicator** is inoperative or malfunctioning, qualified person directing lift shall establish boom length at which lift will be made by actual measurement and marking of boom.
8. When **swing limiter** or other **proximity device** is inoperative or malfunctioning, qualified person directing lift shall establish procedures to furnish equivalent protection (i.e., assign an additional signal person to

observe distance between boom or load and job site obstructions to include power lines).

9. When **drum spooling limiter** (maximum or minimum bail limit) is inoperative or malfunctioning, qualified person directing lift, operator, or designated signal person shall watch drum and make sure it is not over spooled (rope does not jump off drum) and that there are never less than 2 full wraps of wire rope on load drum or boom hoist (or as otherwise indicated in local, state, or federal regulations).
10. When **closed-circuit television** (CCTV) is inoperative or malfunctioning, designated signal persons shall watch load, drums, and counterweight and provide necessary hand or voice signals to the crane operator.

## OPERATING NEAR ELECTRIC POWER LINES AND TRANSMISSION LINES

### Electrocution Hazard

Thoroughly read, understand, and abide by all applicable federal, state, and local regulations regarding operation of cranes near electric power lines or equipment.

***United States federal law prohibits the use of cranes closer than 10 ft (3 m) to power sources up to 50,000 volts, and greater distances for higher voltages [29CFR1910.180 and 29CFR1926.550].***

***To avoid death or serious injury, Manitowoc recommends that all parts of crane, boom, and load be kept at least 20 ft (6 m) away from all electrical power lines and equipment.***

**NOTE:** For detailed guidelines on operating near power lines, refer to current edition of ASME B30.5 American National Standard.

Keep all personnel and their personal belongings (clothing, water coolers, lunch buckets, etc.) away from crane if it is being operated near electrical power lines or equipment.

Before operating crane in the vicinity of electrical power lines or equipment, notify the power utility company. Obtain positive and absolute assurance that the power has been turned off.

The crane is NOT INSULATED. Always consider all parts of the load and the crane, including the wire rope, pendants or straps, and tag lines as conductors.

Most overhead power lines ARE NOT insulated. Treat all overhead power lines as being energized unless you have reliable information to the contrary from the utility company or owner.

The rules in this section must be followed at all times, even if the electrical power lines or equipment have been de-energized.

Crane operation is dangerous when close to an energized electrical power source. Exercise extreme caution and prudent judgement. Operate slowly and cautiously when in the vicinity of power lines.

If the load, wire rope, boom, or any portion of the crane contacts or comes too close to an electrical power source, everyone in, on, and around the crane can be seriously injured or killed.

The safest way to avoid electrocution is to stay away from electrical power lines and electrical power sources.

The operator is responsible for alerting all personnel of dangers associated with electrical power lines and equipment. The crane is not insulated. Do not allow unnecessary personnel in the vicinity of the crane while operating. Permit no one to lean against or touch the crane. Permit no one, including riggers and load handlers, to hold the load, load lines, tag lines, or rigging gear.

Even if the crane operator is not affected by an electrical contact, others in the area may become seriously injured or killed.

It is not always necessary to contact a power line or power source to become electrocuted. Electricity, depending on magnitude, can arc or jump to any part of the load, load line, or crane boom if it comes too close to an electrical power source. Low voltages can also be dangerous.

### Set-Up and Operation

During crane use, assume that every line is energized ("hot" or "live") and take necessary precautions.

Position the crane such that the load, boom, or any part of the crane and its attachments cannot be moved to within 20 ft (6 m) of electrical power lines or equipment. This includes the crane boom and all attachments. Overhead lines tend to blow in the wind so allow for lines' movement when determining safe operating distance.

A suitable barricade should be erected to physically restrain the crane, all attachments, and the load from entering into an unsafe distance from electrical power lines or equipment.

Plan ahead and always plan a safe route before traveling under power lines. A wooden clearance frame should be constructed to ensure sufficient clearance is maintained between crane and power lines.

Appoint a reliable and qualified signal person, equipped with a loud signal whistle or horn and voice communication equipment, to warn the operator when any part of the crane or load moves near a power source. This person should have no other duties while the crane is working.

Tag lines should always be made of non-conductive materials. Any tag line that is wet or dirty can conduct electricity.



DO NOT store materials under power lines or close to electrical power sources.

Prior to operating near transmitter towers where an electrical charge can be induced into the crane or load:

- The transmitter shall be deenergized OR,
- Tests shall be made to determine if an electrical charge will be induced into the crane or load.

Every precaution shall be taken to dissipate induced voltages. Consult local, state, and federal codes and regulations.

## Electrocution Hazard Devices

The use of insulated links, insulated boom cages/guards, proximity warning devices, or mechanical limit stops does not assure that electrical contact will not occur. Even if codes or regulations require the use of such devices, failure to follow the rules in this section may result in serious injury or death.

Be aware that such devices have limitations and you should follow the rules and precautions outlined in this section at all times even if the crane is equipped with these devices.

Insulating links installed into the load line afford limited protection from electrocution hazards. Links are limited in their lifting abilities, insulating properties, and other properties that affect their performance. Moisture, dust, dirt, oils, and other contaminants can cause a link to conduct electricity. Due to their capacity ratings, some links are not effective for large cranes and/or high voltages/currents.

The only protection that may be afforded by an insulated link is below the link (electrically downstream), provided the link has been kept clean, free of contamination, has not been scratched or damaged, and is periodically tested (just before use) for its dielectric integrity.

Boom cages and boom guards afford limited protection from electrocution hazards. They are designed to cover only the boom nose and a small portion of the boom. Performance of boom cages and boom guards is limited by their physical size, insulating characteristics, and operating environment (e.g. dust, dirt, moisture, etc.). The insulating characteristics of these devices can be compromised if not kept clean, free of contamination, and undamaged.

Proximity sensing and warning devices are available in different types. Some use boom nose (localized) sensors and others use full boom length sensors. No warning may be given for components, cables, loads, and other attachments located outside of the sensing area. Reliance is placed upon the operator in selecting and properly setting the sensitivity of these devices.

Never rely solely on a device to protect you and your fellow workers from danger.

Some variables you must know and understand are:

- Proximity devices are supposed to detect the existence of electricity and not its distance, quantity, or magnitude.
- Some proximity devices will detect only alternating current (AC) and not direct current (DC).
- Some proximity devices detect radio frequency (RF) energy and others do not.
- Most proximity devices simply provide a signal (audible, visual, or both) for the operator and this signal must not be ignored.
- Sometimes the sensing portion of the proximity devices becomes confused by complex or differing arrays of power lines and power sources.

DO NOT depend on grounding. Grounding of a crane affords little or no protection from electrical hazards. The effectiveness of grounding is limited by the size of the (wire) conductor used, the condition of the ground, the magnitude of the voltage and current present, and numerous other factors.

## Electrical Contact

If the crane comes in contact with an energized power source, the operator must:

1. Stay in the crane cab. **DON'T PANIC.**
2. Immediately warn **PERSONNEL** in the vicinity to **STAY AWAY.**
3. Attempt to move the crane away from the contacted power source using the crane's controls which are likely to remain functional.
4. Stay in the crane until the power company has been contacted and the power source has been de-energized. **NO ONE** must attempt to come close to the crane or load until the power has been turned off.

Only as a last resort should an operator attempt to leave the crane upon contacting a power source. If it is absolutely necessary to leave the cab, **JUMP COMPLETELY CLEAR OF CRANE. DO NOT STEP OFF.** Hop away with both feet together. **DO NOT** walk or run.

Following any contact with an energized electrical source, the local, authorized, Manitowoc distributor must be immediately advised of the incident and consulted on necessary inspections and repairs. Thoroughly inspect the wire rope and all points of contact on the crane. Should the distributor not be immediately available, contact Manitowoc Crane Care at factory. The crane must not be returned to service until it is thoroughly inspected for any evidence of damage and all damaged parts are repaired or replaced as authorized by your Manitowoc distributor.

## REFUELING

1. When using a portable container to refuel crane, container shall be a safety-type can equipped with an automatic closing cap and a flame arrester.
2. Engine shall be **stopped** before refueling crane.
3. Smoking and open flames shall be prohibited in refueling area.

## FIRE EXTINGUISHERS

1. A portable fire extinguisher with a minimum rating of 10 BC shall be installed in operator's or machinery cab of crane.
2. Operator and all maintenance personnel shall be thoroughly familiar with location, use, and care of fire extinguisher(s) provided.

## ACCIDENTS

If this crane becomes involved in a property damage and/or personal injury accident, immediately contact Manitowoc Crane Care or the Product Safety and Reliability Manager at the following address:

**Manitowoc Cranes**  
2401 So. 30th St.  
Manitowoc, WI 54220

Phone: 1-888-499-7278 or  
920-683-6390

Provide a complete description of the accident, including the crane model and serial number.

## SAFE MAINTENANCE PRACTICES



### WARNING

Importance of safe maintenance cannot be over emphasized. Carelessness and neglect on part of maintenance personnel can result in their death or injury and costly damage to the crane or property.

Safety information in this publication is intended only as a guide to assist qualified maintenance personnel in safe maintenance. Manitowoc cannot foresee all hazards that will arise in field; therefore, **safety remains responsibility of maintenance personnel and crane owner.**

## Maintenance Instructions

To ensure safe and proper operation of Manitowoc cranes, they must be maintained according to the instructions

contained in this manual and the Service Manual provided with the crane.

Crane maintenance and repair must be performed by personnel who by reason of training and experience are thoroughly familiar with the crane's operation and required maintenance. These personnel must **read Operator's Manual and Service Manual before attempting any maintenance procedure**. If there is any question regarding maintenance procedures or specifications, contact your Manitowoc distributor for assistance.

**Training/qualification of maintenance personnel is responsibility of crane owner.**

## Safe Maintenance Practices

1. Perform following steps (as applicable) before starting a maintenance procedure:
  - a. Park crane where it will not interfere with other equipment or operations.
  - b. Lower all loads to ground or otherwise secure them against movement.
  - c. Lower boom onto blocking at ground level, if possible, or otherwise secure boom against dropping.
  - d. Move all controls to off and secure all functions against movement by applying or engaging all brakes, pawls, or other locking devices.
  - e. Stop engine and render starting means inoperative.
  - f. Place a warning sign at start controls alerting other personnel that crane is being serviced and engine must not be started. *Do not remove sign until it is safe to return crane to service.*
2. Do not attempt to maintain or repair any part of crane while engine is running, unless absolutely necessary.

If engine must be run, keep your clothing and all parts of your body away from moving parts. **Maintain constant verbal communication between person at controls and person performing maintenance or repair procedure.**

3. Wear clothing that is relatively tight and belted.
4. Wear appropriate eye protection and approved hard hat.
5. Never climb onto or off a moving crane. **Climb onto and off crane only when it is parked and only with operator's permission.**

Use *both hands* and handrails, steps and ladders provided to climb onto and off crane.

Lift tools and other equipment which cannot be carried in pockets or tool belts onto and off crane with hand lines or hoists.

6. Boom and gantry are not intended as ladders. Do not attempt to climb lattice work of boom or gantry to get to maintenance points. If boom or gantry is not equipped with an approved ladder, lower them before performing maintenance or repair procedures.
7. Do not remove cylinders until working unit has been securely restrained against movement.
8. Pinch points are impossible to eliminate; watch for them closely.
9. Pressurized air, coolant, and hydraulic oil can cause serious injury. Make sure all air, coolant, and hydraulic lines, fittings, and components are tight and serviceable.

***Do not use your hands to check for air and hydraulic oil leaks:***

- Use a soap and water solution to check for air leaks (apply to fittings and lines and watch for bubbles).
  - Use a piece of cardboard or wood to check for coolant and hydraulic oil leaks.
10. Relieve pressure before disconnecting air, coolant, and hydraulic lines and fittings.
  11. Do not remove radiator cap while coolant is hot or under pressure. Stop engine, wait until pressure drops and coolant cools, then slowly remove cap.
  12. Avoid battery explosion: do not smoke while performing battery maintenance, do not short across battery terminals to check its charge.
  13. Read safety information in battery manufacturer's instructions before attempting to charge a battery.
  14. Avoid battery acid contact with skin and eyes. If contact occurs, flush area with water and immediately consult a doctor.
  15. Stop engine before refueling crane.
  16. Do not smoke or allow open flames in refueling area.
  17. Use a safety-type can with an automatic closing cap and flame arrestor for refueling.
  18. Hydraulic oil can also be flammable. Do not smoke or allow open flames in area when filling hydraulic tanks.
  19. Never handle wire rope with bare hands. Always wear heavy-duty gloves to prevent being cut by broken wires.
  20. Use extreme care when handling coiled pendants. Stored energy can cause coiled pendants to uncoil quickly with considerable force.
  21. When inflating tires, use a tire cage, a clip-on inflator, and an extension hose which permits standing well away from tire.
  22. Only use cleaning solvents which are non-volatile and non-flammable.

23. Do not attempt to lift heavy components by hand. Use a hoist, jacks, or blocking to lift components.
24. Use care while welding or burning on crane. Cover all hoses and components with non-flammable shields or blankets to prevent a fire or other damage.
25. To prevent damage to crane parts (bearings, cylinders, swivels, slewing ring, computers, etc.), perform following steps ***before welding on crane:***
  - Disconnect all cables from batteries.
  - Disconnect output cables at engine junction box.
  - Attach ground cable from welder directly to part being welded and as close to weld as possible.

Do not weld on engine or engine mounted parts (per engine manufacturer).

26. Disconnect and lock power supply switch before attempting to service high voltage electrical components and before entering tight areas (such as carbody openings) containing high voltage components.
27. When assembling and disassembling booms, jibs, or masts on ground (with or without support of boom rigging pendants or straps), securely block each section to provide adequate support and alignment.

***Do not go under boom, jib, or mast sections while connecting bolts or pins are being removed.***

28. Unless authorized in writing by Manitowoc, do not alter crane in any way that affects crane's performance (to include welding, cutting, or burning of structural members or changing pressures and flows of air/hydraulic components). Doing so will invalidate all warranties and capacity charts and make crane owner/user liable for any resultant accidents.
29. ***Keep crane clean.*** Accumulations of dirt, grease, oil, rags, paper, and other waste will not only interfere with safe operation and maintenance but also create a fire hazard.
30. Store tools, oil cans, spare parts, and other necessary equipment in tool boxes. Do not allow these items to lie around loose in operator's cab or on walkways and stairs.
31. Do not store flammable materials on crane.
32. Do not return crane to service at completion of maintenance or repair procedures until all guards and covers have been reinstalled, trapped air has been bled from hydraulic systems, safety devices have been reactivated, and all maintenance equipment has been removed.
33. Perform a function check to ensure proper operation at completion of maintenance or repair.

***THIS PAGE BLANK***

## ENVIRONMENTAL PROTECTION

***Dispose of waste properly!*** Improperly disposing of waste can threaten the environment.

Potentially harmful waste used in Manitowoc cranes includes — but is not limited to — oil, fuel, grease, coolant, air conditioning refrigerant, filters, batteries, and cloths which have come into contact with these environmentally harmful substances.


Handle and dispose of waste according to local, state, and federal environmental regulations.

When filling and draining crane components: do not pour waste fluids onto the ground, down any drain, or into any source of water.


- Always drain waste fluids into leak proof containers that are clearly marked with what they contain.
- Always fill or add fluids with a funnel or a filling pump.
- Immediately wipe up any spills.

A10415

**View A**  
**WRONG – DANGEROUS!**



**View B**  
**WRONG – DANGEROUS!**



**View C**  
**RIGHT – SAFE**




FIGURE 2-5

## BOOM DISASSEMBLY SAFETY

**NOTE:** The term “boom” used in the following instructions applies to all lattice attachments (fixed jib, luffing jib, mast, etc.).



### DANGER!

#### Collapsing Boom Hazard!

Prevent death or serious injury when disassembling boom sections — read and adhere to following instructions.

Safe handling of lattice booms during disassembly is a primary concern for preventing serious or fatal injuries. A boom can collapse during disassembly if workers fail to observe safe working practices.

Accidents during boom disassembly usually result from one of three primary causes:

- Workers are not familiar with equipment or are not properly trained.
- Disassembly area is not suitable.
- Safe procedures are overlooked because not enough time is allocated for the task.

### General

Safety decals (Figure 2-6) are placed near the connectors on the boom sections as shown on the Boom Disassembly Decal Drawing at the end of this section.

Workers involved with boom disassembly must be trained and experienced in the operation and disassembly of construction cranes. Everyone must read and understand these instructions, the information in the Boom Assembly Drawing, and the instructions in Section 4 of this manual before beginning disassembly. **One worker who does not fully understand or fails to follow correct procedures can endanger other workers.**

### Location

Select a suitable location for boom disassembly. It must be firm, level, and be free of obstructions. It should have enough open space to accommodate the crane, the length of boom, and – if required – movement of an assist crane or other equipment. If possible, secure the area to keep unauthorized personnel and vehicles away.

### Pin Removal

When removing pins from boom sections, stand clear of pins being removed. Even though the boom is resting on

blocking, individual pin connections may still be under load. Pins can be ejected forcefully if the boom has any pressure on it or if the boom is not supported properly.



FIGURE 2-6

### Disassembly Precaution

Always block boom sections so they are securely supported and cannot shift or move suddenly when pins are removed. If there is any doubt about a boom disassembly procedure, **block tightly under boom sections before removing any pin.**



### DANGER

#### Collapsing Boom Hazard!

Boom can collapse or jerk when pins are removed. To avoid death or serious injury:

- Do not remove bottom connecting pins from any boom section when boom is supported by straps as shown in Figure 2-5, View A.
- Do not remove strap connecting pins until straps are fully lowered into supports as shown in Figure 2-5, View C.
- Do not remove bottom connecting pins from any boom section when boom point is resting on ground and handling pendants are slack as shown in Figure 2-5, View B.
- Never work or stand inside boom unless it is lowered and securely blocked as shown in Figure 2-5, View C.
- Do not stand or walk on top of boom unless it has walkways.



### DANGER

#### Falling Boom Hazard!

Crane can tip or boom can collapse if excess boom is cantilevered. Never cantilever more boom than allowed in rigging drawings or capacity charts.

## PERSONNEL HANDLING POLICY

In 1998, the American Society of Mechanical Engineers issued a new American National Standard entitled, Personnel Lifting Systems, ASME B30.23-1998. This standard provides, ***“lifting and lowering of personnel using ASME B30 Standard hoisting equipment shall be undertaken only in circumstances when it is not possible to accomplish the task by less hazardous means. Unless all of the applicable requirements of this volume are met, the lifting or lowering of personnel using ASME B30 Standard equipment is prohibited.”***

The ASME Standards recognize that mobile and locomotive cranes are primarily designed and intended for handling materials and not personnel. The ASME Standards have a retrofit statement that applies to existing cranes after the standards go into effect. It is not the intent of the standards to require retrofitting of existing equipment. If an item is being modified, the performance requirement shall be reviewed relative to the current standard. The standards contain more criteria than the current OSHA 1926.550.

This new standard is consistent with the U.S. Department of Labor, Occupational Safety and Health Administration (OSHA) regulations for Construction that state, in 29CFR1926.550(g)(2) General Requirements: ***“The use of a crane or derrick to hoist employees on a personnel platform is prohibited, except when the erection, use, and dismantling of conventional means of reaching the work site, such as a personnel hoist, ladder, stairway, aerial lift, elevating work platform or scaffold, would be more hazardous or is not possible because of structural design or work site conditions.”***

Use of a Manitowoc crane to handle personnel is acceptable provided:

- The crane user shall comply with the manufacturer's specifications and limitations for lifting accessories (hooks, slings, personnel platforms, etc.).
- The requirements of the applicable national, state and local regulations and safety codes are met.
- A determination has been made that use of a crane to handle personnel is the least hazardous means to perform the work.
- The crane operator shall be qualified to operate the specific type of hoisting equipment used in the personnel lift.
- The crane operator and occupants have been instructed in the recognized hazards of personnel platform lifts.
- The crane is in proper working order.
- Load and boom hoist drum brakes, swing brakes, and locking devices such as pawls and dogs shall be engaged when the occupied personnel platform is in a stationary position.

- The crane is equipped with a positive acting device which prevents contact between the load block or overhaul ball and the boom tip (anti-two block device).  
For friction cranes, this implies the addition of spring applied brakes activated by the anti-two block device. The load line hoist drum shall have a system or device on the power train, other than the load hoist brake, which regulates the lowering rate of speed of the hoist mechanism (controlled load lowering).
- The crane's Operator's Manual is in the crane's cab, readily accessible to the Operator.
- The crane's load capacity chart is affixed inside the crane's cab, readily accessible to the operator. The total weight of the loaded personnel platform and related rigging shall not exceed 50 percent of the rated capacity for the radius and configuration of the crane.
- The crane is uniformly level within one percent of level grade and located on a firm footing. Some capacity charts require more stringent levelness criteria. Cranes with outriggers shall have them all fully deployed following manufacturer's specifications.
- The platform meets the requirements as prescribed by applicable standards and regulations.
- Applicable personnel protection equipment is provided (i.e., personal fall-arrest system, etc.)
- For wire rope suspended platforms, the crane is equipped with a hook latch that can be closed and locked, eliminating the throat opening.
- The platform is properly attached and secure.
- Handling personnel from a platform suspended by wire rope from a luffing jib is acceptable, but only when it is not possible to accomplish the task using a less hazardous means. The crane user and operator shall take into account hazards that may be present when using a luffing jib.
- Direct attachment of a personnel platform to a luffing jib is prohibited.
- Personnel platforms must not be used if wind exceeds 20 mph (9 m/s).
- Hoisting personnel within 20 ft (6 m) of a power line that is up to 350 kV or within 50 ft (15 m) of a power line that is over 350 kV is PROHIBITED, except for work covered in OSHA 29CFR1926 subpart V.

For operation outside the United States, the requirements of the applicable national, state and local regulations and safety codes must be met. This may include, in addition to the above:

- Automatic brakes such that when the equipment operating controls are released, the motions are brought to rest.



- A holding device (such as a load hold check valve) shall be provided in the hydraulic or pneumatic systems to prevent uncontrolled movement of the hoisting equipment in the case of a system failure.

Manitowoc offers upgrade packages for friction controlled models to install anti-two block, dead man control, and automatic hoist system control requirements to satisfy other codes and standards.

Manitowoc recommends that cranes be properly maintained, regularly inspected and repaired as necessary. All safety decals must be in place and legible. We also urge Manitowoc crane owners to upgrade their cranes with rated capacity indicator/limiter systems for all lifting operations.

Should you have any questions about this subject or other product safety matters relating to the operation and use of a Manitowoc crane, please contact Manitowoc Crane Care or the Product Safety and Reliability Manager at the following address:

**Manitowoc Cranes**  
2401 So. 30th St.  
Manitowoc, WI 54220

Phone: 1-888-499-7278 or  
920-683-6390

## PEDESTAL/BARGE MOUNTED CRANES

### WARNING

Crane owner/user must verify that method used to fasten or restrain crane to foundation, barge, ship or floating platform is strong enough, under all operating conditions, to prevent crane from breaking off foundation or moving on barge.

Manitowoc does not permit use of a truck crane on a barge, ship or floating platform.

### Pedestal Mounted Crane

Also see ASME publication B30.8-2004, Floating Cranes and Derricks.

### WARNING

#### Overload Hazard!

A pedestal mounted crane will not tip to indicate to operator that crane's capacity has been exceeded. When capacity of a pedestal mounted crane is exceeded, turntable bearing, hook rollers (if equipped), or other structural components may break, before load lines fail, causing crane to separate from pedestal.

For this reason, great care must be taken to operate a pedestal mounted crane within its rated capacity.

Careful planning is required before a crane can be operated on a barge. Crane user shall verify that barge is capable of limiting crane list and/or dynamics to maximum allowable specified on capacity charts. If specified crane list and/or dynamic conditions are exceeded, crane's capacity may be exceeded; therefore, turntable bearing, hook rollers (if equipped), or other structural components may break, causing crane to separate from pedestal.

#### Definition

A pedestal mounted crane is a crane which is securely fastened to a foundation, barge, ship or floating platform so the crane is restrained from tipping.

#### Examples

1. Crane upperworks mounted on a turret (or tub) which is securely fastened to foundation (Figure 2-7).





FIGURE 2-7

2. Crane upperworks mounted on a carbody (crawlers removed) which is securely fastened to foundation (Figure 2-8).



## Barge Mounted Crane


### Definition

A barge mounted crane is a crane that is anchored or restrained in a work area of the barge, ship or floating platform and is subjected to tipping forces.


### Examples

**NOTE:** The foundation is the deck of the barge, ship or floating platform.

1. Crawler-mounted crane with carbody anchored with tie-downs to foundation (Figure 2-9).



2. Crawler-mounted crane working on timbered area of barge, ship or floating platform with crawlers restrained by curbing and end stops (Figure 2-10). When not working, crane carbody is anchored with tie-downs to foundation. **Traveling with load is not permitted.**



3. RINGER® (crawler mounted, carbody mounted) supported on blocking, screw jacks or steel pedestals which are braced and fastened to foundation in such a manner as to prevent movement (Figure 2-11).
4. RINGER (platform mounted) which has ring braced and fastened directly to foundation in such a manner as to prevent movement.




FIGURE 2-11

AXIS		TRANSITIONAL		ROTATIONAL	
SYMBOL	NAME	STATIC	DYNAMIC	STATIC	DYNAMIC
X	Longitudinal		Surge	Heel List	Roll
Y	Vertical		Heave		Yaw
Z	Lateral		Sway	Trim	Pitch

FIGURE 2-12

## Capacity Charts

Manitowoc provides two types of capacity charts for a crane mounted on a barge or other supporting structure under static conditions.

1. A capacity chart based on tipping when crane is anchored only to prevent shifting.
2. A capacity chart based on structural competence when crane is securely fastened for use as a pedestal mounted crane.

**NOTE:** Unless otherwise specified on a machine list capacity chart, a "0" degree machine list capacity chart rating applies to machine list **not to exceed 1/2 degree**. All other machine list ratings – 1°, 2°, and 3° – must NOT be exceeded.

## Shock Loading

### Definition

Shock loads to the crane can be experienced when the barge is subjected to up and down movement of wave action (referred to as DYNAMICS). Figure 2-12 illustrates the dynamic conditions of the barge which influence crane capacity.

## CAUTION

### Structural Damage Hazard!

If crane boom or structure is shock loaded during operation, or there is any indication of shock loading, all structural components of crane shall be inspected to detect cracks and other damage. Nondestructive test equipment, such as magnetic particle or ultrasonic procedures, is recommended for this inspection.

**NOTE:** Manitowoc does not allow crane operation under dynamic conditions.

## Operation On Barge

### General

Machine list and/or dynamics will be experienced when a crane is operated on a barge, ship or floating platform. Both of these conditions reduce the crane's capacity, and each must be taken into account for safe operation on a barge, ship or floating platform.



### WARNING

#### Tipping Crane Hazard!

Tie-downs which only prevent crane from shifting as in barge, ship or floating platform mounting, may not provide adequate support when using a capacity chart for pedestal mounting. Before operating a crane on a barge, ship or floating platform, crane user shall verify that correct capacity chart is being used — pedestal mounted, barge mounted, 0°, 1°, 2° or 3° list or dynamic capacity chart.

Failing to use correct capacity chart can result in an accident.

### Definitions

1. **Machine List**, as defined by Manitowoc, is crane's out-of-level condition — from side-to-side — as measured by angle between horizontal and a line drawn through centerline of crane's boom hinge pins (Figure 2-13). This out-of-level condition creates side load and effects crane's lifting capacity.
2. **Barge List** (also referred to as heel or trim) causes swing out of the load and may produce side load. When Manitowoc provides a capacity chart showing capacities for a 2 degree machine list for example, we are referring to maximum allowable lifting capacity for crane when experiencing an out-of-level condition (side-to-side) of 2 degrees as measured by angle between horizontal and a line drawn through centerline of crane's boom hinge pins.  
  
Unless otherwise specified on capacity chart, barge list (heel or trim) must not exceed machine list degrees given on the capacity chart.
3. **Barge List and Machine List are not same.** As machine rotates on barge, barge list (as defined above) will change. Worst machine list condition generally occurs when machine swings over corner of barge, producing maximum side load.




FIGURE 2-13

## Crane Inspection

To aid in preventing harmful and damaging failure as previously indicated, regular inspection for signs of overloading in the following load bearing components is required. Correct each defect found before placing the crane into service.

- Boom
- Gantry
- Backhitch
- Rotating Frame
- Wire Rope
- Pendants and Straps
- Turntable Bearing

When equipped with hook rollers, it is recommended that each hook roller assembly be inspected daily for any sign of overloading, to include:

- Deformation of roller path.
- Proper hook roller adjustment.
- Deformation or cracks in hook roller hanger.
- Bent hook roller shaft.
- Damaged bearings.

## Transporting Crane on Barge

If it is necessary to transport the crane on a barge, ship or floating platform when dynamic conditions will be experienced, the boom shall be lowered onto a cradle (or other support) and the boom, crane upperworks and lowerworks shall be secured against movement. If the crane is equipped with a mast, the mast shall be securely tied down with guylines. Failing to take these steps can result in shock load or side load damage to the boom and mast.

## SAFETY AND INFORMATION SIGNS

### Maintaining Signs

The crane owner/user shall make sure that all signs are legible and installed at the proper locations on the crane. If a sign has been defaced or removed, it must be replaced immediately. See Nameplates and Decals Drawing in this section for the installation locations of signs.

### Ordering Signs


Order replacement signs from your local Manitowoc distributor or from the factory at the following address:

#### Manitowoc Crane Care

2401 So. 30th St.  
Manitowoc, WI 54220

Phone: 888-499-7278  
Fax: 920-683-6278  
E-mail: latticeteam@manitowoc.com

When ordering a sign, give the crane model number, the serial number, and the name and part number of the sign (Figure 2-14). If the sign has a figure number, it can be used if the drawing number is missing.





## SECTION 3

### OPERATING CONTROLS AND PROCEDURES

#### TABLE OF CONTENTS

Standard Hand Signals for Controlling Crane Operations . . . . .	3-1
Symbol Identification . . . . .	3-3
Front Window Operation . . . . .	3-8
Closing Window . . . . .	3-8
Opening Window For Ventilation . . . . .	3-8
Opening Window For Emergency Exit . . . . .	3-8
Operating Controls. . . . .	3-8
General . . . . .	3-8
Cab Door Damper Adjustment. . . . .	3-9
Closing Cab Door . . . . .	3-9
Damper Adjustment . . . . .	3-9
Controls Identification And Function . . . . .	3-11
A – Engine Controls . . . . .	3-11
A1. Engine Ignition Switch . . . . .	3-11
A2. Engine Emergency Stop Switch . . . . .	3-11
A3. Engine Hand Throttle . . . . .	3-11
A4. Engine Foot Throttle . . . . .	3-11
A5. Engine Clutch Lever . . . . .	3-11
A6. Battery Disconnect Switch . . . . .	3-11
B – Accessory Controls. . . . .	3-12
B1. Crane Work or Drum Lights Switch . . . . .	3-12
B2. Overhead Windshield Wiper Switch . . . . .	3-12
B3. Front Windshield Wiper-Washer Switch . . . . .	3-12
B4. Climate Control . . . . .	3-13
B5. Radio/CD Player (optional) . . . . .	3-13
B6. Cab Tilt Switch . . . . .	3-13
B7. Panel Lights Switch . . . . .	3-13
B8. Dome Light Switch . . . . .	3-13
B9. Horn Switches . . . . .	3-13
B10. Cigarette Lighter . . . . .	3-13
B11. 12 Volt Power Supply Receptacle . . . . .	3-13
B12. Machinery Heaters . . . . .	3-13
B13. Tinted Visor and Shade . . . . .	3-14
B14. Air Ventilation Knob . . . . .	3-14
B15. Fire Extinguisher . . . . .	3-15
B16. Cab Door Brake . . . . .	3-15
C – Indicators . . . . .	3-15
C1. Boom Angle Indicator . . . . .	3-15
C2. RCL Alarm (optional) . . . . .	3-15
C3. Rear View Mirrors . . . . .	3-15
C4. Bubble Level . . . . .	3-15
C5. Wind Speed Transmitter . . . . .	3-15
C6. Fuel Level . . . . .	3-16
C7. Engine Coolant Temperature . . . . .	3-16
C8. Engine Oil Pressure . . . . .	3-16
C9. Battery Voltage . . . . .	3-16
C10. Drum Rotation Indicators . . . . .	3-16
D – Special Controls . . . . .	3-16
D1. RCL Display and Indicator Lights . . . . .	3-16
D2. Main Display . . . . .	3-16
D3. Limit Bypass Switch . . . . .	3-17

D4. Luffing Jib Limit Bypass Switch . . . . .	3-17
E – Boom/Mast Hoist Controls. . . . .	3-19
E1. Drum 4 (Boom/Mast Hoist) Park Switch . . . . .	3-19
F2. Drum 5 (Boom Hoist) Park Switch . . . . .	3-19
E3. Drum 4 or 5 (Boom/Mast Hoist) Handle . . . . .	3-19
E4. Drum Indicator . . . . .	3-19
F – Load Drum Controls . . . . .	3-19
F1. Drum 1 Park Switch . . . . .	3-19
F2. Drum 2 Park Switch . . . . .	3-19
F3. Drum 3 Park Switch . . . . .	3-19
F4. Drum 1 Handle . . . . .	3-19
F5. Drum 2 Handle . . . . .	3-19
F6. Drum 3 Handle . . . . .	3-19
F7. Drum Indicator . . . . .	3-19
G – Swing Controls . . . . .	3-20
G1. Swing Park Switch . . . . .	3-20
G2. Swing Handle . . . . .	3-20
G3. Swing Holding Brake Switch . . . . .	3-20
H – Travel Controls . . . . .	3-21
H1. Travel Park Switch . . . . .	3-21
H2. Travel Speed Selector . . . . .	3-21
H3. Travel Cruise Selector . . . . .	3-21
H4. Left Crawler Handle . . . . .	3-21
H5. Right Crawler Handle . . . . .	3-21
J – Winch Controls. . . . .	3-21
Rigging Winch Mode . . . . .	3-21
Limit Devices . . . . .	3-22
1. Boom Up Limit . . . . .	3-22
3. Block-Up Limit . . . . .	3-22
4. Luffing Jib Up Limit . . . . .	3-22
5. Luffing Jib Down Limit . . . . .	3-22
7. Minimum Bail Limit. . . . .	3-23
Seat Controls . . . . .	3-25
Preparing Crane for Operation . . . . .	3-26
Operation . . . . .	3-26
Engine Startup . . . . .	3-26
Boom/Mast Hoist Operation. . . . .	3-28
Luffing Hoist Operation . . . . .	3-29
Swing Operation . . . . .	3-29
Load Drum Operation . . . . .	3-30
Travel Operation . . . . .	3-31
Stopping Engine/ Leaving Crane Unattended . . . . .	3-33
Remote Controls. . . . .	3-34
General . . . . .	3-34
Crane Setup Remote Controls. . . . .	3-34
1–Power Switch . . . . .	3-35
2–Stop Switch . . . . .	3-35
3–Left Front Jacking Toggle Switch . . . . .	3-35
4–Right Front Jacking Toggle Switch . . . . .	3-35
5–Left Rear Jacking Toggle Switch . . . . .	3-35
6–Right Rear Jacking Toggle Switch . . . . .	3-35
7–All Jacking Toggle Switch . . . . .	3-35
8–Boom Pins Switch . . . . .	3-36
9–Front Rotating Bed Pins Switch . . . . .	3-36
10–Rear Rotating Bed Pins Switch . . . . .	3-36
11–Counterweight Pins Switch . . . . .	3-36
12–Engine Speed Switch . . . . .	3-36



13–Mast Switch . . . . .	3-36
Carbody Manual Remote Controls . . . . .	3-36
14–Right Crawler Pin Handle . . . . .	3-36
15–Left Crawler Pin Handle . . . . .	3-36
16–Right Front Carbody Jack Handle . . . . .	3-37
17–Right Rear Carbody Jack Handle . . . . .	3-37
18–Left Rear Carbody Jack Handle . . . . .	3-37
19–Left Front Carbody Jack Handle . . . . .	3-37
20–Carbody Level . . . . .	3-37
Replacing Wireless Remote Batteries . . . . .	3-37
Displays . . . . .	3-38
Display Controls . . . . .	3-38
1 – RCL Display . . . . .	3-38
2 – Main Display . . . . .	3-38
3 – Display Touchpad Controls . . . . .	3-38
4 – Display Select Buttons . . . . .	3-38
5 – Select Buttons . . . . .	3-38
6 – Enter/Exit Buttons . . . . .	3-38
7 – Confirm Button . . . . .	3-38
Display Brightness and Color Contrast . . . . .	3-38
Factory Default Display Settings . . . . .	3-38
Blank Display . . . . .	3-38
Main GUI Display Format . . . . .	3-38
Screen Prompts . . . . .	3-39
Menu Screen . . . . .	3-39
Information Screen . . . . .	3-40
Crane Level . . . . .	3-40
Boom to Luffing Jib Working Angle . . . . .	3-40
Wind Speed Indicator . . . . .	3-40
Mast Angle . . . . .	3-40
Hydraulic Tank . . . . .	3-40
Battery . . . . .	3-40
Pump Drive . . . . .	3-40
Engine . . . . .	3-40
MAX-ER (Optional) . . . . .	3-41
Faults . . . . .	3-41
Diagnostic Screen . . . . .	3-43
Diagnostic Screen Component Icons . . . . .	3-43
Swing Diagnostic Screen . . . . .	3-46
Travel Diagnostic Screen . . . . .	3-46
Jacking Accessory Diagnostic Screen . . . . .	3-47
Pins and Fan Accessory Diagnostic Screen . . . . .	3-47
Cab Tilt, Rigging Winch, and Mast Accessory Diagnostic Screen . . . . .	3-48
MAX-ER Diagnostic Screen . . . . .	3-48
Function Mode Screens . . . . .	3-48
Drum Functions . . . . .	3-48
Swing Functions . . . . .	3-49
Travel Functions . . . . .	3-49
Setup Remote Functions . . . . .	3-49
MAX-ER Functions . . . . .	3-49
Drum, Swing or Track Speed Limits . . . . .	3-49
Swing Pressure Limit . . . . .	3-49
Rigging Winch Mode . . . . .	3-49
Boom or Swing Motion Limiter Mode . . . . .	3-50
Setup Remote Control Mode . . . . .	3-50
CAN Bus Screen . . . . .	3-50
Packet Information . . . . .	3-50











Digital Output Disable Fault . . . . .	3-51
Engine Node Status . . . . .	3-51
Crane Status . . . . .	3-51
Load Link Status . . . . .	3-51
Wireless Receiver Status . . . . .	3-51
Boom Node Status . . . . .	3-51
Digital Output Reference Chart . . . . .	3-54
Digital Input Reference Chart . . . . .	3-55
Camera Screen (Optional). . . . .	3-58
Pressure Test and Calibration Screen. . . . .	3-58
Pressure Sender Test . . . . .	3-58
Control Calibration . . . . .	3-59
High Pressure Test . . . . .	3-60
Charge Pressure Test . . . . .	3-61
Wind Conditions . . . . .	3-62
Preparation for Cold Weather. . . . .	3-64
Crane Limitations. . . . .	3-64
Wire Rope . . . . .	3-64
Cold Weather Starting Aid . . . . .	3-64
Coolant and Oil Pan Heaters . . . . .	3-64
Cooling System . . . . .	3-64
Battery . . . . .	3-64
Engine Oil . . . . .	3-64
Fuel Oil . . . . .	3-64
Gear Oil . . . . .	3-64
Hydraulic Cranes . . . . .	3-64
Hydraulic Oil . . . . .	3-65
General . . . . .	3-65
Cold Weather Heater Package. . . . .	3-65
General . . . . .	3-65
Heaters . . . . .	3-65
Turning Heaters On . . . . .	3-65
Turning Heaters Off . . . . .	3-65
Circuit Breakers . . . . .	3-65

## SECTION 33





### OPERATING CONTROLS AND PROCEDURES







#### STANDARD HAND SIGNALS FOR CONTROLLING CRANE OPERATIONS

The following standard hand signals comply with ASME B30.5-2007

 <p><b>HOIST.</b> With forearm vertical, forefinger pointing up, move hand in small horizontal circle.</p>	 <p><b>LOWER.</b> With arm extended downward, forefinger pointing down, move hand in small horizontal circles.</p>	 <p><b>USE MAIN HOIST.</b> Tap fist on head; then use regular signals.</p>	 <p><b>USE WHIPLINE</b> (Auxiliary Hoist). Tap elbow with one hand; then use regular signals.</p>
 <p><b>RAISE BOOM.</b> Arm extended, finger closed, thumb pointing upward.</p>	 <p><b>LOWER BOOM.</b> Arm extended, fingers closed, thumb pointing downward.</p>	 <p><b>MOVE SLOWLY.</b> Use one hand to give any motion signal and place other hand motionless in front of hand giving the motion signal (hoist slowly shown as an example).</p>	
 <p><b>RAISE BOOM &amp; LOWER LOAD.</b> With arm extended, thumb pointing up, flex fingers in and out as long as load movement is desired.</p>	 <p><b>LOWER BOOM &amp; RAISE LOAD.</b> With arm extended, thumb pointing down, flex fingers in and out as long as load movement is desired.</p>	 <p><b>SWING.</b> Arm extended point with finger in direction of swing of boom.</p>	

da0108

 <p><b>STOP.</b> Arm extended, palm down, move arm back and forth horizontally.</p>	 <p><b>EMERGENCY STOP.</b> Both arms extended, palms down, move arms back and forth horizontally.</p>	 <p><b>TRAVEL.</b> Arm extended forward, hand open and slightly raised, make pushing motion in direction of travel.</p>	 <p><b>DOG EVERYTHING.</b> Clasp hand in front of body.</p>
--	--	---	--

 <p><b>TRAVEL (Both Tracks).</b> Use both fists in front of body, making a circular motion about each other, indicating direction of travel; forward or backward. (For Land Cranes Only).</p>	 <p><b>TRAVEL (One Track).</b> Lock the track on side indicated by raised fist. Travel opposite track in direction indicated by circular motion of other fist, rotated vertically in front of body. (For Land Cranes Only).</p>	 <p><b>EXTEND BOOM (Telescoping Booms).</b> Both fists in front of body with thumbs pointing outward.</p>
 <p><b>RETRACT BOOM (Telescoping Boom).</b> Both fists in front of body with thumbs pointing toward each other.</p>	 <p><b>EXTEND BOOM (Telescoping Boom).</b> One Hand Signal. One fist in front of chest with thumb tapping chest.</p>	 <p><b>RETRACT BOOM (Telescoping Boom).</b> One hand signal. One fist in front of chest, thumb pointing outward and heel of fist tapping chest.</p>

da0109

SYMBOL IDENTIFICATION

The following symbols are used on the control consoles to identify the operating controls and their operation.

Air Circulation – Cab		Cylinders – Live Mast	
Air Circulation – Outside		Data, Enter	
Alert, Safety		Data, Save Entered	
Cab Tilt		Drum	
Cylinders, Live Mast – Extend or Retract		Drum – Lower (Load, Boom, Luffing Jib, or Mast) (depends on drum use.)	
Cylinders, Jacking – Extend or Retract		Drum – Raise (Load, Boom, Luffing Jib, or Mast) (depends on drum use.)	
Cylinders, Jacking – Location	<div>Left Front </div> <div>Right Front </div> <div>Left Rear </div> <div>Right Rear </div> <div>All </div>	Drum Free Fall (with drum number)	
		Drum Number (identifies drum is in use)	

FIGURE 3-1

















Energize (turn on)		Engine Temperature	
Engine		Heater/Defroster	
Engine, Battery Voltage		Horn	
Engine, Fuel		Light, Panel	
Engine Pressure		Light, Dome	
Engine Run		Lighter	
Engine Start		Limit Bypass	
Engine Stop		Limit Bypass, Luffing Jib	

FIGURE 3-1 continued

















On/Start and Off/Stop		Pins – Main Mast	
Off/Stop		Pins – Rotating Bed Front	
On/Start		Pins – Rotating Bed Rear	
Park Off		Scroll (up, down, and side-ways)	
Park On		Setup Mode	
Pins – Disengage		Speed, Fast	
Pins – Engage		Speed, Slow	
Pins – Boom Hinge		Stop (emergency)	

FIGURE 3-1 continued









































Swing		Travel Direction Reverse – Right Crawler	
Swing Left	 OR 	Travel Speed	
Swing Right	 OR 	Winch, Rigging	
Travel		Winch, Rigging– Haul In Rope	
Travel Cruise		Winch, Rigging – Pay Out Rope	
Travel Direction Forward – Left Crawler		Windshield Wiper	
Travel Direction Forward – Right Crawler		Windshield Wiper – Overhead with Washer	
Travel Direction Reverse – Left Crawler		Windshield Wiper – Front with Washer	

FIGURE 3-1 continued



Cylinder	Extend		Pin, Hinge (telescopic beam)		
	Retract				
Cylinder, Counterweight Lifting			Energize (turn on)		
Cylinder, Telescopic Beam			Set-Up (remote)		
Engine			Speed:		
Jack:	Extend		Fast		
	Retract		Slow		
Jack (location):	Left Front		Wheels, Right		
	Left Rear				
	Right Front		Wheels, Left		
	Right Rear				
	All				
Pin:	Extend		Wheels, Rotate:		
	Retract				
			Clockwise		

M3-2

FIGURE 3-2

## FRONT WINDOW OPERATION

### Closing Window

Rotate window handle DOWN to position shown in Figure 3-3, View A.

### Opening Window For Ventilation

Rotate window handle UP to position shown in Figure 3-3, View B. Window can be swung open approximately 3 in (76 mm) for ventilation.

### Opening Window For Emergency Exit

Pull out both quick-release pins at handle. Remove both knobs at top of window (Figure 3-3, View C). Push window out to allow emergency exit from cab.

## OPERATING CONTROLS

### General

The purpose of the following instructions is to familiarize qualified operators with the location and function of the operating controls for this crane. This section also contains safety information and a description of operation for each crane function.


Depending on the options your crane is equipped with, some controls identified in this section will not apply.



### WARNING

**To prevent death or serious personal injury:**

- Read and thoroughly understand instructions in this section, in Section 2, and in Capacity Chart Manual.
- Contact your Manitowoc distributor for assistance if you do not clearly understand any operating procedure.



P1751

View A



P1750

View B



P1752

View C

(2 places at top of window)

FIGURE 3-3

CAB DOOR DAMPER ADJUSTMENT

See Figure 3-4 for following procedure.


The cab door damper prevents the cab door from slamming open or closed. This is especially critical when the cab is tilted at an angle other than horizontal.

Closing Cab Door

- To properly close the cab door:
1. Slide cab door to closed position, **but don't latch it**. This releases hydraulic pressure in damper.
  2. Open cab door approximately 8.66 in (22 cm).
  3. Slide cab door fully closed and latch.

Damper Adjustment

1. Adjust cab tilt to level position.
2. Remove pin.
3. Swing damper with rod end away from cab door.
4. **Pull piston rod out to fully extended position.**
  - a. While pulling on rod, turn it **clockwise** (looking at rod end) approximately four full turns until it stops. This is **maximum** damper pressure setting.
  - b. While pulling on rod, turn it **counterclockwise** (looking at rod end) approximately four full turns from maximum to **minimum** damper pressure setting. **This is pressure setting that is recommended.**
5. Reconnect rod end to cab door.
6. It may take several trial and error adjustments to obtain desired damping.



A02019  
A09260  
A1297




FIGURE 3-5

## CONTROLS IDENTIFICATION AND FUNCTION



### WARNING

#### Unauthorized Startup!

Always STOP engine and remove key before leaving crane unattended. This practice will prevent unauthorized personnel from operating crane.

## A – Engine Controls

See Figure 3-5 for engine controls.

### A1. Engine Ignition Switch

Insert key.

Turn CLOCKWISE to RUN position to activate the crane's electric circuits.

Turn fully CLOCKWISE to START engine. **RELEASE to RUN position as soon as engine starts.**

Rotate COUNTERCLOCKWISE to STOP engine and turn off crane's electric system.

**NOTE** Engine diagnostic faults appear on the engine screen (see Main display in this section) when the ignition with is in the run position. The faults must go away when the engine is started. See engine manufacturer's operating instructions manual for engine diagnostic information.

### A2. Engine Emergency Stop Switch

Push knob DOWN to STOP engine only in an emergency — for example, if a crane function does not stop when control handle is released to off (center position) or any other uncontrolled motion of a crane function is observed.

**Beware** — when knob is pushed down, engine stops, brakes apply, and any **functions being operated come to an abrupt stop.**

**NOTE** The knob must be pulled up before the engine can be restarted.

If the emergency stop switch has been activated, test all disk brakes for proper operation before putting the crane back in service. See Section 2 of Service Manual for procedure.

Use engine ignition switch (A1) to stop engine for normal operating conditions.

### A3. Engine Hand Throttle

Pull handle BACK to INCREASE engine speed.

Push handle FORWARD to DECREASE engine speed.

**NOTE:** The selected engine speed is maintained when the handle is released.

Speed of the crane functions depends on engine speed and on how far the control handles are moved in either direction from off.

Engine speed must be fast enough to provide sufficient power for the work being done. **Engine can stall under load if engine speed is too slow.**

### A4. Engine Foot Throttle

PRESS foot throttle to INCREASE engine speed above the hand throttle setting.

RELEASE foot throttle to DECREASE engine speed to idle or to the hand throttle setting.

### A5. Engine Clutch Lever

Pull clutch lever OUT and push DOWN to ENGAGE the clutch.

Pull clutch lever UP and push IN to DISENGAGE the clutch.

### A6. Battery Disconnect Switch

Turn handle CLOCKWISE to CONNECT battery circuit.

Turn handle COUNTERCLOCKWISE to DISCONNECT battery circuit for following reasons:

- When servicing crane's electrical control system.
- If desired, to prevent batteries from discharging when the crane is stored for extended periods of time.
- If desired, to prevent crane from being started by unauthorized personnel.

## CAUTION

### Engine Damage!

To avoid possible engine fault codes and undesirable operation, make sure engine ignition switch has been off two minutes before disconnecting batteries.

Do not rely on this switch to protect crane's electronic systems when welding. Disconnect battery cables at batteries before welding.




FIGURE 3-6

## B – Accessory Controls

See Figure 3-6 for accessory controls.

### B1. Crane Work or Drum Lights Switch

This switch controls four optional lights mounted on crane cab, rotating bed, and boom butt.

Press TOP of rocker to TURN ON lights.

Press BOTTOM of rocker to TURN OFF lights.

### B2. Overhead Windshield Wiper Switch

### B3. Front Windshield Wiper-Washer Switch

PAST PRODUCTION:

- Counterclockwise — OFF.

- Clockwise — INTERMITTENT depending how far knob is turned:
- Clockwise (1st detent) — LOW speed.
- Clockwise (2nd detent) — HIGH speed.
- PRESS front windshield wiper switch to SPRAY washer fluid onto front window.

CURRENT PRODUCTION:

- Toggle fully down — OFF.
- Toggle up — INTERMITTENT depending how far toggle is moved:
- Toggle fully up — HIGH speed.
- PRESS top end of front windshield wiper switch to SPRAY washer fluid onto front window.

**NOTE:** The windshield washer tank is mounted at rear of cab support. Fill the tank with a quality brand washing solution that **will not freeze during cold weather.**

#### **B4. Climate Control**

Provides cab temperature control from 55 to 95°F (13 to 35°C).

- A.** ON - Depress to turn on climate control system. The LED will illuminate and display the current temperature setting.
- B.** OFF - Depress to turn off climate control system.
- C.** AUTO - Depress to places system in fully automatic temperature control mode, to include fan speed. The system will adjust blower fan speed to the lowest setting necessary to maintain the selected cab temperature. A panel indicator light illuminates when this mode is on.
- D.** DEF (defrost) - Depress to energize the A/C system to allow for rapid de-humidification of cab. A panel indicator light illuminates when this mode is on.
- E.** FAN UP/DOWN - Overrides AUTO mode. Depress to increment fan speed up or down in 11 steps. The LED indicates the setting as a percent between HI and LO. The selected fan speed is maintained until changed or the AUTO mode is turned on.
- F.** TEMPERATURE UP/DOWN - Depress to raises or lower the temperature setting. The system maintains the cab temperature as close as possible to the selected temperature.
- G.** LED.
- H.** FAULT CODES - To display fault codes, press ON button three times. Any active fault codes are shown on the LED. Displayed fault codes are:
  - E00 — No Faults
  - E01 — Cab Sensor Shorted
  - E02 — Cab Sensor Open
  - E03 — Evaporator Probe Shorted
  - E04 — Evaporator Probe Open
  - E09 — Water Valve Shorted
  - E10 — Water Valve Open

To change the display temperature from Fahrenheit to Celsius or back, depress TEMPERATURE UP/DOWN buttons simultaneously.

#### **B5. Radio/CD Player (optional)**

See manufacturer's instructions.

#### **B6. Cab Tilt Switch**

PRESS and hold TOP of rocker to RAISE front of cab.

CENTER rocker to LOCK cab in position.

PRESS and hold BOTTOM of rocker to LOWER front of cab.



#### **WARNING** **Moving Cab Hazard!**

Warn personnel to stand clear of operator's cab while tilting.

- Personnel can lose balance and fall.
- Personnel can be crushed between cab and railing.

#### **B7. Panel Lights Switch**

Press TOP of rocker to TURN ON panel lights.

Press BOTTOM of rocker to TURN OFF panel lights.

#### **B8. Dome Light Switch**

Press TOP of rocker to TURN ON dome light.

Press BOTTOM of rocker to TURN OFF dome light.

#### **B9. Horn Switches**

Two horn switches are provided: one on the right console and one on the cab floor. Use either horn **when necessary to warn or signal personnel while crane is being operated or serviced.**

On right console, PRESS and hold bottom of rocker to turn ON horn.

RELEASE rocker to turn OFF horn.

On cab floor, PRESS and hold down switch with right foot to turn horn ON.

RELEASE foot from switch to turn horn OFF.

#### **B10. Cigarette Lighter**


#### **B11. 12 Volt Power Supply Receptacle**

Provided for operation and charging a 12 volt cell phone or other appliance.

#### **B12. Machinery Heaters**

The hydraulic tank can be equipped with two thermostatically controlled heaters (120 or 240 volt) designed to keep the oil temperature 30°F (17°C) warmer than the ambient temperature.

To aid engine startup in cold weather, plug in the heaters at shutdown; unplug the heaters at startup.



See Figure 3-7 for following accessory controls.

### **B13. Tinted Visor and Shade**

A visor is provided for the front window and shades are provided for the roof and side windows. Position the visor and shades as desired to shade sunlight.

### **B14. Air Ventilation Knob**

Pull knob OUT to circulate outside air in the cab.

Push knob IN to close outside air and circulate the existing air in the cab.



**B15. Fire Extinguisher**

One fire extinguisher is in operator's cab behind seat. Foreign code requires another fire extinguisher be mounted on the crane.

**B16. Cab Door Brake**

Manual handle for locking cab door in any position. Push handle down to apply and pull up to release.

**C – Indicators**

See Figure 3-7 for indicators.

**C1. Boom Angle Indicator**


Shows the angle of the boom in degrees above horizontal. The boom, luffing jib, and mast angles can be viewed on RCL display or Main display.

See Figure 3-8 for identification of the various boom and luffing jib angles.

**WARNING****Overload Hazard!**

Use boom angle indicator only as a guide to position boom near angle corresponding to radius for given load.

In all cases, radius shall govern capacity. Exceeding radius given in capacity chart can result in tipping or structural damage.

**FIGURE 3-8****C2. RCL Alarm (optional)**

The amber beacon rotates and the alarm sounds whenever the crane's capacity is near an overload condition (when RCL system is ON).

**C3. Rear View Mirrors**

Adjustable rear view mirrors on operator's cab and right side of rotating bed allow the operator to view the rear of crane. Mirrors can be rotated inward for shipping.

**C4. Bubble Level**

On past production cranes with upperworks jacking (S/N 16001032 and older), a bubble level is mounted on the cab support.


On current production cranes (S/N 16001118 and newer), a bubble level is mounted on the front of the carbody.

The bubble level indicates crane levelness from front to rear and from side to side as shown in Figure 3-9.

Crane levelness can also be viewed in the Information Screen of the main display.

**WARNING****Tipping Hazard!**

Unless otherwise specified on capacity chart, all crane operations must be performed with crane **level** to within one percent of grade in all directions – 1 ft in 100 ft (0,3 m in 30 m); otherwise, crane could tip.

**FIGURE 3-9****C5. Wind Speed Transmitter**

Wind speed at the boom and jib points appears in the wind speed screen (see Main display later in this section).




FIGURE 3-10

See Figure 3-7 for following indicators.

#### **C6. Fuel Level**

Indicates amount of fuel remaining in fuel tank.

#### **C7. Engine Coolant Temperature**

See engine manual for operating specifications.

#### **C8. Engine Oil Pressure**

See engine manual for operating specifications.

#### **C9. Battery Voltage**

Indicates condition of battery charging system.

#### **C10. Drum Rotation Indicators**

Pin-type actuators located under all drum handle covers. They move UP and DOWN to signal the operator, by feel,

that the corresponding drum is turning. Indicator movement corresponds to drum speed.

### **D – Special Controls**

See Figure 3-10 for special controls.

#### **D1. RCL Display and Indicator Lights**

Displays load lifting information and alerts the operator to overload conditions. See separate Rated Capacity Indicator/Limiter Operation manual for detailed instructions.

#### **D2. Main Display**

Displays operating conditions, faults, and diagnostic information. See Main Display topic in this section for detailed instructions.

**D3. Limit Bypass Switch****WARNING**

When bypassing a limit, carefully follow instructions under Limit Devices topic in this section.

This switch bypasses the limits identified in .

Insert key. Turn CLOCKWISE and hold to BYPASS (deactivate) reached operating limits. This position allows the functions to be operated beyond the limits.

RELEASE to ACTIVATE operating limits. This position allows the limits to stop the functions in the normal manner.

Remove key to prevent unauthorized operation.

**D4. Luffing Jib Limit Bypass Switch**

This switch bypasses the limits identified in . Insert Key. Turn CLOCKWISE to BYPASS corresponding limits. This position allows functions to be operated beyond the limits.

Turn COUNTERCLOCKWISE to ACTIVATE corresponding limits. This position allows limits to stop functions in the normal manner. **Key must be in this position for all normal operation. Otherwise, structural damage can occur.**

Remove key to prevent unauthorized operation.

**D5. Seat Switch**

Prevents crane from being operated until operator is seated.

When operator is not seated, all control handles are inoperable, all brakes are applied, and travel cruise is turned off.

**Table 3-1** Bypassable Limit Identification

Limit	Limit Bypass Switch (momentary)	Luffing Jib Limit Bypass Switch <sup>1</sup> (maintained)
Boom Up	Yes or No <sup>2</sup>	No
Boom Down (optional)	Yes	No
Block-Up (each drum)	Yes	Yes
Bail — Max and Min (each drum)	Yes	No
Luffing Jib Maximum UP 1	Yes	Yes
Luffing Jib Maximum UP 2	No	No
Luffing Jib Maximum Down 1	<sup>3</sup>	<sup>3</sup>
Luffing Jib Maximum Down 2	No	No
Rated Capacity Indicator/Limiter	Yes	Yes


<sup>1</sup> Use only for rigging.

<sup>2</sup> The boom up limit cannot be bypassed on current production cranes. To determine if the boom up limit can be bypassed on your crane, perform the test given on page 3-22 in this section.

<sup>3</sup> When you reach luffing jib maximum down limit, operation does not stop. Fault 50 alarm comes on. You can lower luffing jib an additional 3° to luffing jib maximum down 2 limit.

A02452

## DRUM AND HANDLE IDENTIFICATION



Handle Options (Note 1)	HANDLE A Controls Drum	HANDLE B Controls Drum	HANDLE C Controls Drum	HANDLE D Controls Drum
Standard	4 - Boom Hoist	1 - Load Hoist	2 - Load Hoist	3 - Load Hoist
Rigging Winch	0 - Rigging Winch	1 - Load Hoist	2 - Load Hoist	3 - Load Hoist
Luffing Jib (Note 2)	3 - Luffing Hoist	1 - Load Hoist	2 - Load Hoist	4 - Boom Hoist
MAX-ER Setup	4 - Mast Hoist	1 - Load Hoist	2 - Load Hoist	5 - Boom Hoist
MAX-ER (Note 3)	5 - Boom Hoist	1 - Load Hoist	2 - Load Hoist	3 - Load Hoist
MAX-ER w/Luffing Jib (Note 3)	3 - Luffing Hoist	1 - Load Hoist	2 - Load Hoist	5 - Boom Hoist

**NOTE 1:** Handle display lights show which drums are controlled by which handles.

**NOTE 2:** Load/Luffing hoist (drum 3) and right travel are both controlled by same pump. Only one system can be operated at a time.

**NOTE 3:** In MAX-ER configuration, boom hoist (drum 5) is operable and mast hoist (drum 4) is inoperable.




FIGURE 3-11

See Figure 3-11 for drum and handle identification.

## E – Boom/Mast Hoist Controls

The boom/mast hoist and swing are controlled by a dual-axis handle that allows both functions to be operated at the same time with one handle.

Boom/mast hoist has a spring-applied, hydraulically-released disc brake on one motor of the drum.

- Drum brake is released automatically when the handle is moved in either direction from off.
- Drum brake is applied automatically when handle is moved to off, engine is stopped (or power is lost for any reason), applicable operating limits are reached, applicable system faults occur, or selected park switch is turned on.

### E1. Drum 4 (Boom/Mast Hoist) Park Switch

#### F2. Drum 5 (Boom Hoist) Park Switch

Press TOP of rocker to TURN ON park switch. With park switch on, boom/mast hoist handle is inoperable, drum brake is applied, and drum pawl is engaged.

Press BOTTOM of rocker to TURN OFF park switch. With park switch off, boom/mast hoist handle is operable, drum brake is applied and released in conjunction with handle movement, and drum pawl is disengaged.

### E3. Drum 4 or 5 (Boom/Mast Hoist) Handle

Pull handle BACK to RAISE boom. Drum brake releases and speed increases in relation to handle movement.

Release handle to CENTER to STOP boom. Drum brake spring applies.

Push handle FORWARD to LOWER boom. The drum brake releases and speed increases in relation to handle movement.

**NOTE:** When the crane is configured with a luffing jib, boom/mast hoist handle D is the last load drum handle on right console. The luffing jib is then controlled with handle A.

### E4. Drum Indicator

Drum number appears to indicate that boom/mast hoist is active.

## F – Load Drum Controls

Each load drum has a spring-applied, hydraulically-released disc brake on motor at one end of drum.

For normal operation:

- Corresponding drum brake is released automatically when drum handle is moved in either direction from off.
- Corresponding drum brake is applied automatically when drum handle is moved to off.

**NOTE:** Drum brakes are applied automatically when engine is stopped (or power is lost for any reason), applicable operating limits are reached, applicable system faults occur, or drum park switch is turned on.

### F1. Drum 1 Park Switch

### F2. Drum 2 Park Switch

### F3. Drum 3 Park Switch

Press TOP of rocker to TURN ON corresponding drum park switch. With drum park switch on, drum handle is inoperable, drum brake is applied, and (if equipped) drum pawl is engaged.

Press BOTTOM of rocker to TURN OFF drum park switch. With drum park off, drum handle is operable, drum brake is applied and released in conjunction with handle movement, and (if equipped) drum pawl is disengaged.

### F4. Drum 1 Handle

### F5. Drum 2 Handle

### F6. Drum 3 Handle

The following description is for full-power operation.

Pull handle BACK to HOIST load. Drum brake releases and speed increases in relation to handle movement.

Release handle to CENTER to STOP load. Drum brake spring applies.

Push handle FORWARD to LOWER load. Drum brake releases and speed increases in relation to handle movement.

### F7. Drum Indicator

Indicates the number of the drum that the corresponding handle will control. Drum operation can vary depending on crane configuration. See Figure 3-11 for drum and handle identification.




FIGURE 3-11

## G – Swing Controls

See Figure 3-11 for swing controls.

Swing drive has a spring-applied, hydraulically-released disc brake and swing lock.

- Brake is released and the lock is disengaged during normal operation.
- Brake is applied automatically if power is lost, when swing holding brake switch is enabled, and when drum park switch is turned on.
- Swing lock is engaged only when drum park switch is turned on.

### G1. Swing Park Switch

Press TOP of rocker to TURN ON swing park switch. With park switch on, swing handle is inoperable, swing brake is applied, and swing lock is engaged.

Press BOTTOM of rocker to TURN OFF swing park switch. With park switch off, swing handle is operable, swing brake is released, and swing lock is disengaged.

### G2. Swing Handle

- Dual-axis handle allows the boom/mast hoist and swing to be operated at the same time with one handle.
- The swing alarm will beep to warn personnel when the rotating bed is swung.

Move handle to LEFT to SWING LEFT. Swing speed increases in relation to handle movement.

Release handle to CENTER to STOP. Swing speed decreases to off and rotating bed slows to a stop. Move handle in opposite swing direction to stop swing motion faster.

Press swing holding brake switch to hold the stopped rotating bed in position.

Move handle to RIGHT to SWING RIGHT. Swing speed increases in relation to handle movement.

### G3. Swing Holding Brake Switch

Use the swing holding brake switch (on side of handle) to hold the rotating bed in position for short periods of time during the operating cycle. The swing brake will apply and

the swing handle will be inoperable while the switch is pressed.

PRESS button to APPLY swing holding brake.

RELEASE button to RELEASE swing holding brake.

## CAUTION

### Swing Drive/Boom Damage!

Do not apply swing holding brake or turn on swing park switch while swinging; brake will bring rotating bed to an abrupt stop. This action could cause damage to boom from side loading or damage to swing drive from shock loading. Bring rotating bed to smooth stop with swing handle and then apply swing holding brake or turn on swing park switch.

## H – Travel Controls

See Figure 3-11 for travel controls.

The crawlers have spring-applied, hydraulically-released disc brakes.

- Both crawler brakes release when either crawler handle is moved in either direction from off.
- Both crawler brakes apply when both crawler handles are moved to off.
- Both crawler brakes apply to hold crane in position if power is lost for any reason.

### H1. Travel Park Switch

Press TOP of rocker to TURN ON travel park switch. With travel park switch on, travel handles are inoperable and brakes are applied.

Press BOTTOM of rocker to TURN OFF travel park switch. With travel park switch off, travel handles are operable and brakes are applied and released in conjunction with handle movement.

### H2. Travel Speed Selector

Press TOP of rocker to operate travel motors in HIGH speed. High speed operation provides the maximum available travel speed for traveling long distances.

Press BOTTOM end of rocker to operate travel motors in LOW speed. Low speed operation provides smoother starts and stops and more precise control of the travel motors than high speed.

In low speed, the travel motors operate at approximately 1/3 the speed of high speed.

**NOTE:** It is okay to change travel speed while traveling:

The travel motors will shift immediately from high to low when low speed is selected.

The travel motors will not shift from low to high when high speed is selected until:

- Engine speed is at high idle.
- Hydraulic pressure is low enough to allow the motors to shift from low to high speed.

### H3. Travel Cruise Selector

The travel cruise selector allows the crawlers to be operated in either direction at a selected speed without the operator's hand on the crawler handles.

Move both crawler handles in either direction from off to select desired speed and direction of travel. Press top of rocker to turn ON travel cruise. Release handles to off. Crawlers continue to travel at selected speed and direction.

Slightly move either crawler handle in the opposite direction or press bottom of rocker to turn OFF travel cruise.

### H4. Left Crawler Handle

### H5. Right Crawler Handle

The following directions of travel are with **front of rotating bed and front of carbody facing same direction**.

- Operator's cab is at front of rotating bed.
- Carbody and crawler control valve is at front of carbody. If front of rotating bed and front of carbody face in opposite directions, crane will travel in the direction opposite handle movement.

Push handle FORWARD to travel FORWARD. Brakes release and speed increases in relation to handle movement.

Release handle to CENTER to STOP traveling. Brakes spring apply.

Pull handle BACK travel in REVERSE. Brakes release and speed increases in relation to handle movement.

The swing/travel alarm beeps to warn personnel when the crane is traveled.

## J – Winch Controls

### Rigging Winch Mode

See Rigging Winch Operation in Section 4 of Operator's Manual.

## LIMIT DEVICES

See Table 3-1 to determine which limit bypass switch bypasses a given limit.

### 1. Boom Up Limit

Automatically stops the boom when it is raised to the following maximum angles:

#### PAST PRODUCTION

- 83° for boom with or without fixed jib (without luffing jib) when boom up limit **can be bypassed**.
- 87° for boom with luffing jib when boom up limit **can be bypassed**.

#### CURRENT PRODUCTION

- 84° for boom with or without fixed jib (without luffing jib) when boom up limit **cannot be bypassed**.
- 88° for boom with luffing jib when boom up limit **cannot be bypassed**.

The boom can be lowered after the limit is contacted.



### WARNING

#### Falling Boom/Jib Hazard!

If you bypass boom up limit for any reason, DO NOT allow physical boom stops to bottom out. Boom butt could be damaged, causing boom and jib to fall over backwards.

#### Crush Hazard!

Maintain constant communication between operator and assistant during following steps.

Stay clear of moving parts.

**LIMIT BYPASS TEST:** Perform the following test to determine if the boom up limit on your crane can be bypassed or not:

1. Lower the boom onto blocking at ground level.
2. Have an assistant push the boom stop rod in to trip the boom up limit switch open.
3. Rotate limit bypass key (D3) to the bypass position and hold.
4. Try to boom up SLOWLY — do not raise the boom any higher than necessary to perform the test:
  - a. If the boom rises, your boom up limit can be bypassed.
  - b. If the boom does not rise, your boom up limit cannot be bypassed.

5. The test is complete: release the limit bypass key and the boom stop rod to the normal operating positions.

### 3. Block-Up Limit

Automatically stops the boom or luffing hoist from lowering and the load drums from hoisting if the load contacts a block-up limit switch.

The load on the corresponding drum can be lowered and the boom or luffing jib can be raised after a block-up limit switch is contacted.

The appropriate limit bypass switch must be turned to the bypass position before a load can be hoisted above the limit.



### WARNING

#### Two-Blocking Hazard!

If it is necessary to hoist a load above block-up limit, do so slowly with extreme caution to prevent two-blocking.

Do not hoist load above minimum block clearance given in Range Diagram (see Capacity Chart Manual).

Do not use limit bypass switch to lower boom or luffing jib after block-up limit is contacted; two-blocking could occur, causing load to fall.

### 4. Luffing Jib Up Limit

Two luffing jib up limits stops are provided:

- **JIB MAXIMUM UP 1** (max working angle): this programmed limit automatically stops the luffing jib when the boom to jib angle is 169°.
- **JIB MAXIMUM UP 2** (max angle): automatically stops the luffing jib when the boom to jib angle is 170.5°.

This limit cannot be bypassed.

The luffing jib can be lowered after either limit is contacted.



### WARNING

#### Falling Boom/Jib Hazard!

Do not raise luffing jib above MAX UP limit. Boom and luffing jib could be pulled over backwards.

### 5. Luffing Jib Down Limit

Two luffing jib down limits are provided:



- **JIB MAXIMUM DOWN 1:** this programmed limit does not stop operation. It activates Fault 50 alarm. You can lower luffing jib an additional 3° to luffing jib maximum down 2 limit.
- **JIB MAXIMUM DOWN 2** (max working angle): automatically stops the luffing jib when the boom to jib angle is 67°.

This limit cannot be bypassed.

The luffing jib can be raised after either limit is contacted.



### **WARNING**

#### **Falling Boom/Jib Hazard!**

Do not lower luffing jib below maximum down limit. Structural damage will result, possibly causing boom and luffing jib to collapse.

---

## **7. Minimum Bail Limit**

Automatically stops the corresponding drum from lowering when there are three wraps of wire rope remaining on the drum.

The load can be raised after the limit is contacted.

The appropriate limit bypass switch must be turned to the bypass position before the load can be lowered below the limit.



### **WARNING**

#### **Falling Load Hazard!**

When lowering load below minimum bail limit, do so slowly with extreme caution. Do not lower load to point where less than three full wraps of wire rope are on drum; wire rope could be pulled out of drum allowing load to fall.

---

***THIS PAGE BLANK***

## SEAT CONTROLS

### CAUTION

#### Avoid Damage!

Disconnect electric cord from rear of left console before you remove seat from operator's cab.



### WARNING


#### Moving Load Hazard!

Operator, be aware that backrest is spring loaded. If you get out of seat to adjust backrest, it will spring forward.

To prevent backrest from springing forward into control handles and activating crane functions, park all crane functions before getting out of seat.

### SEAT HEIGHT AND POSITION

- Move rear switch up or down to raise or lower seat rear.
- Move center switch to raise/lower seat and move it forward/backward.
- Move front switch up or down to raise or lower seat front.



P1743

### BACKREST

- Move switch up to release backrest.
- Use body weight to adjust backrest.
- Release switch to lock position of backrest.

### SEAT FORE-AFT

- Push lever to left to unlock.
- Use body weight to slide seat to desired position.
- Release lever and make sure it is latched to lock seat in position.



P1708a

Left Side of Seat  
Under Armrest

### ARMREST

Turn knob clockwise to raise armrest or counterclockwise to lower armrest.

FIGURE 3-12

## PREPARING CRANE FOR OPERATION



### WARNING

#### Read Capacity Charts!

Do not attempt to operate crane without first reading and understanding capacity charts.

Crane must be rigged and operated according to instructions given in capacity charts and rigging guides.

Unless otherwise specified in capacity charts, all crane operations must be performed with crane level to within one 1% of grade in all directions — 1 ft in 100 ft (0,3 m in 30 m); otherwise, crane could tip.

Do not operate crane, to include raising boom from ground level, if wind exceeds limits given in Capacity Charts. Contact your local weather station for wind velocity.

Failing to comply with Capacity Chart requirements can result in tipping or structural failure of boom or luffing jib.

#### Moving Load Hazard!

Operator must select proper crane capacity chart before operating.

Unexpected drum motion or improper limit responses can result if wrong capacity chart is selected.

Limit bypass switches must be in "activate" position and all limits with which crane is equipped must be operational before operating crane. See Service Manual supplied with your crane for adjustment procedures.

#### Avoid injuring personnel in operating area!

Sound horn to alert personnel that operation is about to begin.

#### Moving Machinery Hazard!

To avoid injuring personnel or damaging crane and property:

- Do not start engine if warning or out-of-order sign is present at start controls.
- Check that all controls are off so crane and load do not move when engine is started.
- Check that all personnel are clear of crane before starting engine. **Sound horn to alert personnel.**

### CAUTION

#### Avoid Machinery Damage!

Before operating crane at start of each shift, perform preventive maintenance checks and lubrication requirements listed in Sections 5 and 6 of this manual.

Adjust operator's seat as shown in Figure 3-12.

## OPERATION

### Engine Startup

Read and understand starting instructions in Engine Operation and Maintenance Manual provided with crane.

1. If used, unplug or turn off engine block heater, engine oil pan heater, hydraulic tank heaters and any other crane heaters.


**NOTE:** Manitowoc recommends the use of heaters (engine, hydraulic tank, etc.) to aid startup when the ambient temperature will be 32°F (0°C) and below.

### CAUTION

#### Pump Damage!

Do not start engine until hydraulic tank shutoff valve is open; otherwise, pumps could cavitate and be damaged.


2. Open hydraulic tank shutoff valve at rear of hydraulic tank (see Figure 3-13).



3. Turn ignition switch to RUN position.

**NOTE:** All indicator lights, operating limit buzzer, and system fault beeper should come on for two to three seconds when ignition switch is in RUN position; if not, replace defective parts.

4. If necessary in cold weather, disengage engine clutch as shown in Figure 3-14. This step will disconnect the pumps from the engine and aid in cold weather startup.



### CAUTION

#### Avoid Engine Clutch Damage!

Observe following precautions for engine clutch:

- **Decrease engine speed to idle** before engaging or disengaging clutch.
- Do not run engine longer than twenty minutes with clutch disengaged.
- Disengage and engage clutch several times monthly with engine running.

5. Turn ignition switch to START.

### CAUTION

#### Starter Motor Damage!

If engine does not start after 30 seconds of cranking, wait a few minutes so starter motor cools before trying again.

**NOTE:** If the engine does not start, check to see if the engine emergency stop switch or the remote control stop switch is depressed. If so, pull it out.

6. Increase engine speed as necessary to keep engine running after it starts.
7. If engine clutch is disengaged, decrease engine speed to low idle and engage engine clutch within 20 minutes after starting engine.

**NOTE:** The engine clutch may be engaged when the temperature of the hydraulic oil is above 0°F (-18°C).

The hydraulic tank heaters are designed to keep the temperature of the oil in the tank at a minimum of 0°F (-18°C).

8. Run engine at low idle until hydraulic oil temperature is higher than 65°F (18°C). Otherwise, the hydraulic fluid temperature fault will remain on.

**NOTE:** It is normal for engine and crane faults to appear when the engine is started. The faults should go away as soon as engine oil pressure and hydraulic oil temperature rise to normal (if no other faults exist).

### CAUTION

#### Machinery Damage!

Do not operate crane when engine and crane faults exist. If faults do not go away soon after engine is started or come on during operation, immediately proceed as follows:

- Determine fault on Main display, Information screen.
- Land loads, if possible, and park all functions.
- Move all control handles to off.
- Stop engine.
- Correct cause of fault.

9. Select crane configuration and capacity charts on RCL display, Configuration screen. The load drums and hoist drums are inoperable until this step is performed.

### CAUTION

#### Mast Assist Damage!

Prevent damage to mast assist arms and cylinders during cold weather:

- Do not attempt to lower live mast with boom hoist/mast hoist until temperature of hydraulic oil is 60°F (16°C).
- Once oil is at specified temperature, fully extend and retract mast assist cylinders twice to fill cylinders with warm oil.

Cylinders and arms will bend under weight of mast if this precaution is not taken.

### CAUTION

#### Machinery Damage!

Continuous operation with hydraulic oil temperature above 180°F (82°C) can result in damage to hydraulic components. Troubleshoot hydraulic system if oil temperature exceeds 180°F (82°C).

## Boom/Mast Hoist Operation

See Figure 3-15 for boom /mast hoist operation.

In standard configuration the boom/mast hoist handle is on the left console. When the crane is configured with a luffing jib, boom/mast hoist handle is the last load drum handle D on right console.

### CAUTION

#### Avoid Rigging Damage!

Check that boom/mast hoist wire rope is reeved through all sheaves and spooled properly onto drum before raising boom from ground.

- See Boom Rigging Drawing in Section 4 for wire rope and reeving specifications.
- See Wire Rope Installation in Section 4 for instructions on attaching wire rope to boom.

1. Select crane configuration and capacity charts on RCL display, Configuration screen.
2. Turn off Drum 4 or Drum 5 park switch.

### CAUTION

#### Avoid Boom or Jib Damage!

Do not turn on drum park switch while raising or lowering boom; brake will bring boom to an abrupt stop. This action could cause shock load damage to boom and jib. Bring boom to a smooth stop with handle and then turn on drum park switch.

3. Increase engine speed to desired rpm with hand throttle. Depress foot throttle to momentarily increase engine speed when more power is required.
4. See Figure 3-15. Push boom/mast hoist handle FORWARD from off to LOWER boom or pull handle BACK from off to RAISE boom.



### WARNING

#### Avoid Two-Blocking Hazard!

Pay out load lines while lowering boom. Load may contact boom point or jib point sheaves if this step is not taken. Wire rope or other parts could break allowing load to fall.




FIGURE 3-15

5. As boom nears desired angle, slowly move handle toward off to decrease speed. Then move handle to off to stop boom and hold it in position and brake will apply.

**NOTE:** Besides a boom up limit, a physical boom stop cushions boom raising between approximately 78° and the maximum angle. The boom stop also provides a physical stop at 90°.

6. Turn on park switch if boom angle will not be changed.

### CAUTION

#### Avoid Rigging Damage!

When lowering boom to ground:

- If equipped, disconnect fixed jib stop before jib point contacts ground.
- If equipped, remove upper boom point before upper point contacts ground.
- If equipped, disengage luffing jib stop at specified boom to luffing jib angle (see Luffing Jib Rigging Guide).

## Luffing Hoist Operation

See Figure 3-15 for Luffing hoist operation.

When the crane is configured with a luffing jib (Drum 3), the multi-function handle on left console controls the luffing jib drum (See Figure 3-15).



### WARNING

#### Avoid Death or Serious Injury!

Read and understand instructions in Luffing Jib Rigging Guide before attempting to raise or lower luffing jib from or to ground.

Use extreme care when operating luffing hoist and boom hoist at same time. Maximum or minimum operating radius will be reached quickly when operating both hoists at same time.

### CAUTION

#### Avoid Rigging Damage!

Check that luffing hoist wire rope is reeved through all sheaves and spooled properly onto Drum 3 before raising boom and jib from ground.

- See Jib Rigging Drawing in Luffing Jib Operator's Manual for wire rope and reeving specifications.
- See Wire Rope Installation in Section 4 of this manual for instructions on attaching wire rope to luffing hoist drum.

1. Select luffing jib configuration and capacity charts on RCL display, Configuration screen.
2. Turn off Drum 3 park switch.

### CAUTION

#### Avoid Boom or Luffing Jib Damage!

Do not turn on Drum 3 park switch while raising or lower luffing jib; brake will bring luffing jib to an abrupt stop. This action could cause shock load damage to boom and jib. Bring luffing jib to smooth stop with control handle and then turn on Drum 3 park switch.

3. Increase engine speed to desired rpm with hand throttle. Depress foot throttle to momentarily increase engine speed when more power is required.
4. See Figure 3-15. Push luffing hoist handle (Drum 3) on right console FORWARD from off to LOWER luffing jib or pull handle BACK from off to RAISE luffing jib.



### WARNING

#### Avoid Two-Blocking Hazard!

Pay out load lines while lowering luffing jib. Load may contact luffing jib point sheaves if this step is not taken. Wire rope or other parts could break allowing load to fall.

5. As luffing jib nears desired angle, slowly move luffing hoist handle toward off to decrease speed. Then move handle to off to stop luffing jib and hold it in position and brake will apply.
6. Turn on Drum 3 park switch if luffing jib angle will not be changed.

### CAUTION

#### Avoid Luffing Jib Damage!

When lowering boom and luffing jib to ground, disengage luffing jib stop at specified boom to luffing jib angle (see Luffing Jib Rigging Guide).

## Swing Operation

See Figure 3-16 for swing operation.



### WARNING

#### Tipping Hazard!

Prevent crane from tipping; adhere to any swing limitations given in capacity charts.



### DANGER!

#### Moving Crane Hazard!

Counterweights can strike personnel in area of swing path! Warn personnel to stay clear of swing path. Sound horn prior to swinging.

1. Turn off swing park switch.

### CAUTION

#### Avoid Boom/Swing Drive Damage!

Do not apply swing holding brake or turn on swing park switch while swinging; brake will bring rotating bed to an abrupt stop. This action could cause damage to boom and luffing jib from side loading or damage to swing drive from shock loading. Bring rotating bed to a smooth stop with swing handle and then apply swing holding brake or turn on swing park switch.

2. Increase engine speed to desired rpm with hand throttle. Press foot throttle to momentarily increase engine speed when more power is required.
3. See Figure 3-16. Push swing handle to LEFT from off to SWING LEFT or pull handle to RIGHT from off to SWING RIGHT.
4. Start swing motion with a smooth acceleration. Continue handle motion to swing at desired speed.

Swing speed and torque can be adjusted on Main display, Function Mode screen to meet operator comfort.

If equipped with optional swing limits, adjust switches to stop rotating bed at desired position in either direction.

5. Stop swinging by releasing swing handle to off. Swing speed will decrease to off and rotating bed will coast to a stop. If a faster stop is desired, move swing handle past off to opposite swing direction.
6. Once rotating bed stops, apply swing holding brake to hold rotating bed in position for short periods during operating cycle.

To hold rotating bed in position for long periods, turn on swing park switch.




FIGURE 3-16

## Load Drum Operation

See Figure 3-17 for load drum operation.

**NOTE:** See Drum and Lagging Chart in Capacity Chart Manual for drum identification.



## WARNING

### Falling Load Hazard!

Prevent load on unused drums from falling. Turn on drum park switch for drums not in use.

1. Select crane configuration and capacity charts on RCL display, Configuration screen.
2. Turn off drum park switch for drum to be operated.

## CAUTION

### Avoid Boom or Luffing Jib Damage!

Do not turn on drum park switch while raising or lowering load; brake will bring load to an abrupt stop. This action could cause shock load damage to boom, luffing jib, and load line. Bring load to a smooth stop with drum handle and then turn on drum park switch.

3. Increase engine speed to desired rpm with hand throttle. Depress foot throttle to momentarily increase engine speed when more power is required.
4. Pull drum handle (Drum 1, 2, or 3) BACK from off to RAISE load or push handle FORWARD from off to LOWER load.
5. As load nears desired position, slowly move drum handle toward off to slow down load. Then release handle to off to stop load and hold it in position and drum brake will apply.




FIGURE 3-17



## Travel Operation



### WARNING

#### Tipping Hazard!

Travel surface must be firm and uniformly supporting.

For **traveling with load**, grade must not exceed 1% in any direction.

For **traveling without load**, grade in direction of travel must not exceed 30%; grade from side to side must not exceed 2%, measured at boom hinge pins. For all travel on grades, see Maximum Allowable Travel Specifications Chart in Capacity Chart Manual.

Failing to comply with above specifications can result in tipping.

#### Moving Crane Hazard!

Know position of rotating bed with relation to front of carbody before traveling. An accident can result if crane travels opposite of intended direction.

#### Flying Object Hazard!

Excessive dirt build-up at tumbler and front roller ends of crawlers can result in excessive tension in tread connectors. Tread connectors can break if over tensioned, causing treads to fly apart unexpectedly with dangerous force.

## CAUTION

### Crawler Damage!

Avoid damage to crawler components (treads, rollers, frames)!

Use care to prevent dirt from piling up at tumbler and front roller ends of crawlers when turning on soft surfaces:

- Bring crawlers to a complete stop before changing travel direction.
- Turn a few degrees. Then slowly travel forward or reverse so dirt falls away from crawlers. Continue this procedure until desired turn has been made.
- Avoid sharp turns (Figure 3-19) if possible.
- Make gradual turns (Figure 3-20) or counter-rotate (Figure 3-21) whenever possible so both crawlers are always powered.
- Clean crawlers often.
- Keep crawler treads properly adjusted.

## CAUTION

### Boom Damage!

Avoid shock loading boom and rigging!

- Perform all travel functions — starting, turning, stopping — slowly and smoothly.

#### 1. Before traveling:

- a. Plan travel route. It must be free of ground and overhead constructions.
- b. Check crawlers for proper adjustment.
- c. Warn personnel to stand clear of travel area. **Do not travel without a signal person.**

#### 2. Position boom at or above boom angle given on capacity chart when **traveling with load**.

#### 3. Travel with boom in-line with crawlers except when swinging is necessary while traveling. Travel with boom facing direction of travel.

#### 4. For **traveling with load**, carry load as close to ground as possible; stabilize load with taglines.

For **traveling without load**, carry load block and weight ball low enough that they cannot swing into boom or jib. If desired, tie off load block at front of rotating bed.

#### 5. Increase engine speed to desired rpm with hand throttle. Depress foot throttle to momentarily increase engine speed when more power is required.

#### 6. Select desired travel speed, low or high.

**NOTE:** The following directions of travel are with **front of rotating bed and front of carbody facing same direction**.

- Operator's cab is at front of rotating bed.
- Carbody/crawler control valve is at front of carbody.

If the front of the rotating bed and the front of the carbody face in opposite directions, the crane will travel in the direction opposite of handle movement.

7. To TRAVEL STRAIGHT (Figure 3-18), move both crawler handles same amount in desired direction from off.




FIGURE 3-18

8. To make a SHARP LEFT TURN (Figure 3-19), move right crawler handle to front from off and leave left crawler handle in off; crane will pivot about left crawler.
9. To make a SHARP RIGHT TURN, reverse step 8.




FIGURE 3-19

10. To make a GRADUAL LEFT TURN (Figure 3-20), move both crawler handles to front from off, but move right crawler handle farther to front than left crawler handle; right crawler will turn faster than left crawler.




FIGURE 3-20

11. To make a GRADUAL RIGHT TURN, reverse step 10.
12. To COUNTER-ROTATE LEFT (Figure 3-21), move right crawler handle to front from off and move left crawler handle to rear from off.




FIGURE 3-21

13. To COUNTER-ROTATE RIGHT, reverse step 12.
14. Slowly move both crawler handles to off to stop traveling and to hold crane in position.
15. Turn on travel park switch.

## STOPPING ENGINE/ LEAVING CRANE UNATTENDED



### WARNING

#### Moving Load/Tipping Crane Hazard!

Operator shall not leave operator's cab until crane, loads, and boom have been secured against movement.

Changing weather conditions including but not limited to: wind, ice or snow accumulation, precipitation, flooding, lightning, etc. should be considered when determining the location and configuration of a crane when it will be left unattended.

1. Travel crane onto a level surface; ***do not leave crane unattended on a grade.***
2. Turn on travel park switch.
3. Swing rotating bed to desired position. Then turn on swing park switch.
4. Lower all loads to ground.

5. Turn on drum park switch for each load drum.
6. If possible, lower boom and luffing jib onto blocking at ground level and turn on boom park switch.

If the boom and luffing jib cannot be lowered, as determined by a qualified designated person, they must be securely fastened from movement by wind or other outside forces (see Wind Conditions in Capacity Chart Manual).

**NOTE:** The designated person must be familiar with the job site limitations, the crane configuration, and the expected weather conditions.

7. Check that all control handles are off.
8. Decrease engine speed to idle.  
Allow engine to idle for three to five minutes so it cools evenly.
9. Stop engine.
10. Remove all keys from cab to ***prevent unauthorized operation.***
11. Lock operator's cab windows and door to ***prevent unauthorized entry.***

## REMOTE CONTROLS



### WARNING

#### Read Instructions!

Avoid death or serious injury to personnel and damage to crane:

- Read Crane Assembly and Disassembly Instructions in Section 4 before operating remote controls.

The following instructions identify and describe operation of the remote controls used for crane assembly and disassembly.

### General

The following instructions identify and describe operation of remote controls. Disregard any control not equipped on your crane.

This crane has two types of remote controls:


- Electronic crane setup remote control shown in Figure 3-23. Store the crane setup remote control in the operator's cab until needed (see Figure 3-22).
- Manual carbody remote control shown in Figure 3-27.

P1976




Shelf Behind Seat in Cab

FIGURE 3-22



View A — with Upperworks Jacking

A12639



View B — without Upperworks Jacking

FIGURE 3-23

### Crane Setup Remote Controls

The wireless remote control can be operated in any mode.

A slight delay is normal from the time a remote toggle switch is enabled to the time the corresponding function operates.

To turn on the remote control, proceed as follows:

1. Enter the function mode screen in the main display (Figure 3-24).




FIGURE 3-24

2. Scroll to and enter the setup screen (Figure 3-25).




FIGURE 3-25

3. The screen in Figure 3-26 will appear.





FIGURE 3-26

4. Verify the TXID number on the screen matches the number on top of the remote control. If not, enter the proper number.
5. Hold down the power button on the remote control.
6. Scroll up or down to turn on the remote control.
7. Continue to hold down the power button on the remote control until the remote control ON prompt (shown to right) flashes in the display. This could take 5-10 seconds.  
  
The flashing prompt indicates the remote control is communicating properly.
8. Exit the remote control data box to save the setting.
9. The remote control remains on (remote control ON prompt remains in display) until it is turned off.

See Figure 3-23 for following items.

### 1–Power Switch

DEPRESS button to TURN ON battery power to remote controls.

RELEASE button to TURN OFF battery power to remote controls.

### 2–Stop Switch

DEPRESS knob to STOP the engine and all remote controlled functions in an emergency only — for example: if a function does not stop when the control is released to off or any other uncontrolled motion of a function is observed.

Always use ignition switch in cab to stop engine for normal operating conditions.

**Beware — when knob is pushed down, engine stops and any function being operated comes to an abrupt stop.**

**NOTE:** The knob must be pulled UP to RESTART the engine and operate remote controlled functions.

### 3–Left Front Jacking Toggle Switch

### 4–Right Front Jacking Toggle Switch

### 5–Left Rear Jacking Toggle Switch

### 6–Right Rear Jacking Toggle Switch

### 7–All Jacking Toggle Switch

## WARNING

### Moving Part Hazard!

To avoid serious crushing injury:

- Keep feet clear of moving jacks.
- Warn all personnel to stay clear of jacks while they are being extended.

### Tipping Hazard!

- Keep crane as level as possible while jacking. Do not allow crane to get more than 4.5° out of level while jacking to prevent crane from collapsing due to structural failure of jacks.

Move selected toggle UP and hold to EXTEND jacking cylinder.

Release toggle to CENTER to STOP jacking cylinder.

Move selected toggle DOWN and hold to RETRACT jacking cylinder.

Use the ALL toggle to operate all four jacking cylinders at the same time in the selected direction.

## CAUTION

### Machinery Damage!

To avoid damage to jacking cylinders, fully retract them before traveling.

**NOTE:** On crane Serial Number 16001128 and newer with upperworks jacking (remote control shown in View A Figure 3-23):

The travel and swing alarm will sound while jacking with any switch on the remote control.

When the ALL jacking switch is used, the crane's programmable controller will attempt to adjust the jacking cylinders to maintain or return the rotating bed to level as sensed by the rotating bed level sensor.

Prior to using the ALL jacking switch, verify the accuracy of the rotating bed level sensor with a user furnished digital level. The angles shown on the main display should be the same as the angles shown on the digital level.

Out of level fault 4 will appear on the main display and the swing and travel alarm will sound if the rotating bed gets approximately 3° out of level while jacking.

- Operation does not stop automatically when this alarm comes on.
- When this alarm comes on, **operator must stop jacking and level rotating bed using individual jacking switches.**

If the rotating bed level sensor indicates that the rotating bed is approximately 4.5° out of level, out of level sensor fault 43 will appear on the main display, the swing and travel alarm will sound at a lower pitch than normal, and the ALL jacks switch will be disabled. The rotating bed should then be leveled using the individual jacking switches, and the accuracy of the rotating bed level sensor should be checked.

### 8–Boom Pins Switch



#### **WARNING**

##### **Falling Load Hazard!**

To prevent boom or boom butt from falling off crane:

- Do not disengage boom hinge pins until boom butt is properly supported on stands at ground level. Boom/boom butt could fall off crane.
- Read Boom Rigging Guide in Section 4 of this Manual.

Move toggle UP and hold to ENGAGE boom hinge pins.

Release toggle to CENTER to STOP pins.

Move toggle DOWN and hold to DISENGAGE boom hinge pins.

### 9–Front Rotating Bed Pins Switch

### 10–Rear Rotating Bed Pins Switch

Move selected toggle UP and hold to ENGAGE rotating bed pins.

Release toggle to CENTER to STOP.

Move selected toggle DOWN and hold to DISENGAGE rotating bed pins.

### 11–Counterweight Pins Switch

Move toggle DOWN and hold to DISENGAGE counterweight pins. Counterweight pins return to ENGAGED position when toggle is released.

### 12–Engine Speed Switch

The engine speed switch allows the operator to select high or low engine idle speed from a remote position. Speed of operation (jacks and pins) depends on toggle switch movement and engine speed. To provide adequate speed for some items, engine should be operated at high idle.

Place toggle UP to HIGH to operate engine at high idle.

Place toggle DOWN to LOW to operate engine at low idle.

### 13–Mast Switch

Move toggle UP and hold to RAISE live mast arms with mast cylinders.

Release toggle to CENTER to STOP mast cylinders. Valves on the cylinders lock them in position.

Move toggle DOWN and hold to LOWER live mast arms with mast cylinders.

Read Crane Assembly and Disassembly in Section 4 for live mast raising and lowering instructions.

## **Carbody Manual Remote Controls**

The speed at which the jacks and pins operate depends on control handle movement and engine speed. To provide adequate engine speed, operate engine at mid to high idle.

All control handles are spring returned to off.

See Figure 3-27 for following items.

### 14–Right Crawler Pin Handle

### 15–Left Crawler Pin Handle

Pull selected crawler pin handle DOWN to ENGAGE crawler pins.

Release handle to CENTER when pins are fully engaged.

Push selected crawler pin handle UP to DISENGAGE crawler pins.

**NOTE:** Carbody jacking is provided as an option to allow the carbody, adapter frame, rotating bed and cab to be transported as one unit.

**16–Right Front Carbody Jack Handle**

**17–Right Rear Carbody Jack Handle**

**18–Left Rear Carbody Jack Handle**

**19–Left Front Carbody Jack Handle**



## WARNING

### Moving Part Hazard!

To avoid serious crushing injury:

- Keep feet clear of moving jacks.
- Warn all personnel to stay clear of jacks while they are being extended.

### Tipping Hazard!

- Keep crane as level as possible while jacking. Do not allow crane to get more than 3° out of level while jacking to prevent crane from collapsing due to structural failure of jacks. Monitor carbody level while jacking.

Push handle TOWARD carbody to LOWER carbody (retract jack).

Release handle to CENTER to stop jack. Valves on the jack lock it in position.

Pull handle AWAY from carbody to RAISE carbody (extend jack).

## CAUTION

### Machinery Damage!

To avoid damage to carbody jacks, fully retract jacks before traveling.

### 20–Carbody Level

Indicates crane levelness from front to rear and from side to side while jacking carbody (see item C4. Bubble Level on page 3-15).

## Replacing Wireless Remote Batteries


The wireless remote control is powered by two AA size batteries in the control handle. The battery status is shown on Main display, CAN Bus screen. The wireless icon displays the following:

- 16 and 32 On — 75% and up battery charge.
- 32 On, 16 Off — 50% to 75% battery charge.
- 32 Off, 16 On — 25% to 50% battery charge.
- Both Off — 0% to 25% battery charge.

To replace batteries:

1. Remove end cap at bottom of control handle.
2. The seal gasket must remain in place.
3. Remove old batteries.
4. Replace with two AA Lithium type batteries, if possible.

**NOTE:** Alkaline AA type batteries can be substituted, but battery life is reduced.




## DISPLAYS

### Display Controls

See Figure 3-28 for following procedure.

The Menu screens for the RCL and crane is displayed with select buttons. Use the following controls to operate the display screens.



#### 1 – RCL Display

Rated Capacity Indicator/Limiter (RCL) display is on the left side of front console. (See RCL document for operation.)

#### 2 – Main Display

The main display is on the right side of the front console (these screens are described in this section).

#### 3 – Display Touchpad Controls

Contains all the screen controls required to operate the RCL display and Main display screens.

#### 4 – Display Select Buttons

**4a.** To select Rated Capacity Indicator/Limiter display, press touch pad button 1.

**4b.** To select Main display, press touch pad button 2.

#### 5 – Select Buttons

Use the green select touch pad buttons to select screen images, icons or data boxes, and values or icons within data boxes. Button (5a) scrolls up and button (5b) scrolls down.

#### 6 – Enter/Exit Buttons

Use the red touch pad buttons to enter (6a) or exit (6b) a screen or to change the screen's operating **level**. Use Enter

button to enter a screen or go to the next level. Use Exit button to exit a screen or level.

#### 7 – Confirm Button

Use the purple Confirm touchpad button to start certain test routines from the screen and to confirm data when required.

### Display Brightness and Color Contrast

To adjust display contrast, proceed as follows:

1. Press desired display button (4a or 4b) and confirm button (7) at same time to select the desired display.
2. Release confirm button (first) and then release display button.
3. Press top select button (5a) to lighten display, or press bottom select button (5b) to darken display.
4. Press enter button (6a) to increase color intensity, or press exit button (6b) to decrease color intensity.
5. Press confirm button.

### Factory Default Display Settings

This procedure only applies to cranes with program number 16000 FCN 2.039 and newer.

1. Press desired display button (4a or 4b) and confirm button (7) at the same time to select the desired display.
2. Press select buttons (5a and 5b) at the same time to return to the factory default display settings.
3. Press confirm button.

### Blank Display.

If a display goes blank on cranes with program number 16000 FCN 2.039 and newer, try the following procedure to restore a the display. **Do not return a display to Manitowoc until this procedure has been tried.**

1. Press desired display button (4a or 4b) and confirm button (7) at the same time.
2. Press select buttons (5a and 5b) at the same time to return to the factory default display settings.
3. Press confirm button.






### Main GUI Display Format

The basic components for the Main GUI display format are the Information screen, Diagnostic screens, Function Mode screens, CAN Bus screen, Camera screens, and Pressure Test and Calibration screens. The appearance and function of each screen depends on the screen **level**. Some screen levels show icons and/or data boxes that can be selected to change parameters and/or to enter different screen levels.



## Screen Prompts

Screen prompts can appear on a selected screen if a fault condition exist or to prompt or confirm certain operator actions when required by the system. Prompt descriptions and icons are shown below.

- The RCL Display is item 1 and the Main Display is item 2. 
- The yellow alert symbol is displayed if a system fault occurs. See Information screen topic in this section to access faults. 
- The purple confirm prompt appears when the operator must start certain test routines from the screen and to confirm data when required. 
- The wireless remote symbol is displayed when the hand-held wireless remote is enabled. 
- The engine stopped symbol is displayed when engine is stopped. 

A graphic picture of the Manitowoc logo is displayed at crane startup See Figure 3-29. The Manitowoc screen displays the following program items:

- Model/ Program Number (16000 FCN 1.012 shown).
- Con Number (009 000 000 008 shown).
- Screen Program Number (GUI 2.007 shown).




FIGURE 3-29

## Menu Screen

See Figure 3-30 for following procedure.

The Menu screen is the **base** screen for the crane system. All other screens must be entered from this screen. Exiting from any screen will return to the Menu screen.



The Menu screen shows six screen icons:

1. Information Screen icon
2. Diagnostic Screen icon
3. Function Mode Screen icon
4. CAN Bus Screen icon
5. Camera Screen icon
6. Pressure Test and Calibration Screen icon

The Menu screen operates on one **level** only.

- Use Select buttons to highlight icon that represents the screen to be entered. Press the Enter button to go to selected screen.
- To return to Menu screen, press Exit button until Menu screen appears.

## Information Screen

See Figure 3-31 for following procedure.

Information screen shows all the general crane information required for viewing during normal operation. The screens contain three data boxes which may be individually tailored to show the information items appropriate for the current crane application.

The Information screen operates on three **levels**:

**Level 1**— Selected data box highlighted blue. Use Select buttons to highlight the data box to change.

**Level 2** — Selected data box highlighted red. Use Select buttons to choose the information item to be shown in the highlighted data box.

**Level 3** — Selected data box highlighted green (if applicable). Use Select buttons to alter the information displayed in the highlighted data box.





FIGURE 3-31

The crane information items currently available (if equipped) for the two smaller data boxes on the left side of the screen are as follows:


### Crane Level

Crane level icon displays the crane level condition forward to rear and side to side. Unless otherwise specified in capacity charts, all crane operations must be performed with crane level to within one 1% of grade in all directions — 1 ft in 100 ft (0,3 m in 30 m); or crane could tip.




### Boom to Luffing Jib Working Angle

Boom to luffing jib icon displays the boom to jib working angle between center line of boom and center line of luffing jib.




### Wind Speed Indicator

Wind speed icon displays the steady wind speed and maximum gust wind speed. The indicator is reset with Confirm button in **level 3**.




### Mast Angle

Mast angle icon displays the mast angle in degrees mast is positioned above transport position.




### Hydraulic Tank

Hydraulic tank icon displays the tank fluid level in percent and temperature in degrees.




### Battery

Battery icon displays the active battery voltage.



### Pump Drive

Pump drive icon displays the oil pressure and temperature of pump drive cooling system.



### MAX-ER Icons


MAX-ER counterweight lift position and telescopic beam extend icons are not shown. See MAX-ER Operator's Manual for complete MAX-ER attachment information.

The crane information items currently available (if equipped) for the large data box on the right side of the screen are as follows:

### Engine

Engine data box displays the following engine items:

- Engine coolant temperature should be below 204°F (96°C).
- Engine oil pressure should be above 15 psi (1.03 bar).
- Engine speed in rpm, 1050 rpm low idle 1,800 rpm high idle.
- Fuel level in percent of fuel in main tank.
- Engine hours displays the total number of hours engine has been run.
- Diagnostic box with engine manufacturer's fault code/flash code. See engine Owners Manual for description of fault codes.




**MAX-ER (Optional)**

MAX-ER data box displays the MAX-ER wheel position icons (not shown). See MAX-ER Operator's Manual for complete MAX-ER attachment information.

**Faults**

The fault data box displays the fault icon with the fault number, date, and time of day listed in the order they occurred.

When one or more faults are enabled, an alarm turns on to warn the operator. The yellow alert symbol is displayed on active screen if a fault occurs. You must go to Information screen to identify the

























fault. When the fault data box is selected, the screen scrolls through the current faults one icon at a time. The fault history goes back in time to review past faults.












Press the Enter button to access **level 2** and use Select buttons to view past fault history. Press the Exit button to exit the fault screen. The alarm turns off when the cause of fault is corrected. Depending on the configuration, not all listed faults are active (see faults in Table 3-2).



Table 3-2 lists all the faults that can appear in the fault screen. **Some of the fault items shown in Table 3-2 may not be on your crane.**

Faults indicated with an asterisk (\*) **will** stop crane operation in the direction of the fault. **Corrective action must be take before continuing crane operation.** The other faults **will not** stop crane operation. **Correct all faults as soon as possible.**

Table 3-2. Faults

Item	Description	Item	Description
	0-No Fault.		57-Minimum Bail* — Limit switch stops drum (x) from lowering or down direction. Move drum in hoisting or up direction.
	4-Out of Level (S/N 16001128 and newer) — Indicates that crane is approximately 3° to 4-1/2° out of level while jacking upperworks with setup remote control.		60-Block Up Limit* — Limit switch stops load drum and boom. Lower load or raise boom.
	6-Setup Mode — Indicates setup mode is on (Liftcrane Mast Capacities Chart selected in configuration screen of RCL or luffing jib setup mode, if applicable, is on.		61-Filter 1 — Filter is dirty or plugged. 62-Filter 2 — Replace element or clean filter.
	10-Engine Fault* — See engine data box on Information screen. See engine Owners Manual for diagnostics fault codes.		63-Boom Angle Sensor — Boom angle sensor is out of normal range (0.15 to 4.85 Volts).
	13-Mast 2 Degree Fault* — Stops down movement of live mast when lowering to transport position. Complete mast lowering manually with hand-held wireless remote.		64-Jib Angle Sensor — Luffing jib angle sensor is out of normal range (0.15 to 4.85 Volts).
	34-Function Parked* — Function inoperable because it is parked. Turn indicated park switch off or sit down in operator's seat.		65-Hydraulic Fluid Temperature — Fluid temperature in hydraulic tank is below 65°F (18°C) or above 180°F (82°C).
	43-Out of Level Sensor (S/N 16001128 and newer) — Indicates that crane is approximately 4-1/2° out of level while jacking upperworks with ALL switch on setup remote control. Relevel crane with individual jacking switches on remote control.		66-Mast Too Far Forward* — Live mast is below 156°. Raise live mast. Further lowering is not intended - <b>mast will fall</b> .
	49-Jib Maximum Up 1* — Program limit stops luffing jib when jib is raised to maximum working angle. Lower luffing jib. Can bypass this limit to raise jib to Maximum Up 2 limit.		67-Jib Maximum Down 2* — Limit switch stops luffing jib when jib is lowered to minimum angle. Raise luffing jib.
	50-Jib Maximum Down 1* — Program limit activates fault alarm. Operation does not stop. You can lower luffing jib an additional 3° to Luffing jib maximum down 2 limit (67).		69-Hydraulic Reservoir Level — Hydraulic oil at <b>caution low level</b> indicated on tank gauge. Fill tank.
	54-Rated Capacity Indicator/Limiter* — Stops all drums. Land load or raise boom/jib.		70-Engine Coolant Temperature — Engine coolant temperature above 205°F (96°C).
	55-Boom Up* — Limit switch stops boom in up direction. Move boom in lowering direction.		71-Engine Oil Pressure — Oil pressure below 7.25 psi (0.5 bar).

Item	Description
	73-Jib Maximum Up 2* — Limit switch stops luffing jib when jib is raised to maximum angle. Lower luffing jib. Cannot bypass this limit.
	75-Low Fuel Level — Five percent fuel remaining in tank. Fill tank as soon as possible to prevent engine stoppage.
	77-Mast System — Boom/mast hoist inoperable in both directions. Determine cause of fault and correct.
	78-Battery Low — Battery voltage below 18 volts. Determine cause of fault and correct.
	80-Invalid Configuration* — Make sure selected RCL configuration for load drums is correct.
	81-Wireless System — Wireless load link sensing fault. See wireless link information in separate Rated Capacity Indicator/Limiter manual.
	83-Alternator — Engine alternator is not generating a charge to the battery.
	84-Digital Output Disabled — Digital output signal has a short circuit between computer node and output device. See CAN Bus screen or Diagnostic screen information to identify problem component.
	85-CAN Communication — One or more computer nodes are not communicating correctly. See CAN Bus screen to identify node(s).
	86-Boom Range Limiter* — Up or down range limiter is tripped. Move boom in direction away from limit.
	87-Swing Range Limiter* — Right or left range limiter is tripped. Swing rotating bed in direction away from limit.

Item	Description
	88-Engine Shutdown* — Remote emergency stop shut down switch is pushed. Pull switch up to reset and allow engine to start.
	89-Super Charge Pressure — Pressure switch that monitors hydraulic fluid to main pumps is open.

## Diagnostic Screen

Diagnostic screens shows a graphic of hydraulic circuit and status of all pumps, motors, valves, and switches that apply to crane function selected.

This view-only screen operates on two **levels**:

**Level 1** — Image of overall crane shown. Use Select buttons to highlight individual crane functions.

**Level 2** — Shows Diagnostic screen for highlighted crane functions.


The yellow alert symbol is displayed if a system fault occurs. You must go back to Information screen to identify the fault.

### Diagnostic Screen Component Icons

Each Diagnostic screen component icon is identified and described in the following paragraphs.


#### Control Handle

Displays system control handle command in percent from neutral with +raise and –lower for drums, +right and –left for swing, and +forward and –reverse for travel.




#### Variable Closed-Loop Pump

Pump command from neutral (0%) to +/-% of full displacement for drums, swing, and travel.




#### Gear Pump

Accessory pump or system charge pump.




#### Variable Closed-Loop Motor

Displays motor command with 0% maximum displacement and 100% minimum displacement.




### Closed Loop Variable Motor with Remote Pilot

Displays two-speed motor with remote pilot. This motor type is used for shifting motor speeds automatically when selected.




### System Pressure Sender

Displays hydraulic pressure (psi/bar).



### DIN Electrical Connector


DIN electrical connector changes to yellow when selected item is enabled. The yellow short to ground icon or open circuit icon indicates a circuit fault that must be serviced immediately.



**NOTE:** Variable outputs may show a yellow icon all the time.


### Drum Speed

Displays drum speed in revolutions per minute (rpm). Drum direction is also shown.




### Swing Status

Displays status of swing. Swing right (shown) or swing left arrow is yellow when swing is enabled. Swing speed is shown in revolutions per minute (rpm).




### Track Symbol

Shows travel function. Travel (right shown) is yellow when function is operating.




### Valve Status

Displays status of a valve.




### Pilot Valve

Displays status of an external piloted valve.




### Disc Brake

Displays disc brake status— applied or released (shown).




### Swing Lock

Displays swing lock status — disengaged (shown) or engaged.



### Drum Pawl

Displays pawl status — engaged or disengaged (shown).




### Mast Angle

Displays mast angle in degrees mast is positioned above transport position.



### Mast Raise Status

Displays command state of mast raise cylinders.




### Cab Tilt Status

Displays command state of cab tilt cylinder — cab up/out or down/in (shown).



### Rigging Winch Status

Displays command state of rigging winch — haul in or pay out (shown) line.



### Counterweight Pin Status

Displays command state of counterweight pin cylinders — extended (shown) or retracted.



### Boom Hinge Pin Status

Displays command state of boom hinge pin cylinders — extended (shown) or retracted.



### Rotating Bed Pin Status

Displays command state of rotating bed pins — extended or retracted (shown).




### Engine Cooling Fan Status

Displays command state of engine cooling fan (shown on).



### Crane on Jacks Symbol

Displays image of crane on jacks. Front view icon also shown on Diagnostic screen.




### Jack Status

Displays command state of a jack cylinder. Left rear jack extended shown.



### Wireless Remote Control

Displays wireless remote control status by indicating which switches are closed. Each control switch corresponds with a number (see Table 3-3). Switch numbers start from 1 through 8 in row one, 9 through 16 in row two, 17 through 24 in row three and 25 through 32 in row four. Not all switch numbers are used. Switch number 14 (Left Front Jack - Extend) is enabled in example shown.




**Table 3-3 Wireless Remote Switch Identification**

No.	Description	No.	Description
1	Engine Low Speed	16	Right Front Jack - Extend
2	Engine High Speed	17	Left Rear Jack - Retract
7	Boom Pins - In	18	Left Rear Jack - Extend
8	Boom Pins - Out	19	Right Rear Jack - Retract
9	Front Adapter Pins - In	20	Right Rear Jack - Extend
10	Front Adapter Pins - Out	21	All Jacks - Retract
11	Rear Adapter Pins - In	22	All Jacks - Extend
12	Rear Adapter Pins - Out	24	Counterweight Pins - Out
13	Left Front Jack - Retract	25	Mast Lower
14	Left Front Jack - Extend	26	Mast Raise
15	Right Front Jack - Retract	27	Remote Stop

**Drum Diagnostic Screens**

Select drum icon in screen **level 1** as shown Figure 3-32. Press Enter button to go to **level 2**

**FIGURE 3-32**


In the drum example shown in Figure 3-33, drum 4 function is shown hoisting **up**. A single pump is shared with drum 5

and is connected to drum 4 through a diverting valve. A second pump could also power drum 4 shown connected to the left track through upper diverting valve.

**NOTE:** Mast hoist drum 5 is only selected when crane is configured with a MAX-ER.

For load drums 1 or 2, drum 2 pump is dedicated to the drum 1 motor through diverting valve when drum 1 is selected. The opposite is true when drum 2 is selected. Both drums can be operated at the same time but would operate at one half speed.


For load drum 3, the left travel pump is dedicated to operate drum 3 motor through diverting valve when drum 3 is selected. Drum 3 is inoperable when traveling. Drum 3 can be configured as load drum or luffing jib.

**FIGURE 3-33**




### Swing Diagnostic Screen

Select swing icon in screen **level 1** as shown in Figure 3-34. Press Enter button to go to **level 2**




Swing system icons are displayed in Figure 3-35. The example shows how the swing function might appear when swinging right. Circular arrow symbols near each pressure sender indicate which sender monitors swing right and left pressures.




### Travel Diagnostic Screen

Select travel icon in screen **level 1** as shown in Figure 3-36. Press Enter button to go to **level 2**



In travel system example shown in Figure 3-37, the left travel pump is dedicated to operate drum 3 through diverting valve if drum 3 is selected. The right travel pump is dedicated to operate drum 4 through diverting valve if drum 4 is selected under certain conditions when drum 5 is also configured.


**NOTE:** When crane travel is enabled, drum 3 is disabled.






**Jacking Accessory Diagnostic Screen**


Select crane carbody with jacking icon in screen **level 1** as shown in Figure 3-47. Press Enter button to go to **level 2**

**FIGURE 3-38**


At jacking accessory diagnostic screen component icons are displayed as shown in Figure 3-39. In the following example, all jack switch on wireless remote is selected. The crane on jacks icons indicate crane level status.

**FIGURE 3-39****Pins and Fan Accessory Diagnostic Screen**

Select crane, pins, and engine fan icon in screen **level 1** as shown in Figure 3-40. Press Enter button to go to **level 2**

**FIGURE 3-40**

For counterweight pins, boom hinge pins, front/rear rotating bed pins, and engine fan screen see Figure 3-41. In the following example, the left front rotating bed pin on wireless remote is selected. Engine fan status is also shown.

**FIGURE 3-41**

### Cab Tilt, Rigging Winch, and Mast Accessory Diagnostic Screen

Select cab tilt, rigging winch, and mast icon in screen **level 1** as shown in Figure 3-42. Press Enter button to go to **level 2**.




FIGURE 3-42

For cab tilt, rigging winch, and mast raising cylinders screen see Figure 3-43. In the following example, the mast raising cylinders in up direction on wireless remote is selected.




FIGURE 3-43

### MAX-ER Diagnostic Screen

Select MAX-ER (optional) icon in screen **level 1** and press enter button to go to **level 2**. See MAX-ER Operator's Manual for complete MAX-ER attachment information.

### Function Mode Screens

See Figure 3-44 for following procedure.

The Function Mode screens are to enable/disable modes and to set operating parameter for the individual crane functions. This screen operates on four **levels**.

**Level 1**— Image of overall crane shown. Use Select buttons to highlight individual crane functions.

**Level 2**— Shows the function mode screen for highlighted crane function. The selected mode or limit data box is highlighted blue. Use Select buttons to choose a mode or limit data box.

**Level 3**— The selected mode or limit data box highlighted red. Use Select buttons to enable/disable a mode or to set a limit.

**Level 4**— The selected mode or limit data box highlighted green. Use Select buttons to adjust the value shown in data box.

To enable/disable modes or to set operating parameters for the individual crane functions:

1. Press Enter or Exit buttons as required to go to **level 1**. Use Select buttons to highlight desired crane function.
2. Press Enter button to go to **level 2**. Use Select buttons to choose the mode or limit data box to access. Press Enter button to go to **level 3**.
3. Use Select buttons to enable/disable mode or to adjust operational parameter.
4. Press Enter button to go to **level 4** if required. Use Select buttons to adjust operational parameter.
5. Press the Exit button as required to return to a previous **level** or to the Menu screen.

The yellow alert symbol is displayed if a system fault occurs. See Information screen to access faults.

**On** (I) and **off** (O) icons in some data boxes indicate and enable the electrical status of item.



### Drum Functions

Select drum functions 1 through 5 from screen shown below.




FIGURE 3-44

### Swing Functions

Select swing functions from screen shown below.




FIGURE 3-45

### Travel Functions

Select travel functions from screen shown below.




FIGURE 3-46

### Setup Remote Functions

Select setup remote function from screen shown below.




FIGURE 3-47

### MAX-ER Functions

Select MAX-ER functions from MAX-ER attachment screen. See MAX-ER Operator's Manual for complete MAX-ER attachment information.

### Drum, Swing or Track Speed Limits

See Figure 3-48 in following procedure.

Drum, swing, and crawler speeds can be selected. In **level 3**, the value shown in these data boxes can be adjusted with the Select buttons to limit the function speed between 25% and 100% of maximum capability.




FIGURE 3-48

### Swing Pressure Limit

See Figure 3-49 in following procedure.

In **level 3**, the value shown in this data box can be adjusted with the Select buttons to limit swing pressure between 25% and 100% of maximum capability.




FIGURE 3-49

### Rigging Winch Mode

See Figure 3-50 in following procedure.

In **level 3**, use the Select buttons to enable or disable rigging winch for the selected drum function. The rigging winch mode data box **shown disabled** will not appear in the function mode screen unless this feature is available.

When rigging winch is enabled, the computer selects control handle (selected handle display light is 0). If rigging winch is enabled for drum 4, the computer selects a load drum handle to control winch.




FIGURE 3-50

Boom or Swing Motion Limiter Mode

See Figure 3-50 in following procedure.

**NOTE:** Motion limiter mode data boxes do not appear unless crane has this option.

In **level 3**, use the Select buttons to enable or disable the motion limiter mode. When in **level 3** with the motion limiter mode enabled, the controller monitors and stores the maximum right/left or up/down angles during operation. After exiting **level 3**, these angles are used to limit boom or swing motion.




FIGURE 3-51

Setup Remote Control Mode

To turn on the crane setup remote control, see procedure under Crane Setup Remote Controls topic on page 3-34.




FIGURE 3-52

CAN Bus Screen

See Figure 3-53 for following procedure.

The CAN (Controller Area Network) bus diagnostic screen is for technicians. The screen displays CAN bus packet and node information, engine status, history status, and boom status. Any node that is yellow indicates that communication is lost to that node.

The CAN Bus screen operates on two **levels**:

**Level 1** — Packet number data box highlighted blue.

**Level 2** — Packet number data box highlighted red.




FIGURE 3-53

Packet Information

The top row of the screen contains CAN Bus packet number (26). Enter the desired packet number in the first data box by using Select buttons.

Packet type (DO) is displayed on top middle data box.

Related node (2) is displayed in top last data box.

Packet contents is displayed in the eight banks under the row. Packet content and format depends on packet type. Many packets are not easily interpreted by other than factory technical personnel and their content is not discussed in this publication.

Each individual input/output is assigned a number (identifier) in the binary system (powers of two). The identifiers of all inputs/outputs that are ON (active) for each bank are added for a total of 0 – 255. The number displayed for each bank is the **sum** of all identifiers that are ON in that bank. Each possible ON/OFF combination per bank has a unique total.

To determine the status of an individual digital input or output, you need to know the CAN packet number (see Table 3-5 and Table 3-6). For example: **Drum 1 Brake** has a packet number of **CAN26-1-64**.

The first part of the Code Number (**26**) indicates that the individual input or output is located in **packet 26** of the CAN communications.

Second part of Code Number (**1**) indicates the **bank** where the individual information is shown on the CAN screen.

The third part of the Code Number (**64**) is the item **identifier**.

Determine status of the individual input/output by check the total in bank 1 (255). Find 255 in the numbered column of Table 3-7 - Bank Identifier Numbers. In the corresponding row the identifier numbers that are ON in the bank are shaded. In the above example if **64** is shaded the **Drum 1 Brake** is ON.

### Digital Output Disable Fault

See Figure 3-53 for following procedure.

The control system is capable of detecting an open or short circuit in most of the system's digital outputs. When **Fault 84-Digital Output Disable** is shown in fault section of Information screen, check for DOD fault in packets 36 through 41:

1. Scroll through packet numbers 36 through 41.
2. Banks 1, 2, and 3 of CAN bus screen should display number 255.
3. If a number less than 255 is displayed in banks 1, 2, and 3, use the Bank Identifier Numbers in Table 3-7 to determine which bit(s) are **off**.
4. Use Table 3-4 - Digital Output Disable, to determine what outputs are not working.
5. Investigate indicated outputs for short to ground, short to shield or other problem.

### Engine Node Status

Engine displays node bus status that is for factory use only. Communication number should be under 64. See engine manufacturers manual for engine fault code information.

### Crane Status

Two crane status banks on the left side display crane errors. Crane status banks should display zero.

The number displayed in the crane status top bank corresponds to the numbered communication errors listed below:

- 0 — Crane status normal.
- 1 — Node-2 is not communicating.
- 2 — Node-3 is not communicating.
- 4 — Node-4 is not communicating.
- 8 — Node-5 is not communicating.
- 16 — Node-7 is not communicating.
- 32 — Bin node is not communicating.

64 — Wireless remote is not communicating.

128 — Engine node is not communicating.

**NOTE:** Bottom crane status bank is not used at this time.

### Crane History

Top crane history bank displays errors since power was cycled.

**NOTE:** Bottom crane history bank is not used at this time.

### Load Link Status

The load link sensor icons indicate the selected load sensor operating status. The selected link sensor is operating normal if blue antenna icon is displayed. The following numbers indicate the type of communication error:

4 — is a calibration fault.

8 — is RF (radio frequency) state. The selected link sensor is not communicating.

64 — is a sign on error.

128 — indicates a RF (radio frequency) communication error.

Drum load link and wireless remote battery status displays:

- 16 and 32 On — 75% and up battery charge.
- 32 On, 16 Off — 50% to 75% battery charge.
- 32 Off, 16 On — 25% to 50% battery charge.
- Both Off — 0% to 25% battery charge.

### Wireless Receiver Status

Wireless receiver status displays boom top and wireless receiver communication. The following numbers indicate the type of communication:

0 — Communication error.

1 — Boom top transmitter working.

2 — Rotating bed receiver working.

### Boom Node Status

The boom node status displays boom top node and jib node communication. Zero is displayed if there is a communication error. Boom data box indicates what boom nodes may be available on the bus:

0 — No communication.

1 — is boom top node.

2 — is luffing jib node.

4 — is fixed jib node.

128 — indicates a node is present that is not currently identified.

***THIS PAGE BLANK***

Table 3-4 Digital Output Disable

CAN Packet Number	Item Description (Node Number)
36-1-1	Cab Base RCL Beacon (N2)
36-1-2	Handle (H4) Rotation Indicator (N2)
36-1-4	Handle (H2) Rotation Indicator (N2)
36-1-8	Front Wiper Switch (N2)
36-1-16	Overhead Wiper Switch (N2)
36-1-32	Handle (H3) Rotation Indicator (N2)
36-1-64	Handle (H1) Rotation Indicator (N2)
36-1-128	Handle Displays; Seat Switch (N2)
36-2-1	Travel 2-Speed; Travel Cruise Switch (N2)
36-2-16	Limit Bypass and Rigging Limit Switches (N2)
36-2-128	Drum Park Switches (N2)
36-3-64	Foot Throttle Output (N2)
37-1-1	Cab Tilt Up Solenoid (N3)
37-1-2	Cab Tilt Down Solenoid (N3)
37-1-4	Rear Rotating Bed Pins - Extend (N3)
37-1-8	Rear Rotating Bed Pins - Retract (N3)
37-1-16	Boom Hinge Pin – Extend (N3)
37-1-32	Boom Hinge Pin – Retract (N3)
37-1-64	Left Side RCL Capacity Alarm (N3)
37-1-128	Load Hoist (Drum 2) LS Motor Control (N3)
37-2-1	Boom/Mast Hoist (Drum 4) Pawl – Out (N3)
37-2-2	Boom/Mast Hoist (Drum 4) Pawl – In (N3)
37-2-4	Left Side Swing/Travel Alarm Solenoid (N3)
37-2-8	Accessory Proportional Relief Solenoid (N3)
37-2-16	Pump 4 Control – Drum 1/Drum 2 (N3)
37-2-32	Pump 4 Control – Drum 1/Drum 2 (N3)
37-2-64	Pump 3 Control – Drum 4/Drum 5 (N3)
37-2-128	Pump 3 Control – Drum 4/Drum 5 (N3)
37-3-1	Pump 6 Control – Drum 2/Drum 1 (N3)
37-3-2	Pump 6 Control – Drum 2/Drum 1 (N3)
37-3-4	Pump 2 Control – Left Travel/Drum 3 (N3)
37-3-8	Pump 2 Control – Left Travel/Drum 3 (N3)
37-3-16	Pump 1 Control – Right Travel/Drum 4 (N3)
37-3-32	Pump 1 Control – Right Travel/Drum 4 (N3)
37-3-64	Pump 5 Control – Swing (N3)
37-3-128	Pump 5 Control – Swing (N3)
38-1-1	Load/Luffing (Drum 3) Brake Sol. (N6)
38-1-2	Load/Luffing (Drum 3) RS Motor Cont. (N6)
38-1-8	Load/Luffing (Drum 3) Pawl In (N6)
38-1-16	Load/Luffing (Drum 3) Pawl Out (N6)
38-1-64	Load Hoist (Drum 1) Brake Solenoid (N6)
38-1-128	Load Hoist (Drum 1) LS Motor Control (N6)
38-2-1	Load Hoist (Drum 1) RS Motor Control (N6)
38-2-2	Load Hoist (Drum 1) Min. Bail Limit Sw. (N6)
38-2-4	Boom Hoist (Drum 5) Brake Solenoid (N6)
38-2-8	Boom Hoist (Drum 5) LS Motor Control (N6)
38-2-16	Boom Hoist (Drum 5) RS Motor Control (N6)
38-2-32	Boom Hoist (Drum 5) Pawl – In (N6)
38-2-64	Boom Hoist (Drum 5) Pawl – Out (N6)
39-1-1	Counterweight Pins Disengage (N4)
39-1-2	Drum 1 to Drum 2 Diversion Solenoid (N4)
39-1-4	Drum 2 to Drum 1 Diversion Solenoid (N4)
39-1-8	Drum 4 to Drum 5 Diversion Solenoid (N4)
39-1-16	Left Travel to Drum 3 Diversion Sol. (N4)
39-1-32	Right Travel to Drum 4 Diversion Sol. (N4)
39-1-64	Boom/Mast Hoist (Drum 4) Brake (N4)
39-1-128	Boom/Mast Hoist (Drum 4) Motor Cont. (N4)
39-2-4	Left Front Jack Solenoid - Extend (N4)
39-2-8	Left Front Jack Solenoid - Retract (N4)
39-2-16	Right Front Jack Solenoid - Extend (N4)
39-2-32	Right Front Jack Solenoid - Retract (N4)
39-2-64	Left Rear Jack Solenoid - Extend (N4)
39-2-128	Left Rear Jack Solenoid - Retract (N4)
39-3-1	Right Rear Jack Solenoid - Extend (N4)
39-3-2	Right Rear Jack Solenoid - Retract (N4)
39-3-4	Rigging Winch - Spool In (N4)
39-3-8	Rigging Winch - Spool Out (N4)
39-3-16	Mast Raising Cylinders – Extend (N4)
39-3-32	Mast Raising Cylinders – Retract (N4)
39-3-64	Front Rotating Bed Pins - Retract (N4)
39-3-128	Front Rotating Bed Pins - Extend (N4)
41-1-1	Boom/Mast Hoist (Drum 4) Motor Cont. (N5)
41-1-2	Engine Hydro-Fan Solenoid (N5)
41-1-8	Right Side RCL Capacity Alarm (N5)
41-1-64	Load Hoist (Drum 2) RS Motor Control (N5)
41-1-128	Load Hoist (Drum 2) Brake Solenoid (N5)
41-2-1	Right Side Swing/Travel Alarm (N5)
41-3-2	Travel Brake Release Solenoid (N5)
41-3-4	Travel Two Speed Solenoid (N5)
41-3-8	Swing Brake Release Solenoid (N5)
41-3-16	Swing Lock – In (N5)
41-3-32	Swing Lock – Out (N5)
41-3-64	Swing Bearing Grease Motor (N5)
41-3-128	Crawler Track Grease Motor (N5)

## Digital Output Reference Chart

Table 3-5 Digital Outputs

CAN Packet Number	Item Description (Node Number)	CAN Packet Number	Item Description (Node Number)
CAN24-1-1	Cab Base RCL Beacon (N2)	CAN26-2-32	Boom Hoist (Drum 5) Pawl – In (N6)
CAN24-1-2	Handle (H4) Rotation Indicator (N2)	CAN26-2-64	Boom Hoist (Drum 5) Pawl – Out (N6)
CAN24-1-4	Handle (H2) Rotation Indicator (N2)	CAN27-1-1	Counterweight Pins Disengage (N4)
CAN24-1-8	Front Wiper Switch (N2)	CAN27-1-2	Drum 1 to Drum 2 Diversion Solenoid (N4)
CAN24-1-16	Overhead Wiper Switch (N2)	CAN27-1-4	Drum 2 to Drum 1 Diversion Solenoid (N4)
CAN24-1-32	Handle (H3) Rotation Indicator (N2)	CAN27-1-8	Drum 4 to Drum 5 Diversion Solenoid (N4)
CAN24-1-64	Handle (H1) Rotation Indicator (N2)	CAN27-1-16	Left Travel to Drum 3 Diversion Sol. (N4)
CAN24-1-128	Handle Displays; Seat Switch (N2)	CAN27-1-32	Right Travel to Drum 4 Diversion Sol. (N4)
CAN24-2-1	Travel 2-Speed; Travel Cruise Switch (N2)	CAN27-1-64	Boom/Mast Hoist (Drum 4) Brake (N4)
CAN24-2-16	Limit Bypass and Jib Up Limit Switches (N2)	CAN27-1-128	Boom/Mast Hoist (Drum 4) Motor Cont. (N4)
CAN24-2-128	Drum Park Switches (N2)	CAN27-2-1	Pump 7 Control – Accessory Pump (N4)
CAN24-3-64	Foot Throttle Output (N2)	CAN27-2-4	Left Front Jack Solenoid - Extend (N4)
CAN25-1-1	Cab Tilt Up Solenoid (N3)	CAN27-2-8	Left Front Jack Solenoid - Retract (N4)
CAN25-1-2	Cab Tilt Down Solenoid (N3)	CAN27-2-16	Right Front Jack Solenoid - Extend (N4)
CAN25-1-4	Rear Rotating Bed Pins - Extend (N3)	CAN27-2-32	Right Front Jack Solenoid - Retract (N4)
CAN25-1-8	Rear Rotating Bed Pins - Retract (N3)	CAN27-2-64	Left Rear Jack Solenoid - Extend (N4)
CAN25-1-16	Boom Hinge Pin – Extend (N3)	CAN27-2-128	Left Rear Jack Solenoid - Retract (N4)
CAN25-1-32	Boom Hinge Pin – Retract (N3)	CAN27-3-1	Right Rear Jack Solenoid - Extend (N4)
CAN25-1-64	Left Side RCL Capacity Alarm (N3)	CAN27-3-2	Right Rear Jack Solenoid - Retract (N4)
CAN25-1-128	Load Hoist (Drum 2) LS Motor Control (N3)	CAN27-3-4	Rigging Winch - Spool In (N4)
CAN25-2-1	Boom/Mast Hoist (Drum 4) Pawl – Out (N3)	CAN27-3-8	Rigging Winch - Spool Out (N4)
CAN25-2-2	Boom/Mast Hoist (Drum 4) Pawl – In (N3)	CAN27-3-16	Mast Raising Cylinders – Extend (N4)
CAN25-2-4	Left Side Swing/Travel Alarm Solenoid (N3)	CAN27-3-32	Mast Raising Cylinders – Retract (N4)
CAN25-2-8	Accessory Proportional Relief Solenoid (N3)	CAN27-3-64	Front Rotating Bed Pins - Retract (N4)
CAN25-2-16	Pump 4 Control – Drum 1/Drum 2 (N3)	CAN27-3-128	Front Rotating Bed Pins - Extend (N4)
CAN25-2-32	Pump 4 Control – Drum 1/Drum 2 (N3)	CAN29-1-1	Boom/Mast Hoist (Drum 4) Motor Cont. (N5)
CAN25-2-64	Pump 3 Control – Drum 4/Drum 5 (N3)	CAN29-1-2	Engine Hydro-Fan Solenoid (N5)
CAN25-2-128	Pump 3 Control – Drum 4/Drum 5 (N3)	CAN29-1-8	Right Side RCL Capacity Alarm (N5)
CAN25-3-1	Pump 6 Control – Drum 2/Drum 1 (N3)	CAN29-1-64	Load Hoist (Drum 2) RS Motor Control (N5)
CAN25-3-2	Pump 6 Control – Drum 2/Drum 1 (N3)	CAN29-1-128	Load Hoist (Drum 2) Brake Solenoid (N5)
CAN25-3-4	Pump 2 Control – Left Travel/Drum 3 (N3)	CAN29-2-1	Right Side Swing/Travel Alarm (N5)
CAN25-3-8	Pump 2 Control – Left Travel/Drum 3 (N3)	CAN29-2-2	Drum 2 Minimum Bail (N5)
CAN25-3-16	Pump 1 Control – Right Travel/Drum 4 (N3)	CAN29-3-2	Travel Brake Release Solenoid (N5)
CAN25-3-32	Pump 1 Control – Right Travel/Drum 4 (N3)	CAN29-3-4	Travel Two Speed Solenoid (N5)
CAN25-3-64	Pump 5 Control – Swing (N3)	CAN29-3-8	Swing Brake Release Solenoid (N5)
CAN25-3-128	Pump 5 Control – Swing (N3)	CAN29-3-16	Swing Lock – In (N5)
CAN26-1-1	Load/Luffing (Drum 3) Brake Sol. (N6)	CAN29-3-32	Swing Lock – Out (N5)
CAN26-1-2	Load/Luffing (Drum 3) RS Motor Cont. (N6)	CAN29-3-64	Swing Bearing Grease Motor (N5)
CAN26-1-8	Load/Luffing (Drum 3) Pawl In (N6)	CAN29-3-128	Crawler Track Grease Motor (N5)
CAN26-1-16	Load/Luffing (Drum 3) Pawl Out (N6)	CAN129-1-1	System Operation Alarm (N1)
CAN26-1-32	Load/Luffing (Drum 3) Min. Bail Limit (N6)	CAN129-1-4	RCL Warning L.E.D. (N1)
CAN26-1-64	Load Hoist (Drum 1) Brake Solenoid (N6)	CAN129-1-32	RCL Caution L.E.D. (N1)
CAN26-1-128	Load Hoist (Drum 1) LS Motor Control (N6)	CAN129-1-64	Displays 1 and 2 (N1)
CAN26-2-1	Load Hoist (Drum 1) RS Motor Control (N6)	CAN129-2-2	Drum Handle Display H1 (N1)
CAN26-2-2	Load Hoist (Drum 1) Min. Bail Limit Sw. (N6)	CAN129-2-8	Drum Handle Display H3 (N1)
CAN26-2-4	Boom Hoist (Drum 5) Brake Solenoid (N6)	CAN129-2-16	Drum Handle Display H4 (N1)
CAN26-2-8	Boom Hoist (Drum 5) LS Motor Control (N6)	CAN129-2-64	Drum Handle Display H2 (N1)
CAN26-2-16	Boom Hoist (Drum 5) RS Motor Control (N6)		



CAN Packet Number	Item Description (Node Number)	CAN Packet Number	Item Description (Node Number)
<b>MAX-ER</b>			
CAN-28-1-1	Counterweight Lift Cylinder Extend (N7)	CAN-28-2-64	Right Front Jacking Cylinder Extend (N7)
CAN-28-1-2	Counterweight Lift Cylinder Retract (N7)	CAN-28-2-128	Right Front Jacking Cylinder Retract (N7)
CAN-28-1-64	Telescopic Beam Cylinder Extend (N7)	CAN-28-3-1	Right Rear Jacking Cylinder Extend (N7)
CAN-28-1-128	Telescopic Beam Cylinder Retract (N7)	CAN-28-3-2	Right Rear Jacking Cylinder Retract (N7)
CAN-28-2-1	Telescopic Beam Hinge Pin In (N7)	CAN-28-3-4	Right Wheel Steering Clockwise (N7)
CAN-28-2-2	Telescopic Beam Hinge Pin Out (N7)	CAN-28-3-8	Left Wheel Steering Counter-Clock. (N7)
CAN-28-2-4	Left Front Jacking Cylinder Extend (N7)	CAN-28-3-16	Right Wheel Steering Clockwise (N7)
CAN-28-2-8	Left Front Jacking Cylinder Retract (N7)	CAN-28-3-32	Right Wheel Steering Counter-Clock. (N7)
CAN-28-2-16	Left Rear Jacking Cylinder Extend (N7)	CAN-28-3-64	Left Wheel Brakes (N7)
CAN-28-2-32	Left Rear Jacking Cylinder Retract (N7)	CAN-28-3-128	Right Wheel Brakes (N7)

## Digital Input Reference Chart

Table 3-6 Digital Inputs

CAN Packet Number	Item Description (Node Number)	CAN Packet Number	Item Description (Node Number)
CAN43-1-1	Handle (H4) Direction Signal (N2)	CAN129-3-4	Load Hoist (Drum 2) Park Switch (N1)
CAN43-1-2	Handle (H3) Direction Signal (N2)	CAN129-3-16	Load Hoist (Drum 2) Park Switch (N1)
CAN43-1-4	Swing Holding Brake Switch (N2)	CAN129-3-64	Travel Park Switch (N1)
CAN43-1-8	Swing Handle Direction Signal (N2)	CAN129-3-128	Cab Tilt Up Switch (N1)
CAN43-2-1	Left Track Direction Signal (N2)	CAN129-4-1	Display Enter Switch (N1)
CAN43-2-2	Handle (H1) Direction Signal (N2)	CAN129-4-2	Confirm Switch (N1)
CAN43-2-4	Handle (H2) Direction Signal (N2)	CAN129-4-4	Limit Bypass Switch (N1)
CAN43-2-8	Right Track Direction Signal (N2)	CAN129-4-8	Display Scroll Up Switch (N1)
CAN45-1-4	Super Charge Pressure Switch (N3)	CAN129-4-16	Jib Up Limit Bypass Switch (N1)
CAN45-1-64	Hydraulic Charge Filter Alarm Switch (N3)	CAN129-4-32	Display Scroll Down Switch (N1)
CAN45-1-128	Hydraulic Return Filter Alarm Switch (N3)	CAN129-4-64	Travel Cruise Switch - On (N1)
CAN47-1-8	Load/Luffing (Drum 3) Minimum Bail Limit (N6)	CAN129-5-1	Seat Switch (N1)
CAN47-1-128	Load Hoist (Drum 1) Minimum Bail Limit (N6)	CAN129-5-2	Cab Tilt Up Switch (N1)
CAN51-1-64	Left Front Jacking Cylinder Limit (N7)	CAN129-5-8	Air Conditioning Compressor Clutch On (N1)
CAN51-1-128	Left Rear Jacking Cylinder Limit (N7)	CAN129-5-32	Engine Run/Start (N1)
CAN55-1-8	Maximum Boom Angle Limit Switch (N5)	CAN129-5-128	Boom/Mast Hoist (Drum 4) Park Switch (N1)
CAN55-1-128	Drum 2 Minimum Bail Limit (N5)	CAN129-6-4	Display 1 (N1)
CAN86-6-64	Block Up Limit Luffing/Fixed Jib Upper Pt. (N21)	CAN129-6-8	Travel 2-Speed Switch (N1)
CAN86-6-128	Block Up Limit Luffing Jib Lower Point (N21)	CAN129-6-16	Display 2 (N1)
CAN112-6-64	Block Up Limit Boom Upper Point (N20)	CAN129-6-32	Swing Park Switch - On (N1)
CAN112-6-128	Block Up Limit Boom Lower Point (N20)	CAN129-6-64	Display Exit Switch (N1)
CAN129-3-1	Boom Hoist (Drum 5) Park Switch (N1)	CAN129-6-128	Load/Luffing (Drum 3) Park Switch (N1)

Table 3-7 Bank Identifier Numbers

	1	2	4	8	16	32	64	128
1								
2								
3								
4								
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								

	1	2	4	8	16	32	64	128
44								
45								
46								
47								
48								
49								
50								
51								
52								
53								
54								
55								
56								
57								
58								
59								
60								
61								
62								
63								
64								
65								
66								
67								
68								
69								
70								
71								
72								
73								
74								
75								
76								
77								
78								
79								
80								
81								
82								
83								
84								
85								
86								

	1	2	4	8	16	32	64	128
87								
88								
89								
90								
91								
92								
93								
94								
95								
96								
97								
98								
99								
100								
101								
102								
103								
104								
105								
106								
107								
108								
109								
110								
111								
112								
113								
114								
115								
116								
117								
118								
119								
120								
121								
122								
123								
124								
125								
126								
127								
128								
129								

Dark shaded boxes indicate ON; white boxes OFF.

Table 3-7 Bank Identifier Numbers (continued)

	1	2	4	8	16	32	64	128
130								
131								
132								
133								
134								
135								
136								
137								
138								
139								
140								
141								
142								
143								
144								
145								
146								
147								
148								
149								
150								
151								
152								
153								
154								
155								
156								
157								
158								
159								
160								
161								
162								
163								
164								
165								
166								
167								
168								
169								
170								
171								
172								

	1	2	4	8	16	32	64	128
173								
174								
175								
176								
177								
178								
179								
180								
181								
182								
183								
184								
185								
186								
187								
188								
189								
190								
191								
192								
193								
194								
195								
196								
197								
198								
199								
200								
201								
202								
203								
204								
205								
206								
207								
208								
209								
210								
211								
212								
213								
214								
215								

	1	2	4	8	16	32	64	128
216								
217								
218								
219								
220								
221								
222								
223								
224								
225								
226								
227								
228								
229								
230								
231								
232								
233								
234								
235								
236								
237								
238								
239								
240								
241								
242								
243								
244								
245								
246								
247								
248								
249								
250								
251								
252								
253								
254								
255								

Dark shaded boxes indicate ON; white boxes OFF.

## Camera Screen (Optional)

The camera screen (not shown) displays camera options and items for selecting and operating. The camera option includes up to three different cameras to monitor drum spooling and the area behind the crane.

Use Select buttons to select the camera screen on the Menu screen. Press Enter button to access the screen.

Use Select buttons to select desired camera view.

Press Exit button until Menu screen appears.

## Pressure Test and Calibration Screen

The Pressure Test and Calibration Screen (see Figure 3-54) is used to initiate and monitor the four hydraulic test and calibration procedures described in this section.

The screen shows the pump commands and pressure levels for all primary crane functions. Use the data box in the upper left corner of the screen to select and start a specific test or calibration procedure.

Pressure Test and Calibration screen operates on two **levels**.

**Level 1** — Test data box highlighted blue.

**Level 2** — Test data box highlighted red. Use Select buttons to choose the test or calibration procedure.

All test and calibration procedures must be run at a particular engine speed. If a test is started at the wrong speed, the appropriate prompt shown below appears in the data box and the procedure is aborted.

### Engine Off

The yellow engine pressure **0** icon indicates that the test must be run with engine off.



### Engine Low Idle

The yellow engine pressure **down arrow** icon indicates that the test must be run with engine at low idle.



### Engine High Idle

The yellow engine pressure **up arrow** icon indicates that the test must be run with engine at high idle.



The yellow open circuit icon indicates a circuit fault that must be serviced immediately.



The yellow short to ground icon indicates a circuit fault that must be serviced immediately.



### Pressure Sender Test

See Figure 3-54 for following procedure.

The pressure sender test calculates the zero-pressure output level for each pressure sender. Pressure sender null (0) must be within 0.65 to 1.35 volts.


Perform this test when:

- A new pressure sender is installed.
- A new controller node that monitors pressure senders is installed.
- A new master node or master node software is installed.
- Pressure readings are noticeably in error.


Be aware that if there is any residual pressure in the system during the calibration process, the display pressure reading in the cab may not reflect actual system pressure. See Note on page 3-59.

Test pressure senders as follows:

1. Stop engine and turn ignition switch to **run** position. Push Enter button to go to Pressure Test and Calibration screen from Menu screen.
2. Press Enter button to go to **level 2**. Use Select buttons to show PRESSURE SENDER icon in data box.
3. Press Confirm button to start test.
4. Test starts and percent of completion is displayed in data box.
5. When test is complete, pressure sender icon reappears in data box.



Pressure senders must show a signal within a specified range during this test. Any sender signal out of this range is highlighted yellow. Troubleshoot failed senders to determine cause of fault.



**NOTE:** The cause of a failed pressure sender test or faulty display pressure reading may not be the pressure sender. The cause of the fault could be trapped air or hydraulic pressure in the system during the pressure sender test.

Before replacing a pressure sender, do the following:

- Perform pressure sender test.
- Attach an accurate hydraulic pressure gauge to the quick-coupler at the suspect pressure sender (see Section 2 of Service Manual).
- If pressure appears on the gauge, bleed the corresponding system so the gauge reads zero pressure.
- Repeat pressure sender test and check pressure on the display with the engine running at idle — the display reading and the gauge reading should be the same.
- Before replacing a pressure sender, check the signal voltage at the sender. It should be 1.00 volt against ground at 0 psi.

### Control Calibration

See Figure 3-55 for following procedure.


Control calibration calculates the pump threshold command level for all drum and swing functions. The allowable range is 5 to 25% pump command signal for the hoist pumps and 2.5 to 20% in each direction for the swing pump(s).

Perform this calibration when:


- A new pump or motor is installed in a drum or swing function.
- A new master node or master node software is installed.
- Operation indicates threshold is in error.
- Excessive handle motion or time required to initiate motion.

- Inability to smooth start motion.

Calibrate controls as follows:

1. Apply **all** park brakes and start engine. Set engine speed at **high idle**.
2. Press Enter button to go to Pressure Test and Calibration screen from Menu screen.
3. Press Enter button to go to **level 2**. Use Select buttons to show CONTROL CALIBRATION icon in data box. 
4. Press Confirm button to start test.
5. Calibration starts and percent of completion is displayed in data box.
6. When calibration is complete, control calibration icon reappears in data box.

Pump threshold command levels must be within a specified range during this test. Any pump requiring a threshold command level outside this range is highlighted yellow. Troubleshoot failed circuit to determine cause of fault.



### High Pressure Test

See Figure 3-56 for following procedure.

The high pressure test checks the ability of all primary crane functions to reach and hold high pressure. This test generally is used only as a shop procedure on new cranes. It can also be used as a quick way to test hydraulic components in primary hydraulic circuits.



### WARNING

#### High Pressure Hazard!


This test generates maximum pressure in the main hydraulic circuits. Defective brakes may allow unintended motion during test. Move crane to an area where such motion is not a hazard.

We recommend an observer to monitor functions the operator cannot see.

Be prepared to stop engine if unintended motion occurs.

Test high pressure as follows:

1. Apply **all** park brakes and start engine. Set engine speed at **high idle**.
2. Press Enter button to go to Pressure Test and Calibration screen from Menu screen.
3. Press Enter button to go to **level 2**. Use Select buttons to show HIGH PRESSURE icon in data box.



4. Press Confirm button to start test.
5. Test starts and percent of completion is displayed in data box.
6. When test is complete, high pressure icon reappears in data box.
7. Maximum pressure levels must be reached within a specific pump command range during this test. Any pump requiring a command in excess of this range or failed completely to generate maximum pressure is highlighted yellow. Troubleshoot failed circuit to determine cause of fault.




FIGURE 3-56


**Charge Pressure Test**

See Figure 3-57 for following procedure.

The charge pressure test checks the ability of all primary crane functions to build proper charge pressure. This test generally is used only as a shop procedure on new cranes. It can also be used as a quick way to test hydraulic components in primary hydraulic circuits. Charge pump pressure must be within 275 to 400 psi (19 to 27 bar).


Test charge pressure as follows:

1. Apply **all** park brakes and start engine. Set engine speed at **low idle**.
2. Press Enter button to go to Pressure Test and Calibration screen from Menu screen.
3. Press Enter button to go to **level 2**. Use Select buttons to show LOW PRESSURE icon in data box.
4. Press Confirm button to start test.
5. Test starts and percent of completion is displayed in data box.
6. When test is complete, charge pressure icon reappears in data box.



Charge pressure levels must be within a specified range during this test. Any pump that failed to maintain charge

pressure within a specified range is highlighted yellow. Troubleshoot failed circuit to determine cause of fault.



## WIND CONDITIONS

Wind adversely affects lifting capacity and stability as shown in Figure 3-58. The result could be loss of control over the load and crane, even if the load is within the crane's capacity.



### WARNING

#### Tipping Crane Hazard!

Judgment and experience of qualified operators, job planners, and supervisors must be used to compensate for affect of wind on lifted load and boom by reducing ratings or operating speeds, or a combination of both.

Failing to observe this precaution can cause crane to tip or boom and/or jib to collapse. Death or serious injury to personnel can result.

---

Wind speed (to include wind gusts) must be monitored by job planners and supervisors.

The wind speed at boom or jib point can be greater than wind speed at ground level. Also be aware that the larger the sail area of the load, the greater the wind's affect on the load.

As a general rule, ratings and operating speeds must be reduced when:


***Wind causes load to swing forward past allowable operating radius or sideways past either boom hinge pin.***

For wind conditions specific to this crane, see Wind Conditions Chart at end of this section or, if applicable, see wind conditions in Capacity Charts provided with crane and attachments.



A910


Forward stability is affected by wind on the rear of the boom. Wind applies a force to the boom and load that adds to the crane's overturning moment. This action has the same effect as adding load to the hook.



The wind's affect on the rear of the load increases load radius. This condition can result in an overload hazard, possibly causing the crane to tip or the boom to collapse.

To avoid this hazard, reduce operating speeds and load (see Wind Conditions Chart at end of this section or see wind conditions in Capacity Charts if applicable).


3



Backward stability is affected by wind on the front of the boom. This condition is especially dangerous when the boom is at or near the maximum angle when operating without load.

Wind forces on the front of the boom reduce the normal forward tipping effect of the boom. The crane can tip or the boom can collapse if this condition is not avoided.

The boom can buckle and collapse if the load contacts the boom.



Boom strength is affected the most when the wind acts on the side of the boom.

The wind's affect on the side of the load can cause the load to swing out past the boom hinge pin. This condition can result in excessive side load forces on the boom, possibly causing the crane to tip or the boom to collapse.

To avoid this hazard, reduce operating speeds and load (see Wind Conditions Chart at end of this section or see wind conditions in Capacity Charts if applicable).

FIGURE 3-58

## PREPARATION FOR COLD WEATHER

### Crane Limitations

The static load carrying limitations of the steels used in Manitowoc cranes is not affected by cold weather. Manitowoc's capacity charts are acceptable for use in cold weather.

Dynamic loads (impact and shock) can affect the steels used in Manitowoc cranes when operating in cold weather. Dynamic loads are created by traveling, sudden application and release of load, and duty-cycle operations.

To prevent possible damage to the crane and its attachment when operating during cold weather Manitowoc recommends:

- At -5 to -22°F (-21 to -30°C) — Avoid impact or shock loading of crane and attachment. Operations involving hydraulic cranes should be conducted with regard to potential failure of hydraulic components. For critical lifts, crane should be de-rated 25%.
- At -23 to -40°F (-31 to -40°C) — De-rate crane by 40% for all lift operations. Halting all lifts should be considered. Duty-cycle operation is prohibited.
- Below -40°F (-40°C) — All operation (lift and duty-cycle) is prohibited except in extreme emergencies, and then only with approval from a competent engineer who has de-rated the crane accordingly.

### Wire Rope

Wire rope manufacturers indicate that wire rope will not become brittle in temperatures down to -30°F (-34°C). Lubrication may be a problem during extreme cold weather as normal wire rope lubricants may harden and chip off leaving the rope without lubrication.

Consult your wire rope supplier for recommended cold-weather lubricants.

### Cold Weather Starting Aid

Engine startup at temperatures below 40°F (4°C) requires the use of a cold weather starting aid.



#### **DANGER**

#### **Engine Explosion Hazard!**

The crane engine has an air intake pre-heater, do not spray any combustible starting aid (ether) into air intake.

Pre-heater will ignite ether causing a severe explosion and/or burns.

---

### Coolant and Oil Pan Heaters

A 120 volt coolant and oil pan heater can be installed in the engine. The heaters use an electric heating element to heat the coolant and oil inside the engine when the crane is idle. Each heater has an extension cord for connecting to an owner furnished electric power supply. The coolant heater must be capable of maintaining the engine's coolant and oil temperatures between 40 to 50°F (4 to 10°C). Contact the nearest engine distributor for availability and installation of the heaters.

***Engine heaters must be unplugged when engine is running to prevent cooling system from overheating.***

### Cooling System

The cooling system must be kept full and be protected from freezing at the lowest expected ambient temperature. See the engine manual for antifreeze recommendations.

A mixture of 40% antifreeze and 60% water provides freeze protection to -35°F (-37°C). A mixture of 60% antifreeze and 40% water provides freeze protection to approximately -60°F (-51°C). 100% antifreeze will freeze at -10°F (-23°C).

### Battery

To provide maximum cranking power and to prevent the battery from freezing, it must be kept fully charged (1.26 to 1.28 specific gravity) and warm when the crane is idle during cold weather.

It is recommended that the battery be stored indoors or heated with a battery heater when the crane is idle.

Be aware that:

- A battery with a 50% charge freezes at -16°F (-27°C). A battery with a 100% charge freezes at -70°F (-57°C).
- A battery with a 100% charge retains only 40% of its cranking power at 0°F (-18°C). At -20°F (-29°C), the same battery retains only 18% of its cranking power.

### Engine Oil

See engine manufacturer's manual for recommendations.

### Fuel Oil

See engine manufacturer's manual for recommendations.

### Gear Oil

#### **Hydraulic Cranes**

Use a gear oil which meets MIL-L-2105C specification or API-GL-5 classification. Change to one of the following viscosities when the corresponding temperature range will be encountered:

- 75W-90 below: -10°F (-23°C).

- 80W-90 above: -10 to 100°F (-23 to 38°C)
- 85W-140 above: 100°F (38°C)

## Hydraulic Oil

### General

Optional thermostatically controlled heaters (120 or 240 volt) can be installed in the hydraulic tank to aid in cold-weather startup.

The heaters are designed to keep the oil temperature 30°F (17°C) warmer than ambient air temperature. Each heater has an extension cord for connecting to an owner furnished electric power supply.

***Hydraulic tank heaters must be unplugged when engine is running to prevent hydraulic system from overheating.***

Change the oil in the hydraulic system to ISO Grade 15 when the expected ambient temperature will remain at 32°F (0°C) or below.

Change the oil in the hydraulic system to ISO Grade 46 when the expected ambient temperature will remain above 32°F (0°C).

## COLD WEATHER HEATER PACKAGE

### General

The optional cold weather heater package is a 240 volt AC single phase power supply. The heaters preheat critical machinery and lubricant sumps during cold weather shutdown.

The 240 volt receptacle and circuit breaker panel is mounted on the rear of operator's cab (see Figure 3-59).

When operated in an arctic climate — outside temperature continuously below 0°F (-18°C) and -30°F (-34°C) — the crane should be equipped with the heaters identified in this section and lubricated with the lubricants listed in Section 5.

### CAUTION

#### Machinery Damage!

Operating in an arctic climate without heaters can damage machinery during cold weather startup due to lack of lubrication.

Heater package described in this section may not provide adequate protection when operating below -30°F (-34°C). Contact Manitowoc distributor for recommendations.

#### Hydraulic Pump Damage!

To prevent damage to pumps, warm hydraulic oil to 60°F (16°C) minimum before operating crane in an arctic climate.

## Heaters

The heaters operate on 240 volt AC single phase electrical power supplied by a external power supply. The package includes the following heaters:

- Engine coolant (4000 watt)
- Engine oil sump (300 watt)
- Hydraulic oil tank (four 500 watt or one 2000 watt)
- Battery pad (two 75 watt, 120 volt or two 75 watt, 240 volt)
- Right control console (125 watt)

## Turning Heaters On

1. The external power supply must be disconnected. Then proceed as follows:
  - a. Check that main circuit breaker and each heater circuit breaker is off (see Figure 3-59).
  - b. Check that external power supply source is off.



### WARNING

#### Electrocution Hazard!

Severe electric shock can cause death or serious injury. Crane owner/user must make provisions for turning off electrical power supply before connecting power supply cord to crane.

- c. Connect external power supply cord to receptacle at rear of operator's cab
- d. Turn on external power supply.
- e. Turn on main circuit breaker.
- f. Turn on each heater circuit breaker.

## Turning Heaters Off

1. Turn off main circuit breaker.
2. Turn off each heater circuit breaker.
3. Perform remaining steps only if power supply cord will be disconnected or electrical system is being serviced:
  - a. Turn off external power supply.
  - b. Unplug power supply cord from crane.

## CIRCUIT BREAKERS

See Section 3 in the Service Manual for identification and location of circuit breakers used to protect crane's electric circuits.

Item	Description
1	240 Volt Receptacle
2	Main Circuit Breaker
3	Engine Coolant Heater
4	Engine Oil Heater
5	Hydraulic Reservoir Heaters Left Side (2) or Top (1)
6	Hydraulic Reservoir Heaters Right Side (2)
7	Cab Front Console Heater
8	Battery Pad Heaters (2)
9	Circuit Breaker Load Center
9a	Circuit Breaker Decal (inside load center)




FIGURE 3-59

## SECTION 4

### SET-UP AND INSTALLATION

#### TABLE OF CONTENTS

Rigging Drawings . . . . .	4-1
Liftcrane Mast Capacities . . . . .	4-1
Optional Attachments . . . . .	4-1
General Safety . . . . .	4-1
Crane Orientation . . . . .	4-1
Self-Erecting Equipment . . . . .	4-1
Assist Crane Requirements . . . . .	4-2
Assembly and Disassembly Notes . . . . .	4-2
Assembly And Disassembly Area . . . . .	4-2
Accessing Parts . . . . .	4-2
Crane Weights . . . . .	4-2
Handling Components . . . . .	4-2
Retaining Connecting Pins . . . . .	4-2
Cold Weather Mast Operation . . . . .	4-3
Shipping Crane Components . . . . .	4-5
Operating Controls . . . . .	4-5
Pre-Start Checks . . . . .	4-7
Engine . . . . .	4-7
Gear Boxes . . . . .	4-7
Hydraulic System . . . . .	4-7
Crane Assembly . . . . .	4-7
Install Exhaust Pipes . . . . .	4-7
Remove Rotating Bed from Trailer . . . . .	4-9
Remove Carbody and Adapter Frame from Trailer . . . . .	4-13
Lower Crane onto Carbody Pedestals . . . . .	4-16
Connect Hydraulic Hoses and Electric Cables . . . . .	4-16
Raise Live Mast To Operating Position . . . . .	4-19
Install Assembly Block . . . . .	4-21
Install Crawlers . . . . .	4-21
Handling Crawlers . . . . .	4-23
Install First Crawler . . . . .	4-25
Install First Crawler (continued) . . . . .	4-27
Install Second Crawler . . . . .	4-27
Install Crawler Platforms . . . . .	4-29
Past Production . . . . .	4-29
Past Production . . . . .	4-29
Install Crawler Stairways . . . . .	4-29
Install Counterweight . . . . .	4-31
Install Carbody Counterweight . . . . .	4-31
Install Crane Counterweight . . . . .	4-33
Assemble Boom . . . . .	4-35
Install Boom Butt . . . . .	4-35
Remove Assembly Block . . . . .	4-39
Connect Boom Butt to Boom . . . . .	4-39
Crane Disassembly . . . . .	4-41
Lower Boom . . . . .	4-41
Disconnect Boom Butt from Boom . . . . .	4-41
Install Assembly Block . . . . .	4-42
Remove Boom Butt . . . . .	4-42
Disassemble Boom . . . . .	4-43
Remove Counterweight . . . . .	4-43

Remove Crane Counterweight . . . . .	4-43
Remove Carbody Counterweight . . . . .	4-44
Remove Crawler Stairways . . . . .	4-44
Store Crawler Platforms . . . . .	4-44
Past Production . . . . .	4-44
Past Production . . . . .	4-44
Remove Crawlers . . . . .	4-44
Remove First Crawler . . . . .	4-45
Remove Second Crawler . . . . .	4-45
Remove Assembly Block . . . . .	4-45
Lower Live Mast To Shipping Position . . . . .	4-46
Disconnect Hydraulic Lines and Electric Cables . . . . .	4-46
Raise Crane Off Carbody Pedestals . . . . .	4-46
Place Carbody and Adapter Frame on Trailer . . . . .	4-46
Remove Rotating Bed from Trailer . . . . .	4-47
Remove Exhaust Pipes . . . . .	4-47
Boom Ladder Assembly . . . . .	4-49
General . . . . .	4-49
Removing Ladders from Boom Butt . . . . .	4-49
Installing Ladders on Boom Inserts . . . . .	4-49
Storing Ladders in Boom Butt . . . . .	4-49
Boom Rigging . . . . .	4-50
Assist Crane Requirements . . . . .	4-50
Blocked Crawler . . . . .	4-50
Handling Components . . . . .	4-50
Boom Assembly Drawing . . . . .	4-50
Identifying Boom Sections and Straps . . . . .	4-50
Assemble Boom Sections . . . . .	4-53
Connect Boom Straps . . . . .	4-55
Install Intermediate Suspension . . . . .	4-55
Install Standard Upper Boom Point . . . . .	4-57
Install Extended Upper Boom Point . . . . .	4-57
Install Load Line . . . . .	4-62
Connect Boom Wiring . . . . .	4-62
Perform Pre-Raising Checks . . . . .	4-62
Boom Removal . . . . .	4-62
Wire Rope Installation . . . . .	4-66
Wire Rope Storage . . . . .	4-66
Removing Wire Rope from Shipping Reel . . . . .	4-66
Seizing and Cutting Wire Rope . . . . .	4-66
Anchoring Wire Rope to Drum . . . . .	4-67
Drum Guards . . . . .	4-67
Winding Wire Rope onto Drum . . . . .	4-69
Anchoring Wire Rope to Wedge Socket . . . . .	4-71
Anchoring Wire Rope to Button Socket . . . . .	4-71
Breaking in Wire Rope . . . . .	4-71
Drum Kicker Adjustment . . . . .	4-72
General . . . . .	4-72
Adjustment . . . . .	4-72
Pad Eye Usage for Wire Rope Reeving . . . . .	4-72
General . . . . .	4-72
Safety . . . . .	4-72
Rigging Winch Operation . . . . .	4-74
Selecting Rigging Winch Mode . . . . .	4-74
Operating Rigging Winch . . . . .	4-74
Free-Wheel Operation . . . . .	4-74
Power Operation . . . . .	4-74

Reeving – Load Block . . . . .4-76

Load Block Identification . . . . .4-76

Wire Rope Specifications . . . . .4-76

Wire Rope Installation . . . . .4-76

Duplex Hook . . . . .4-76

Guide Sheaves and Drums . . . . .4-76

Load Block Reeving . . . . .4-76

Reeving – Live Mast . . . . .4-82

General . . . . .4-82

Wire Rope Specification . . . . .4-82





## SECTION 4

### SET-UP AND INSTALLATION

#### RIGGING DRAWINGS

For boom and jib rigging drawings that apply to your crane, see the end of this section.

#### LIFTCRANE MAST CAPACITIES

Lifting capacities for the live mast are located at the end of this section.

#### OPTIONAL ATTACHMENTS

If applicable, instructions for optional attachments that apply to your crane are located at the end of this section.

#### GENERAL SAFETY

To prevent accidents that can result in death or injury during crane assembly and disassembly, comply with following general safety information and with specific safety information contained in assembly and disassembly steps.



#### WARNING

##### Avoid Death or Serious injury!

Read and understand setup and installation instructions in this section before attempting to assemble or disassemble crane.



#### WARNING

##### Tipping/Overload Hazard!

Avoid tipping crane over or collapsing live mast:

- Assemble and disassemble crane on a firm, level, uniformly supporting surface.
- Do not exceed swing limits and mast lifting capacities given in Table 4-2.
- Do not allow crane to go more than 3° out of level when operating rotating bed jacks.



#### WARNING

##### Avoid Falling Off Crane and Boom!

It is necessary to climb onto crane and boom during assembly and disassembly steps.

Use sturdy owner furnished ladders or an approved personnel hoist to gain access to areas which cannot be reached from ladders or steps provided with crane.



#### WARNING

##### Moving Parts/Pinch Points!

Avoid death or crushing injury during crane assembly and disassembly:

- Assembly personnel — take every precaution to prevent injury when working near moving parts.
- Maintain communication between operator and assemblers to avoid accidents.
- Do not raise or lower live mast until all personnel are off crane.
- Keep unauthorized personnel well clear of crane.



#### WARNING

##### Falling Load Hazard!

To prevent lifting equipment from failing and load from dropping, crane owner/user shall verify following prior to each lift:

- All lifting equipment (shackles, hooks, slings, blocks) have been properly maintained and are safe for use.
- All lifting equipment has a capacity equal to or greater than load to be lifted.

#### CRANE ORIENTATION

The terms RIGHT, LEFT, FRONT, REAR used in this section refer to the operator's right, left, front, and rear sides when seated in the operator's cab looking forward with the crawler motors to the rear.

#### SELF-ERECTING EQUIPMENT

The 16000 is equipped with the following self-erect components for assembly and disassembly:

1. Rotating bed jacks with pads for lifting the rotating bed assembly onto and off the trailer.
2. Carbody pedestals for supporting the carbody (with rotating bed) during crawler assembly.
3. Hydraulically actuated arms for raising and lowering the live mast from and to the transport position.
4. Live mast which serves as a boom to install the crane's crawlers, carbody counterweights, and boom butt and to handle other components as required.
5. 45 USt (41 t) load block and 4-leg sling with hooks for handling parts.

## ASSIST CRANE REQUIREMENTS

An assist crane is required for handling and installing the following components:

- Crane (rotating bed) counterweight tray and boxes.
- Catwalks and steps.

See Crane Weights in Section 1 of this Manual for weights of components.

## ASSEMBLY AND DISASSEMBLY NOTES

The crane, boom, and jib shall be assembled and disassembled by experienced personnel trained in erection and operation of construction cranes.

Read and become thoroughly familiar with the instructions in the applicable capacity charts, in this section, and in the rigging drawings at the rear of this section before attempting to assemble, operate, or disassemble the crane.

*Contact your Manitowoc distributor for assistance if any procedure is not fully understood.*

## ASSEMBLY AND DISASSEMBLY AREA

Select an assembly/disassembly area that has a firm, level, uniformly supporting surface. Make sure the area is large enough to accommodate the crane and the selected boom length, movement of trucks with trailers, and movement of an assist crane.

Set jack pads and carbody pedestals on a flat, firm foundation that will support the load placed on them. See Table 4-1 for loadings.

Do not set the jack pads or carbody pedestals in holes, on rocky ground, or on extremely soft ground.

If necessary, use wood blocking or steel plates under the jack pads and carbody pedestals to properly distribute loading. The wood blocking or steel plates must be:

- Free of defects.
- Strong enough to prevent being crushed or bent.
- Sufficient length and width to prevent settling under load.

*Contact Manitowoc Crane Care at factory for ground bearing information.*

**Table 4-1**  
**Jack and Pedestal Load Data**

Maximum load on each jack — 78,000 (35 380 kg)
Jack pad diameter — 24 in (610 mm)
Jack pad weight — 60 lb (27 kg)
Maximum load on each carbody pedestal — 103,000 lb (46 720 kg)
Carbody pedestal diameter — 30-1/2 in (775 mm)
Carbody pedestal assembly weight — 128 lb (58 kg)

## ACCESSING PARTS

Some parts of the crane, boom, and jib cannot be reached from the ground. Take necessary precautions to prevent slipping and/or falling off the crane or boom during assembly, disassembly, maintenance, or other work. ***Falling from any height could result in serious injury or death.***

Owner/user must provide workers with approved ladders or aerial work platforms to access those areas of the crane, mast, boom, and jib that cannot be reached from ground or from steps, ladders, catwalks, and platforms provided by Manitowoc.

*Adhere to local, state, and federal regulations for handling personnel and personnel fall protection.*

***Do not use top of mast or boom as a walkway.***

Optional boom ladders (stored in boom first 40 ft [12 m] insert) are available from Manitowoc. If your crane has ladders, see the instructions later in this section.

## CRANE WEIGHTS

See Crane Weights in Section 1 for overall weight of the crane and individual weights of components.

## HANDLING COMPONENTS

The major components are equipped with lifting lugs which are identified in the assembly and disassembly steps.

When lifting lugs are not provided, use nylon lifting slings. If wire rope or chain slings are used, install protective covering (such as sections of rubber tire) between slings and component being lifted.

*It is owner's/user's responsibility to ensure that all lifting slings, hooks, and shackles are in safe working order and capable of handling loads applied to them.*

## RETAINING CONNECTING PINS

Connecting pins are retained in various ways:

- Snap pins.
- Quick-release pins.
- Cotter pins.

- Keeper plates with cap screws and lock washers.

*Do not operate crane until all connecting pins are installed and properly retained.*

## COLD WEATHER MAST OPERATION

The live mast, live mast cylinders, and live mast arms can be damaged when attempting to lower the live mast (to rear) during cold weather.

Do not attempt to lower the live mast with the mast hoist during cold weather until the following steps have been performed:

- Temperature of hydraulic oil warmed up to at least 60°F (16°C).
- Mast cylinders fully extended and retracted twice to fill cylinders with warm oil.

### Component Identification

A10740-14

Item	Description
1	Live Mast
2	Handling Pendant (Mast and Boom Butt)
3	Load Block — 45 USt (41 t)
4	4-Leg Chain Sling
5	Operator's Cab
6	Crawler Assembly
7	Carbody Counterweight (both ends)
8	Rotating Bed Adapter Frame (with Carbody)
9	Live Mast Assist Arm (1 each side)
10	Rotating Bed Jack (2 at Front)
11	Rotating Bed
12	Rotating Bed Jack (2 at Rear)
13	Boom Hoist
14	Crane (Rotating Bed) Counterweight
15	Boom Hoist Wire Rope




FIGURE 4-1


**Table 4-2**  
**Operating Limitations**

*See Liftcrane Mast Capacities Chart at end of this section for detailed lifting capacities.*

Crane Configuration	Swing	Max Capacity	Max Radius
<ul style="list-style-type: none"> <li>Crane on pedestals (rotating bed, adapter frame, and carbody).</li> <li>Live mast raised or lowered (NOTE 1).</li> <li>No assembly block.</li> <li>No crawlers.</li> <li>No counterweight.</li> </ul>	<b>NO!</b>		
<ul style="list-style-type: none"> <li>Crane on pedestals (rotating bed, adapter frame and carbody).</li> <li>Live mast in operating range (see Figure 4-12).</li> <li>Assembly block installed (NOTE 2).</li> <li>No crawlers installed (handling 1st crawler).</li> <li>No counterweight.</li> </ul>	10° Either Side of Center See Figure 4-13, View E	75,000 lb (34 019 kg)	20 ft (6,1 m)
<ul style="list-style-type: none"> <li>Crane on pedestals.</li> <li>First crawler installed and <b>resting on ground</b>.</li> <li>No counterweight.</li> </ul>	180° 2nd Crawler Can be Lifted Over Same Side as 1st Crawler		
<ul style="list-style-type: none"> <li>Crane on crawlers.</li> <li>Counterweight installed or removed.</li> <li>Handling loads with live mast.</li> </ul>	360°		

**NOTE 1** Maximum mast angle = 156°.

**NOTE 2** Chain sling and 3-part line required.



## SHIPPING CRANE COMPONENTS

To ensure the crane's self-erecting system can load and unload the carbody and upperworks assembly, the trailer must meet the specifications given in Figure 4-2.


It is the owner/user's responsibility to ensure the following:

- That all trailer loads comply with local, state, and federal transportation requirements.
- ***That all crane components are properly blocked and secured so they cannot shift or fall off trailers.***
- To avoid damage to components:

Use nylon tie-downs to secure components as shown in Figure 4-3, View A.

If chain tie-downs are used, install protective covering (such as sections of rubber tire) between the chain and component being secured as shown in Figure 4-3, View B.

When securing boom sections, wrap tie-downs over chords — never over lacings. Keep tie-downs as close to blocking as possible (View A) to prevent bending the chords.



## OPERATING CONTROLS

To use the live mast as a boom for self-erecting the 16000, the Liftcrane Mast Capacities Chart must be selected in the Rated Capacity Indicator/Limiter (RCL/RCI) Configuration screen. See that manual for instructions.

The rotating bed jacks, front and rear rotating frame pins, boom hinge pins, upper counterweight cylinder pins, and mast assist cylinders are controlled by switches on the hand-held radio remote control (Figure 4-5). The remote control also selects engine speed.

The remote control must be turned on in the main display. See Remote Controls topic in Section 3 of this manual for remote control operating instructions.

### **WARNING** **Moving Part Hazard!**

To avoid serious crushing injury:


- Keep feet clear of moving jacks.
- Warn all personnel to stay clear of jacks while they are being extended.

### **Tipping Hazard!**

- Keep crane as level as possible while jacking. Do not allow crane to get more than 3° out of level while jacking to prevent crane from collapsing due to structural failure of jacks.

### **CAUTION** **Machinery Damage!**

To avoid damage to jacking cylinders, fully retract them before traveling.



A10578

FIGURE 4-4

**NOTE:** On crane Serial Number 16001128 and newer with upperworks jacking:

The travel and swing alarm will sound while jacking with any switch on the remote control.

When the ALL jacking switch is used, the crane's programmable controller will attempt to adjust the jacking cylinders to maintain or return the rotating bed to level as sensed by the rotating bed level sensor.

Prior to using the ALL jacking switch, verify the accuracy of the rotating bed level sensor with a user furnished digital level. The angles shown on the main display should be the same as the angles shown on the digital level.

Out of level fault 4 will appear on the main display and the swing and travel alarm will sound if the rotating bed gets approximately 3° out of level while jacking.

- Operation does not stop automatically when this alarm comes on.
- When this alarm comes on, ***operator must stop jacking and level rotating bed using individual jacking switches.***

If the rotating bed level sensor indicates that the rotating bed is approximately 4.5° out of level, out of level sensor fault 43 will appear on the main display, the swing and travel alarm will sound at a lower pitch than normal, and the ALL jacks switch will be disabled. The rotating bed should then be leveled using the individual jacking switches, and the accuracy of the rotating bed level sensor should be checked.

## PRE-START CHECKS

Make the following checks before starting the engine upon arrival at the assembly site. See Section 3 for starting instructions.

### Engine

1. Check for leaks.
2. Check fuel, oil, and coolant levels.
3. Repair or refill as required.


### Gear Boxes

1. Check for leaks.
2. Check levels.

3. Repair or refill as required.

## Hydraulic System

1. Check for leaks.
2. Check level.
3. Repair or refill as required.
4. Make sure hydraulic shut-off valve is open.



Remote Control Stored in  
Rear of Operator's Cab

FIGURE 4-5

## CRANE ASSEMBLY

### Install Exhaust Pipes

**IMPORTANT** Perform following steps before starting engine.

See Figure 4-4 for following procedure.

1. Remove rear enclosure panels (1, View A).
2. Unhook springs (4, View B) from clips (5) and remove both rain caps (3) from shipping position.
3. Store rain caps (3) in enclosure frame (View A).
4. Remove both exhaust pipes (2) from shipping position (View A).
5. Install both exhaust pipes (2) in working position (View B).
6. Connect springs (4, View B) to clips (5).
7. Install rear enclosure panels (1).

A10740-5  
A10740-6

Item	Description
1	Terminator Plug
2	Electric Cable
14	Rear Alignment Pendant
15	Front Alignment Pendant
16	Link




FIGURE 4-6




## Remove Rotating Bed from Trailer

**NOTE:** Circled numbers in Figure 4-6 correspond to following steps.

**NOTE:** The engine will not start until terminator plug (1, View D, Figure 4-6) is connected to cable (2).

See Figure 4-6 for following procedure, unless otherwise specified.

1. Rotate four jacks (View A) to operating position and pin struts to jacks (see Figure 4-7).
2. Remove jack pads from storage (View B) and attach to jacks (View C).
3. If crane is equipped with a MAX-ER Attachment, remove links (16) from storage on side of carbody (View G) and attach to pins in rotating bed (View F).
4. Rotate links (16, View F) to working position (View G).
5. Remove alignment pendants from storage on side of carbody (View H).
6. Pin rear alignment pendants (14) to lugs on rotating bed (View F).
7. Pin front alignment pendants (15) to links (16, View F).
8. Remove tie-downs securing rotating bed to trailer.
9. Start engine and extend jacks with controls on remote control to lift rotating bed just clear of trailer.
10. Rotate operator's cab to operating position and secure with strut (see Figure 4-8).
11. Fully extend jacks to lift rotating bed off trailer (View F).
12. Remove trailer.



A10775





FIGURE 4-7

A11247



Legend for Figure 4-7 and 4-8

Item	Description	Item	Description
3	Rotating Bed Jack (Rear)	10	Locking Pin
4	Strut	11	Connecting Pin
5	Locking Pin Lever	12	Operator's Cab
6	Jack Pad with U-Shaped Pin	13	Strut
7	Rotating Bed Jack (Front)	A	Shipping Hole
8	Strut	B	Storage Hole (for crane operation)
9	Storage Link		

FIGURE 4-8

A10740-7  
A10740-7a  
A10740-7b  
A10740-8




FIGURE 4-9

A10765-2  
A10773  
A10774-1  
A10774-2

## Remove Carbody and Adapter Frame from Trailer

**NOTE:** Circled numbers in Figure 4-9 correspond to following steps.

See Figure 4-9 for following procedure.

---

### CAUTION

#### Equipment Damage!

Use extreme care when backing trailer into position:

- Do not hit jacks with trailer.

Provide a signal person to give instructions to truck driver.

---

1. Position trailer carrying carbody and adapter frame (1, View A) directly under rotating bed (2).
  - a. Align pendants (3 and 4, View B) with adapter frame holes and lugs.
  - b. Retract jacks only enough so alignment pendants can be pinned.

***Keep rotating bed as level as possible while retracting jacks.***


2. Pin front and rear alignment pendants (3 and 4, View B) to adapter frame.
3. Remove tie-downs securing adapter frame and carbody to trailer.
4. Slowly extend jacks to lift carbody and adapter frame just clear of trailer (View C).

Alignment pendants will center carbody and adapter frame under rotating bed.

***Keep rotating bed as level as possible while retracting jacks.***

5. Rotate rear rotating bed pins (5, View D) to operating position:
  - a. Remove shipping pins (6, View D) and connecting pins (7).
  - b. Rotate rear rotating bed pins (5) to operating position (View E).
  - c. Install connecting pins (7, View E) and store shipping pins (6).
6. Unlock keeper plate (9, View E) at both rear rotating bed pins.

A10740-7  
A10740-7a  
A10740-7b  
A10740-8



A10765-2  
A10773  
A10774-1  
A10774-2

FIGURE 4-9 continued

7. Remove locking pins (10, View G) from front rotating bed pins (11) and store.
  8. Disengage all four rotating bed pins with switches on remote control.  
  
With rotating bed pins disengaged, grease them. See Section 5 of this manual.
  9. Slowly retract jacks to lower carbody and adapter frame back onto trailer (View E).
- NOTE:** Adjust jacks so front of rotating bed is slightly lower than rear of rotating bed.
10. STOP lowering rotating bed when alignment pins (12, View H) at front of rotating bed engage saddles (13) in adapter frame. This will align front connecting holes.

---


### CAUTION

#### Overweight Hazard!

Do not lower entire weight of rotating bed onto adapter frame. Weight may exceed trailer capacity.

---

11. Engage front rotating bed pins with switch on remote control.
12. Remove locking pin (10, View G) from storage and install in LOCK position at both front rotating bed pins
13. Retract rear jacks until rotating bed comes to rest on adapter frame and trailer deck just starts to lower.
14. Connect hydraulic hoses to rear rotating bed pins (Figure 4-11).
15. Engage rear rotating bed pins with switch on remote control.
16. Pin keeper plate (9, View E) in LOCK position at both rear rotating bed pins.
17. Fully extend jacks to lift rotating bed, adapter frame, and carbody off trailer (View K).
18. Remove trailer. ***Take extreme care not to hit jacks with trailer. Provide a signal person to give instructions to truck driver.***
19. Remove and store rear alignment pendants. Store front alignment pendants. See Figure 4-6.



## Lower Crane onto Carbody Pedestals

See Figure 4-10 for following procedure.

1. Remove four carbody pedestals (2) from storage.
2. Place pedestals under carbody support pads (3, View C).
3. Retract rotating bed jacks to lower carbody onto four pedestals (View A).  
Check position of carbody with relation to foundation. Carbody must be as level as possible and at least 22 in (559 mm) off foundation for crawler installation.
4. Adjust pedestal screws (4, View C), as required.
5. Repeat steps 3 and 4, as needed.
6. Retract rear jacks until pads are approximately 6 in (152 mm) off ground.
7. Store front jacks as shown in Figure 4-7. **Pin storage links (7, Figure 4-7, View C) in Holes B.**

## Connect Hydraulic Hoses and Electric Cables


See Figure 4-11 for following procedure.

1. Remove sealing caps from hydraulic couplers on rotating bed and adapter frame and thoroughly clean each coupler.
2. Connect hydraulic hoses (2) to couplers (1) on both sides of rotating bed.

Hoses must run in a straight line between rotating bed and adapter frame.

- NOTE:** On current production cranes, the hoses and couplers between the rotating bed and adapter frame have numbered tags. To ensure proper connection, match the numbers on the tags.
3. Connect electric cables (3) to connectors (4) on right side of rotating bed.






Item	Description
1	Couplers on Adapter Frame
2	Hydraulic Hoses from Rotating Bed to Adapter Frame (see NOTE 1:)
3	Electric Cables from Adapter Frame to Rotating Bed (see NOTE 2:)
4	Connectors on Rotating Bed
5a	Hydraulic Hose from Rear Rotating Bed Pin (see NOTE 3:)
5b	Coupler on Rotating Bed
6a	Hydraulic Hose to Rear Rotating Bed Pin (see NOTE 4:)
6b	Coupler on Rear Rotating Bed Pin

- NOTE 1:** Four hydraulic hoses are located on right side of rotating bed and five lines on left side of rotating bed  
Hoses must run in a straight line and not be crossed.
- NOTE 2:** Electric cables are located on right side of rotating bed only.
- NOTE 3:** Hose 5a is connected to coupler (6b) on rear rotating bed pin for shipping.
- NOTE 4:** Hose 6a is connected to coupler (5b) on rotating bed for shipping.

FIGURE 4-11

A10740-10



Item	Description
1	Live Mast
2	Mast Assist Arm and Cylinder
3	Boom Hoist
4	Boom Hoist Wire Rope

FIGURE 4-12

## Raise Live Mast To Operating Position

See Figure 4-12 for following procedure.

The following controls are used to raise the mast. See Operating Controls in Section 3 of this manual for identification and operation of these controls.

The following controls are used to raise the mast and gantry. See Section 3 for identification and operation of these controls.

1. RCL DISPLAY to select the Liftcrane Mast Capacities Chart.

The mast controls will not operate and the mast operating limits remain off until the Liftcrane Mast Capacities Chart is selected.

2. MAST ARMS CONTROL to raise and lower the mast arms independently of the mast.
3. BOOM HOIST CONTROL to raise and lower the mast while using mast as a boom.
4. MAIN DISPLAY information screen to monitor the mast operating angle and to identify mast faults.



### WARNING

#### Falling Mast Hazard!

Prevent mast from falling over backwards or forward:

- Read and thoroughly understand mast raising instructions.
- Select Liftcrane Mast Capacities Chart in RCL configuration screen before raising mast and using it as a boom. Mast operating limits remain off until this step is performed.

### CAUTION

#### Mast Damage!

Make sure mast angle indicator is properly installed and calibrated prior to raising mast.


Mast can be damaged if angle indicator is not properly installed.

1. Select Liftcrane Mast Capacities Chart.
2. Monitor MAST ANGLE on main display information screen during raising procedure.
3. Increase engine speed to desired rpm.
4. Using mast switch on remote control, raise mast assist arms (2) until cylinders stall and stop.

**NOTE:** The following will occur if you don't do step 4 before step 5:

- Mast will not rise.
- Hazard warning buzzer will come on.
- Hazard warning symbol and MAST BELOW 2 DEGREES icon will appear on fault screen.

MAST 2 DEGREE  
FAULT ICON



5. BOOM DOWN with boom hoist control to raise live mast (1) to operating position.

Mast will rise as mast assist arm cylinders (2) extend automatically.

Mast assist arms will stop rising automatically when mast assist cylinders are fully extended (approximately 115°).


6. Proceed to use mast as a boom with boom hoist control for remainder of self-erect assembly procedure.

**See Liftcrane Mast Capacities Chart at end of this section for detailed lifting capacities.**

**NOTE:** The following will occur if the mast is lowered to 156°:

- Mast will stop lowering.
- Hazard warning buzzer will come on.
- Hazard warning symbol and MAST TOO FAR FORWARD icon will appear on fault screen.

MAST TOO FAR  
FORWARD ICON





### WARNING

#### Falling Mast Hazard!

Prevent mast from falling:

- Do not use limit bypass to lower mast below 156°. Mast will fall suddenly. **Connect an assist crane to end of live mast when it is necessary to lower it below 156°.**
- Do not lower mast assist arms until live mast is connected to boom rigging. Mast will fall over backwards if raised above 115° when arms are down.


A10740-10a  
A10740-11  
A10740-18a  
A10740-21



### Component Identification

Item	Description
1	Live Mast
2	Handling Pendant
3	Owner-Furnished Nylon Slings
4	Assist Crane Load Block
5	Mast Straps
6	45 USt Load Block (41 t)
7	Button Socket
8	4-Leg Chain Sling

*See Liftcrane Mast Capacities Chart at end of this section for detailed lifting capacities.*



A10522

**View E**  
*While Handling First Crawler*

**FIGURE 4-13**

## Install Assembly Block

See Figure 4-13 for following procedure.



### WARNING

#### Falling Mast Hazard!

Prevent mast from falling:

- Do not use limit bypass to lower mast below 156° until ***mast is supported with slings from assist crane.***
- Assist crane must lift 14,000 lb (6 350 kg).

1. Position trailer carrying assembly block (6) as shown in View C.
2. BOOM DOWN to lower mast (1) to approximately 160°.
3. Unpin handling pendants (2, View A) from mast and attach pendants to assist crane block (4) with nylon lifting slings (3).
4. Support mast with assist crane.
5. Lower mast to desired position with assist crane. *Do not side load mast.*

Use limit bypass switch to bypass mast limit and pay out boom hoist wire rope as mast is lowered with assist crane.



### WARNING

#### Crush Hazard!

Do not stand or work under mast unless it is supported by assist crane.

### CAUTION

#### Equipment Damage!

To prevent damage, guide mast straps (5) clear of trailer, as required.

6. Reeve wire rope from whip drum through sheaves in mast point and sheaves in assembly block (6, View B).

7. Anchor wire rope to button socket (7, View B) on load block (see Wire Rope Installation and Maintenance in this section).
8. Connect 4-leg chain sling (8, View D) to assembly block.
9. Raise mast to at least 156° with assist crane. As mast is raised:
  - Pay out load line from whip drum.
  - Haul in wire rope on boom hoist.
10. Once mast is at or above 156°, support mast with boom hoist wire rope and disconnect handling pendants (2) from assist crane block.
11. Pin handling pendants to mast for storage (View A).
12. Haul in load line on whip hoist to lift assembly block off trailer.
13. Position mast in operating range (see Figure 4-12).

## Install Crawlers

The crane must be in the following configuration to install crawlers:

- Mast arms fully raised.
- Liftcrane Mast Capacities Chart selected on RCL display configuration screen.
- Swing limited to 10° either side of center when handling first crawler (Figure 4-13, View E).
- Mast operated within limits of Liftcrane Mast Capacities Chart at end of this section.



### WARNING

#### Tipping Hazard!


- Do not exceed capacities given in Liftcrane Mast Capacities Chart when handling crawlers with mast. Crane will tip forward.
- Make sure crane is level. Adjust pedestals as required.

### CAUTION

#### Parts Damage!

Avoid hitting carbody pedestals with crawlers.

A10740-111

**Component Identification**

Item	Description
6	Assembly Block
7	4-Leg Chain Sling
7a	Grab Hook
8	Crawler


Items 9 and 10 No Used

FIGURE 4-14


## Handling Crawlers

See Figure 4-14 for following procedure.


- ## Handling Crawlers
- See Figure 4-14 for following procedure.
1. Attach hooks from chain sling (7, View A and B) to four shackles (9) on crawler lifting lugs — two legs with grab hooks (7a) on outboard side.
  2. Using grab hooks, shorten both outboard legs eleven chain links so crawler tips inward when lifted.
  3. Position chains between crawler pads (View A).



**View A**  
CRAWLER SHIPPING ARRANGEMENT



**View B**  
CARBODY SHIPPING ARRANGEMENT



**View C**  
CARBODY/CRAWLER WORKING ARRANGEMENT


### Component Identification

Item	Description
11	Hydraulic Hose
11a	Coupler
12	Hydraulic Hose
12a	Coupler
13	Hydraulic Hose
13a	Coupler
14	Grease Hose
14a	Coupler

**FIGURE 4-15**

A10740-11aa  
A10740-12aa

*See Liftcrane Mast Capacities Chart at end of this section for detailed lifting capacities.*





**Install First Crawler**

**NOTE:** To prevent the crawler pads from sagging too much when the crawler is lifted, chains are installed between the crawler frames and pads (see Figure 4-17, View F). Some sag must be allowed to prevent interference between carbody and crawler pads.

1. Thoroughly clean and grease all machined surfaces (1, Figure 4-16, Views F and G) on carbody and crawler.

**NOTE:** Failing to clean and grease machined surfaces may result in loud banging sounds when attempting to turn crane while traveling. Though not harmful, operators may find the sounds disturbing.

Once the crawlers are installed, the drive shafts will be at opposite corners: drive shaft on left side to rear and drive shaft on right side to front.

2. Position trailer carrying crawler along desired side of crane (Figure 4-16, View A).
3. Disconnect hydraulic hoses (see Figure 4-15):
  - (11, View A) from coupler (12a).
  - (12, View B) from coupler (11a).

Move hoses out of way so they do not interfere with crawler installation.

See Figure 4-16 for remaining steps.

4. Remove collars (3, View E) and retract crawler connecting pins (2) with crawler pins control (4 or 5, View H).  
With crawler pins disengaged, grease them. See Section 5 of this manual.
5. Attach hooks from chain sling (7, View A) to crawler as shown in Figure 4-14.
6. Tilt operator's cab up, as required, so crawler does not hit cab.
7. Slowly hoist crawler clear of trailer.
8. Remove trailer.
9. Slowly lower crawler, mast up, and swing to engage holes in crawler lugs (11, View D) with fixed pins (12) in carbody.
10. Continue to lower crawler until handling chains slacken.
11. Using control handle (4 or 5, View H), engage crawler connecting pins (2, View E).
12. Install collars (3, View E) and retaining pins.
13. Unhook chain sling (7, View B) from crawler.
14. Rotate rear jacks to horizontal (wing position) as shown in View C. Rear jacks will hit installed crawler if this step is not done before swinging.

**Legend for Figure 4-16** (quantities are for one crawler)

Item	Description	Item	Description
1	Machined Surface	7	Chain Sling
2	Connecting Pin (2 places)	8	Crawler Assembly
3	Collar with Retaining Pin and Hair-Pin Cotter (2 places)		See Figure 4-14 for Items 9 and 10
4	Left Crawler Pins Control	11	Crawler Lug (2 places)
5	Right Crawler Pins Control	12	Fixed Pin (2 places)
6	Assembly Block		




FIGURE 4-17

**Install First Crawler (continued)**

See Figure 4-17 for following procedure.

15. Swing 180° (View A) and rotate rear jacks (11) to working position.

**WARNING****Rotating Drive Shaft Hazard!**

Crawler drive shaft rotates at high speed.

- Make sure crawler drive shaft is securely attached at both ends.
  - Make sure guards are in place and securely attached at both ends during operation.
  - Do not attempt to service drive shaft until crane has been parked and engine stopped.
16. Lift crawler drive shaft (4, View B) off storage bracket (5), extend shaft, and align holes in drive shaft flanges (6 and 7, View C).
  17. Apply Never-Seez™ or an equivalent anti-seizing compound to treads and under heads of flange screws (8, View C).
  18. Insert flange screws (8) and torque to 75 ft-lb (102 N•m).
  19. Slide drive shaft guard (9) over drive shaft and pin to carbody (View D).
  20. Connect hydraulic hoses (Figure 4-15, View C):
    - (11) to coupler (11a).
    - (12) to coupler (12a).
    - (13) to coupler (13a).
  21. Connect grease line (14, Figure 4-15, View C) to coupler (14a, View A).

22. Extend rear jacks (15) to lift crane off carbody pedestals next to first crawler (16, View A).
23. Remove pedestals (17) from next to first crawler and store.
24. Retract rear jacks (15) to lower crawler (16) to ground.
25. Remove chains (1, View F) from between crawler pads (2) and crawler lugs (3) (four places). Store for future use.
26. Rotate rear jacks to horizontal (wing position) as shown in Figure 4-16, View D. Rear jacks will hit installed crawler if this step is not done before swinging.

**Install Second Crawler**

**NOTE:** Once first crawler is installed and **resting on ground**, second crawler can be lifted over same side of crane as first crawler at a **maximum radius of 20 ft (3,5 m)**.

1. Repeat Install First Crawler steps 2 through 13 and 16 through 22 for second crawler.
2. Swing 180° (View A) and rotate rear jacks to working position.
3. Extend rear jacks to lift crane off pedestals (17) next to second crawler (18).
4. Remove pedestals and store.
5. Retract jacks to lower crawler to ground.
6. Remove chains (1, View F) from between crawler pads (2) and crawler lugs (3) (four places). Store for future use.
7. Remove jack pads from rear jacks and store.
8. Fully retract rear jacks and rotate to stored position (Figure 4-7, View A).

**Legend for Figure 4-17**

Description		Item	Description
1	Chain with Hook	9	Drive Shaft Guard
2	Crawler Pad	10	Safety Pin
3	Crawler Lug		See Figure 4-15 for Items 11 through 14
4	Crawler Drive Shaft	15	Rear Rotating Bed Jack
5	Storage Bracket	16	Crawler Assembly (First Installed)
6	Drive Shaft Flange (Carbody)	17	Carbody Pedestal
7	Drive Shaft Flange (Crawler)	18	Crawler Assembly (Second Installed)
8	Flange Screw (8 each)		

A11446-1




FIGURE 4-18

## Install Crawler Platforms

See Figure 4-18 for following procedure.

### **Past Production**

The crawlers are equipped with platforms (1) as shown in View A.

Once the crawlers are installed, rotate platform extensions (1a, View B) to working position.

### **Past Production**

The crawlers are equipped with platforms (1) as shown in View A.

Once the crawlers are installed, rotate platform extensions (1a, View D) to working position:

1. Remove hitch pins (4) and pull supports (2) out to working position.
2. Install hitch pins (4).

3. Remove safety pins (3) and rotate platform extensions (1a) to working position.

4. Install safety pins (3) in ends of platform extensions (1a).

## Install Crawler Stairways

See Figure 4-18 for following procedure.

If the crawler stairways are not already installed, proceed as follows:

1. Using nylon slings from assembly block on live mast, lift stairway (6, View C) into position at desired corner of crawler platform (1).
2. Slide tubes at top of stairway through sleeves (7) on underside of platform.
3. Install quick-release pins (8) to lock stairway in place.
4. Repeat procedure for stairway at opposite corner of crawlers.

**NOTE:** Stairways can be positioned at either end of either crawler to provide access that meets user needs.


Carbody Counterweight Identification

A10740-13  
A10786

	Item	Description	Required Each End of Carbody	Weight Each lbs (kg)	Total Weight lbs (kg)
Series 1	No Carbody Counterweight				
Series 2	1	Center Box	1	30,000 (13 608)	60,000 (27 216)
Series 3	1	Center Box	1	30,000 (13 608)	120,000 (54 431)
	2	Side Box	2	15,000 (6 804)	

Legend

Item	Description
3	Lifting Lug (4 places each box)
4	Slot
5	Hook
6	Pin
7	Pin
8	Stairway
9	Pin



See Liftcrane Mast Capacities Chart at end of this section for detailed lifting capacities.




FIGURE 4-19

## Install Counterweight

See Figure 4-19 and Figure 4-20, View F for identification of the counterweight used on the 16000.



### WARNING

#### Tipping Hazard!

To prevent crane from tipping:

- Install carbody counterweight before installing crane counterweight.

### Install Carbody Counterweight

See Figure 4-19 for following procedure.

#### General

The carbody counterweight can be installed with the live mast. The 16000 must be in the following configuration to install the carbody counterweight:

- Mast assist arms fully raised. Mast will be at approximately 105° (assist arms supporting mast) when attaching carbody counterweights.
- Liftcrane Mast Capacities Chart selected on RCL configuration screen.
- 360° swing permitted while handling counterweight.
- Mast operated within limits of Liftcrane Mast Capacities Chart at end of this section.


## Installation

1. For **Series 2 and 3**, proceed as follows:
  - a. Attach crawler handling shackles to lifting lugs (3) on center box (1).
  - b. Attach legs of chain sling to shackles.
  - c. Lift center box into position at either end of carbody.
  - d. Boom, hoist, and swing as required to engage slots (4) in top of center box with hooks (5) on carbody as shown in View C.
  - e. Lower center box until bottom connecting holes line up.
  - f. Install pins (6, View B).
  - g. Disconnect chain sling and remove shackles.
2. For **Series 3 only**, Install each side box:
  - a. Attach crawler handling shackles to lifting lugs (3) on side box (2).
  - b. Attach legs of chain sling to shackles.
  - c. Lift side box (2) into position and pin to center box.
  - d. Disconnect chain sling and remove shackles.
  - e. Repeat steps for other side box.
3. Repeat steps a and 2 at other end of carbody.
4. Attach shackles to crawlers for storage.

A10787-2

**Legend**

Item	Description
3	Handling Pendant
4	Hydraulic Couplers
5	Hooks
6	Counterweight Pin
7	Hitch Pin
8	Adapter Plate
9	Lifting Sling (Owner Furnished)

**FIGURE 4-20**



### Install Crane Counterweight

The crane counterweight must be installed with an assist crane.

See Figure 4-20, for following procedure.

1. Uncoil handling pendants (3, View B) with adapter plates (8, View B) from storage pockets in tray (1) and hook to lifting slings from assist crane (View C).

### WARNING

#### Falling Load Hazard!

Pendants are designed to handle counterweight tray only.

Do not attempt to lift tray with counterweight boxes installed. Pendants could break allowing counterweight tray and boxes to fall.

2. Lift counterweight tray into position at rear of crane and place tray on ground.
3. Connect hydraulic hoses from counterweight cylinders to couplers (4, View A) on rear of rotating bed.
4. Disengage counterweight pins (6) with switch on remote control. Pins will engage if switch is released.
5. Hoist, travel, boom, and swing as required with assist crane to guide counterweight tray into position under rear of rotating bed (View C).
6. Engage hooks (5, View D) in tray with hooks in rotating bed and align connecting holes.
7. Release switch on remote control to engage counterweight pins (6, View D).
8. Lower counterweight until it is supported by pins (pendants slacken).
9. Remove hitch pins (7, View E) from storage lugs and install in ends of counterweight pins (6).
10. Unhook handling pendants and adapter plates from lifting slings. Coil pendants and place adapter plates in storage pockets (View B).
11. Coil hydraulic hoses on tray for storage.
12. Do not disconnect hydraulic hoses from couplers on rotating bed. Due to thermal expansion, they could be difficult to reconnect.
13. Stack required counterweight side boxes (2, View F) one box at a time alternating from side to side.
  - First box each side must be centered on tray.
  - Lifting lugs and steps on each box center adjacent box.
  - If your crane is luffing jib prepared, side box (2) with lugs (5) must be installed on top of each stack.

### Crane Counterweight Identification

	Item	Description	Total Required	Weight lbs (kg)	Total Weight lbs (kg)
<b>Series 1</b>	1	Tray	1	44,000 (19 958)	224,000 (101 605)
	2	Side Box	10	18,000 (8 165)	
<b>Series 2</b>	1	Tray	1	44,000 (19 958)	296,000 (134 265)
	2	Side Box	14	18,000 (8 165)	
<b>Series 3</b>	1	Tray	1	44,000 (19 958)	332,000 (150 595)
	2	Side Box	16	18,000 (8 165)	

#### Item Description

- |   |                          |
|---|--------------------------|
| 3 | Lifting Lug (4 each box) |
| 4 | Step (2 each box)        |
| 5 | Lug (4 each top box)     |
| 6 | Link (8, one top box)    |
| 7 | Pin (4, one top box)     |





FIGURE 4-20 continued

A10787-1

A10740-16  
A10882  
M4-11c

**Legend**

Item	Description
1	Boom Butt
2	Wire Rope Guide
3	Lifting Lug
4	Pin with Cotter Pins
5a	Hoses
5b	Couplers in Boom Butt
5c	Couplers on Rotating Bed
6	Hinge Pin
7	Locking Pin
8	Shims

**FIGURE 4-21**

## Assemble Boom

The boom can now be assembled using the 16000 live mast.

See Boom Assembly later in this section for detailed instructions.

If a luffing jib will be installed, see separate instructions in Luffing Jib Operator's Manual.

## Install Boom Butt

See Figure 4-21 for following procedure.

1. Raise wire rope guide to operating position (View A):
  - a. Attach lifting sling from 16000 to lifting lug (3, View A) on wire rope guide (2).
  - b. Support wire rope guide so pins (4) are loose and remove pins.
  - c. Raise wire rope guide from shipping position to operating position.
  - d. Install pins (4).
  - e. Disconnect lifting sling.
2. Attach lifting slings from 16000 to lifting lugs in top chords of boom butt as shown in View D.  
**Adjust length of slings so butt is horizontal when lifted.**
3. Lift butt into position at connecting holes in front of rotating bed (View D).
4. Disconnect hydraulic hoses (5a, View B) from couplers (5b) in boom butt.  
**Thoroughly clean couplers to prevent dirt from entering hydraulic system.**
5. Connect hydraulic hoses (5a, View C) to couplers (5c) on left side of rotating bed.
6. Using setup remote control, disengage boom hinge pins (6, View F).
7. Position butt so connecting holes in butt line up with connecting holes in rotating bed.
8. Center butt between rotating bed lugs and check side play. If total side play is greater than 5/64 in (22 mm), install shims (8, View E) as follows:

- a. Install thickest shim possible between inboard side of butt and rotating bed lug on both sides of crane.

**Shim tabs must face inward and rest on rotating bed lugs.**

- b. Install next thickest shim possible between inboard side of butt and first shim on both sides of crane.
- c. If possible, install thinnest shim between inboard side of butt and second shim on both sides of crane.

9. Using setup remote control, engage boom hinge pins.
10. Remove locking pins (7, View E) from shipping position and install in working position.
11. Lower butt onto ground.
12. Disconnect slings.
13. Disconnect hydraulic hoses (5a, View C) from couplers (5c) on rotating bed and connect to couplers (5b, View B) in butt.
14. Hold retaining bar (2, Figure 4-22, View D) down and remove safety pin (3) from one end of bar.
15. Slowly raise retaining bar (2) and rotate hydraulic hoses forward.
16. Repin retaining bar for storage.
17. Remove sealing covers from couplers on boom butt and from couplers and hydraulic hoses on rotating bed.  
**Thoroughly clean couplers to prevent dirt from entering hydraulic system.**
18. Connect hydraulic hoses and couplers on rotating bed to couplers on boom butt as shown in Figure 4-22.

**NOTE:** These are straight line connections. No hoses will cross when the hoses are correctly connected.

On current production cranes, the hoses and couplers between the boom butt and rotating bed have numbered tags. To ensure proper connection, match the numbers on the tags.

Coupler-assist tool (Figure 4-22, View A) can be used to connect the large couplers.

***THIS PAGE BLANK***





FIGURE 4-22

A10740-17  
A10740-19  
A10740-20

**Legend**

Item	Description
1	Trailer
2	Boom Butt
3	Mast
4	Chain Sling
5	Assembly Block
6	Handling Pendant
7	Assist Crane Load Block
8	Nylon Sling
9	Mast Strap
10	Hooked Connector
11	Fixed Pin
12	Pin with Safety Pin

**FIGURE 4-23**

## Remove Assembly Block

See Figure 4-23 for following procedure.



### WARNING

#### Falling Mast Hazard!

Prevent mast from falling:

- Do not use limit bypass to lower mast below 156° until **mast is supported with slings from assist crane.**
  - Assist crane must lift 14,000 lb (6 350 kg).
- 
1. Position trailer (1, View B) or other means of transport in front of boom butt (2) as shown. Or, lower assembly block onto ground and remove with assist crane.
  2. BOOM DOWN to lower mast (3) to approximately 150°.
  3. Guide slings (4) and assembly block (5) around end of boom butt as mast is lowered.
  4. Unpin handling pendants (6, View A) from mast and attach pendants to assist crane block (7) with nylon lifting slings (8).
  5. Support mast with assist crane.
  6. Lower mast to desired position with assist crane. *Do not side load mast.*  
  
Use limit bypass switch to bypass mast limit and pay out boom hoist wire rope as mast is lowered with assist crane.



### WARNING

#### Crush Hazard!

Do not stand or work under mast unless it is supported by assist crane.

7. Lower assembly block (5, View B) onto trailer or ground. Guide mast straps clear of trailer, as required.
8. Remove wire rope from assembly block and mast and store wire rope on whip drum.

### CAUTION

#### Lacing Damage!

Take necessary precaution while storing wire rope on drum so button end of rope does not fall and damage lacings in boom butt.

9. Raise mast to at least 150° with assist crane. As mast is raised haul in wire rope on boom hoist.
10. Once mast is at or above 150°, support mast with boom hoist wire rope and disconnect handling pendants (6) from assist crane block.
11. Position mast at approximately 140° (View C).

## Connect Boom Butt to Boom

See Figure 4-23 for following procedure.

1. Pin handling pendants (6, View D) to lugs on boom butt (2).
2. Boom up to lift boom butt just clear of ground.
3. Position 16000 so boom butt is in line with end of boom (View C).
4. Travel forward and boom down to align hooked connectors (10, View E) in boom butt with fixed pins (11) in adjacent insert.
5. See Capacity Chart to determine if crawlers must be blocked to raise assembled length of boom. **If blocking is required:**
  - a. Mark ground at front end of crawler — center of tumbler on one crawler and center of front roller on other crawler.
  - b. Disengage boom butt from insert and travel backwards approximately 4 ft (1,2 m).
  - c. Install required blocking at points marked in step 5a.
  - d. Repeat step 4.



### WARNING

#### Falling Boom Hazard

Do not attempt to lift assembled boom with handling pendants. Handling pendants could break allowing boom to fall.

6. Boom up slowly (View F) until bottom connectors are lined up between butt and insert.
7. Install pins (12, View G).
8. Unpin handling pendants (6, View D) from boom butt and pin to mast (View A) for storage.

## Legend

A10740-20a

Item	Description
1a	Mast Strap
1b	Insert Strap
2	Links
3	Pin (shipping)
4	Link (shipping)
5	Pin, with Collar, Retaining Pin, and Cotter Pins
6	Terminator Plug with Sealing Cap
7	Electric Cable on Crane
8	Electric Cable From Boom
9	Electric Cable from Drum 1 on Boom
10	Electric Cable from Drum 3 on Boom




FIGURE 4-24



See Figure 4-24 for remaining steps.

9. Connect electric cable from crane to controller on boom butt:
  - a. Remove terminator plug (6, View E) from electric cable (3) on crane.
  - b. Connect electric cable (8) from boom butt to cable (3).
10. Connect electric cables (9, View D) and (10 optional) from boom butt to node on front of rotating bed.
11. Lower mast until ends of mast straps (1a) are approximately 18 in. (457 mm) from boom.
12. Connect mast straps (1a, View B) to insert straps (1b), as follows:
  - a. Remove pins (3, View A) and rotate links (4) to working position (View B).
  - b. Pin links (4, View B) in working position.
  - c. Remove pins (5, View C) from storage.
  - d. Rotate links (2, View A) up and pin to mast straps (1a) with pins (5, View B). Lower mast as required to align holes.



### **DANGER**

#### **Falling Mast/Boom Hazard!**

Prevent mast and boom from falling:

- Fully lower mast arms before raising boom. *Mast can buckle and collapse if it contacts mast arms with a fully rigged boom.*

13. Fully lower mast arms using switch on remote control.
14. Select proper capacity chart on configuration screen of RCL display.
15. Boom can now be raised. **Perform Pre-Raising Checks.**

## **CRANE DISASSEMBLY**

### **Lower Boom**

Perform steps 1 through 4 under Boom Removal topic to lower the boom and jib (if equipped).

### **Disconnect Boom Butt from Boom**

1. Disconnect boom wiring:
  - a. Disconnect electric cable (8, Figure 4-24, View E) (from boom) from electric cable (7) on crane.

- b. Remove sealing cap and connect terminator plug (6, View E) to electric cable (7). Also see Figure 4-6, View D.
- c. Connect sealing cap to electric cable (8) and store electric cable (8) on boom butt.
- d. Disconnect electric cables (9, Figure 4-24, View D) and (10 optional) from node on front of rotating bed.
- e. Connect sealing caps to electric cables (9 and 10) and store the cables in the boom butt.
- f. Disconnect electric cable from cable reel in butt at controller on boom butt and at controller on boom top.
- g. Coil cable onto cable reel.

2. Disconnect mast straps from boom (see Figure 4-24):
  - a. Lower mast until straps (1b) for insert next to butt are resting on insert as shown in View B.
  - b. Unpin links (2, View B) from mast straps (1a) and store links (2) and straps (1b) as shown in View A.
  - c. Store pins (5) in pockets on insert (View C).
3. Fully raise mast arms using switch on remote control.



### **DANGER**

#### **Falling Mast/Boom Hazard!**

Prevent mast from falling:

- Fully raise mast arms before raising mast. Mast will fall over backwards if raised to vertical when arms are down.

4. Disconnect boom butt:

See Figure 4-23 for following procedure.



### **DANGER**

#### **Falling Boom Hazard**

Do not remove bottom pins between butt and insert until handling pendants are connected and supporting boom. Boom will collapse.

- a. Unpin handling pendants (6, View A) from mast and pin to lugs on boom butt (View D).
- b. Boom up until handling pendants (6, View F) are just taut.

**WARNING****Falling Boom Hazard**

Do not attempt to lift assembled boom with handling pendants. Handling pendants could break allowing boom to fall.

- c. Remove pins (12, View G).
- d. Slowly boom down to lower boom onto blocking at least 6 in. (152 mm) (View C).
- e. Boom down until hooked connectors (10, View E) in boom butt disengage fixed pins (11) in adjacent insert.
- f. Travel backward until crane is clear of boom and there is enough room to install assembly block.
- g. Lower boom butt onto blocking.
- h. Unpin handling pendants (6, View D) from boom butt.

**Install Assembly Block**

See Figure 4-23 for following procedure.

**WARNING****Falling Mast Hazard!**

Prevent mast from falling:

- Do not use limit bypass to lower mast below 156° until ***mast is supported with slings from assist crane.***
1. Position trailer carrying assembly block (5) at end of boom butt as shown in View B.
  2. BOOM DOWN to lower mast (3) to approximately 160°.
  3. Pin handling pendants (6) to assist crane block (7) with nylon lifting slings (8).
  4. Support mast with assist crane.
  5. Lower mast to desired position with assist crane. *Do not side load mast.*

Use limit bypass switch to bypass mast limit and pay out boom hoist wire rope as mast is lowered with assist crane.

**WARNING****Crush Hazard!**

Do not stand or work under mast unless it is supported by assist crane.

**CAUTION****Equipment Damage!**

To prevent damage, guide mast straps (5) clear of trailer, as required.

6. Reeve wire rope from whip drum through sheaves in mast point and sheaves in assembly block (see Figure 4-13, View B).
7. Anchor wire rope to socket and wedge on load block (see Wire Rope Installation and Maintenance in this section).
8. Connect 4-leg chain sling (4) to assembly block.
9. Raise mast to at least 156° with assist crane. As mast is raised:
  - Pay out load line from whip drum.
  - Haul in wire rope on boom hoist.
10. Once mast is at or above 156°, support mast with boom hoist wire rope and disconnect handling pendants (6) from assist crane block.
11. Pin handling pendants to mast for storage (View A).
12. Haul in load line on whip hoist to lift assembly block off trailer. ***Take every precaution to prevent block from swinging into end of boom butt and causing damage.***
13. Position mast in operating range (see Figure 4-12).

**Remove Boom Butt**

See Figure 4-21 for following procedure.

1. Lower wire rope guide to shipping position (View A):
  - a. Attach lifting sling from assembly block to lifting lug (3, View A) on wire rope guide (2).
  - b. Support wire rope guide so pins (4) are loose and remove pins.
  - c. Lower wire rope guide from operating position to shipping position.
  - d. Install pins (4).
  - e. Disconnect lifting sling.

2. Disconnect hydraulic hoses between boom butt and rotating bed (see Figure 4-22):
  - a. **Thoroughly clean each coupler** and connect sealing covers to couplers to prevent dirt accumulation.
  - b. Unpin and move retaining bar (2) out of way.
  - c. Swing hydraulic hoses (6 and 7) rearward into notches on rotating bed (View D).
  - d. Pin retaining bar in position to retain hoses (View D).
3. Attach lifting slings from assembly block to lifting lugs in top chords of boom butt as shown in Figure 4-21, View D.
4. Disconnect hydraulic hoses (5a, View B) from couplers (5b) in boom butt.
 

**Thoroughly clean couplers to prevent dirt from entering hydraulic system.**
5. Connect hydraulic hoses (5a, View C) to couplers (5c) on left side of rotating bed.
6. Remove locking pins (7, View E) from operating position and install in shipping position.
7. Attach hand-held taglines to butt so it can be stabilized when pins are disconnected.
8. Lift butt clear of ground (View D).

**WARNING****Moving Load Hazard!**

Warn personnel to stand well clear of boom butt. Butt may swing out away from crane when pins are disengaged.

9. Using setup remote control, disengage boom hinge pins (6, View E).
10. Stabilize butt with taglines.
11. Using setup remote control, engage boom hinge pins.
12. Lift butt onto transport vehicle.
13. Disconnect slings.

**Disassemble Boom**

The boom can now be disassembled using the 16000 live mast.

See Liftcrane Mast Capacities Chart at the end of this section for lifting capacities.

**Remove Counterweight****WARNING****Tipping Hazard!**

To prevent crane from tipping:

- Remove crane counterweight before removing carbody counterweight.

**Remove Crane Counterweight**

The crane counterweight must be removed with an assist crane.

See Figure 4-20, for following procedure.

1. Remove counterweight side boxes (2, View F) one box at a time alternating from side to side.
2. Uncoil handling pendants (3, View B) and plate adapters (8, View B) from storage pockets in tray (1) and hook pendants and plate adapters to load block from assist crane (View C).

**WARNING****Falling Load Hazard!**

Pendants are designed to handle counterweight tray only. Do not attempt to lift tray with counterweight boxes installed. Pendants could break allowing counterweight tray and boxes to fall.

3. Hoist with assist crane until handling pendants are taut.
4. Remove hitch pins (7, View E) from counterweight pins (6) and install in storage lugs.
5. Disengage counterweight pins (6) with switch on remote control. Pins will engage if switch is released.
6. Travel, swing, and lower load as required with assist crane to disengage counterweight tray from hooks (5) in rotating bed (View D).
7. Lower counterweight tray onto ground at rear of crane.
 

Release switch on remote control to engage counterweight pins (6, View D) once tray is clear of holes.
8. Disconnect hydraulic hoses from counterweight cylinders at couplers (4, View A) on rear of rotating bed.
 

Coil hydraulic hoses on tray for storage.
9. Lift counterweight tray onto transport vehicle.
10. Unhook handling pendants and plate adapters from assist crane hook. Coil pendants and place plate adapters in storage pockets (View B).

**WARNING****Tipping Hazard!**

To prevent crane from tipping:

- Remove crane counterweight before removing carbody counterweight.

**Remove Carbody Counterweight**

See Figure 4-19 for following procedure.

**General**

The carbody counterweight can be removed with the live mast when the 16000 is in the following configuration:

- Mast assist arms fully raised. Mast will be at approximately 105° (assist arms supporting mast) when attaching carbody counterweights.
- Liftcrane Mast Capacities Chart selected on RCL configuration screen.
- 360° swing permitted while handling counterweight.
- Mast operated within limits of Liftcrane Mast Capacities Chart at end of this section.

**Removal**

1. For **Series 3 only**, remove each side box:
  - a. Attach crawler handling shackles to lifting lugs (3) on side box (2).
  - b. Attach legs of chain sling to shackles.
  - c. Lift against side box until chain sling legs are taut.
  - d. Unpin side box from center box (store pins in side box holes).
  - e. Lift side box onto transport vehicle.
  - f. Disconnect chain sling and remove shackles.
  - g. Repeat steps for other side box.
2. For **Series 2 and 3**, proceed as follows:
  - a. Attach crawler handling shackles to lifting lugs (3) on center box (1).
  - b. Attach legs of chain sling to shackles.
  - c. Remove pins (6, View B). Store pins in center box holes once box is removed.
  - d. Boom, hoist, and swing as required to disengage slots (4, View C) in top of center box from hooks (5) on carbody.

- e. Lift center box onto transport vehicle.
- f. Disconnect chain sling and remove shackles.

3. Repeat steps 1 and 2 at other end of carbody.

4. Attach shackles to crawlers for storage.

**Remove Crawler Stairways**

See Figure 4-18, View C for following procedure.

If necessary, remove each crawler stairway as follows:

1. Attach nylon slings from assembly block on live mast to stairway (6).
2. Hoist as required to support stairway.
3. Remove quick-release pins (8). Store pins in platform holes once stairway is removed.
4. Slide stairway out of sleeves (7) on underside of platform.
5. Lift stairway onto transport vehicle and disconnect slings.

**Store Crawler Platforms****Past Production**

See Figure 4-18, View B for following procedure.

Rotate platform extensions (1a) to stored position.

**Past Production**

See Figure 4-18, View D for following procedure.

1. Remove safety pins (3) from ends of platform extensions (1a).
2. Rotate platform extensions (1a) to stored position and install safety pins (3).
3. Remove hitch pins (4) and push supports (2) in.
4. Install hitch pins (4).

**Remove Crawlers**

The crane must be in the following configuration to remove crawlers:

- Mast arms fully raised.
- Liftcrane Mast Capacities Chart selected on RCL configuration screen.
- Mast operated within limits of Liftcrane Mast Capacities Chart at end of this section.

**WARNING****Tipping Hazard!**

- Do not exceed capacities given in Liftcrane Mast Capacities Chart when handling crawlers with mast. Crane will tip forward.

**CAUTION****Parts Damage!**

Avoid hitting carbody pedestals with crawlers.

**Remove First Crawler**

**NOTE:** With second crawler installed and **resting on ground**, first crawler can be lifted and swung 180° at a **maximum radius of 20 ft (3,5 m)**.

- Disconnect hydraulic hoses (Figure 4-15) between carbody and crawler:
  - Connect hose (11, View A) to coupler (12a).
  - Connect hose (12, View B) to coupler (11a).
  - Attach sealing cap to end of hose (13, View B) and to coupler (13a). Secure hose to carbody for shipping.
- Disconnect grease hose (14, Figure 4-15, View C) between carbody and crawler.
  - Attach sealing cap to end of hose and to coupler (14a).
  - Secure hose to carbody for shipping.
- Disconnect crawler drive (see Figure 4-17):
  - Unpin drive shaft guard (9, View D) and slide guard back.
  - Support drive shaft (4, View C) and remove flange screws (8). Store screws in carbody flange holes once drive shaft is disconnected.
  - Retract crawler drive shaft and place on storage bracket (5, View B).
- Attach chains (1, Figure 4-17, View F) between crawler pads (2) and crawler lugs (3) (four places). Chains should be snug to prevent treads from sagging when crawler is lifted.
- Swing rotating bed perpendicular to crawlers so rear jacks are over crawler to be removed

- Rotate rear jacks to working position and install jack pads (Figure 4-6, View C).
- Remove carbody pedestals from storage (Figure 4-6, View B).
- Extend rear jacks to lift crawler and install carbody pedestals under carbody (Figure 4-10, View C).
- Retract rear jacks to lower carbody onto pedestals.

Check position of carbody with relation to foundation. Carbody must be at least 22 in (559 mm) off foundation for crawler removal. Adjust pedestal screws if needed.

- Rotate rear jacks to horizontal (wing position) as shown in Figure 4-16, View C. Rear jacks will hit installed crawler if this step is not done before swinging.
- Swing 180° so assembly block from mast is centered over crawler.
- Attach hooks from chain sling (7, Figure 4-17, View E) to crawler as shown in Figure 4-14.
- Position chains between crawler pads.
- Tilt operator's cab up, as required, so crawler does not hit cab.
- Remove collars (3, Figure 4-16, View E) and retract crawler connecting pins (2) with crawler pins control (4 or 5, Figure 4-16, View H).
- Slowly hoist and boom up or down as required to lift crawler clear of carbody.
- Swing as required and lift crawler onto transport trailer.
- Disconnect slings from crawler and remove trailer.
- Engage crawler pins and install collars (3, Figure 4-16, View E).

**Remove Second Crawler****WARNING****Tipping Hazard!**

To prevent crane from tipping:

- Limit swing to 10° either side of center when handling second crawler (Figure 4-13, View E).

Repeat Remove First Crawler steps for second crawler.

**Do not swing more than 10° either side of center when handling second crawler.**

**Remove Assembly Block**

Follow instructions on page page 4-39.

## Lower Live Mast To Shipping Position

See Figure 4-12 for following procedure.



### WARNING

#### Falling Mast Hazard!

Do not raise mast to 115° until mast assist arms are fully raised. Mast will fall over backwards.

1. Select Liftcrane Mast Capacities Chart.
2. Increase engine speed to desired rpm.
3. If required, fully raise mast assist arms using mast switch on remote control.
4. BOOM UP with boom hoist control to lower live mast (1) to shipping position.  
  
Mast assist arms will support mast as cylinders retract automatically.
5. Release boom hoist control once mast comes to rest on supports at rear of rotating bed.
6. Fully lower mast assist arms using mast switch on remote control.

## Disconnect Hydraulic Lines and Electric Cables

See Figure 4-11 for following procedure.

1. Disconnect electric cables (3) from connectors (4) on right side of rotating bed.
2. Disconnect hydraulic hoses (2) from couplers (1) on both sides of rotating bed.
3. Thoroughly clean couplers and sealing caps and attach sealing caps to couplers.

## Raise Crane Off Carbody Pedestals

1. Rotate all four jacks to operating position and secure with struts (see Figure 4-7).
2. Remove jack pads from storage (Figure 4-7, View B) and attach to jacks (View C).

See Figure 4-10 for remaining steps.

3. Extend jacks until carbody is clear of pedestals.
4. Remove carbody pedestals and store.

## Place Carbody and Adapter Frame on Trailer

### CAUTION

#### Equipment Damage!

Use extreme care not to hit jacks with trailer when backing trailer into position:

Provide a signal person to give instructions to truck driver.

1. Center transport trailer under carbody.

Extend jacks as required to provide clearance.

**NOTE: Rotating bed must not be more than 3° out of level when extending or retracting rotating bed jacks.**

2. Slowly retract jacks to lower carbody and adapter frame onto trailer. Stop when trailer deck just starts to lower.

### CAUTION

Do not lower entire weight of rotating bed onto adapter frame. Weight may exceed trailer capacity.

3. Unlock keeper plate (9, Figure 4-9, View E) at both rear rotating bed pins.
4. Remove locking pins (10, Figure 4-10, View G) from front rotating bed pins (11) and store.
5. Disengage all four rotating bed pins with switches on remote control.

**Make sure each pin is fully disengaged.** Adjust jacks as required to free any binding.

6. Disconnect hydraulic hoses at rear rotating bed pins (Figure 4-11).
  - Connect hose (5a) to coupler (6b) at opposite end of cylinder.
  - Connect hose (6a) to coupler (5b) on rotating bed.
7. Fully extend jacks to lift rotating bed off adapter frame and carbody.
8. Remove trailer. **Take extreme care not to hit jacks with trailer. Provide a signal person to give instructions to truck driver.**
9. Rotate rear rotating bed pins (5, Figure 4-9, View E) to storage position:
  - a. Remove shipping pins (6, View E) and connecting pins (7).
  - b. Rotate rear rotating bed pins (5) to shipping position (View D).
  - c. Install shipping pins (6, View E) and store connecting pins (7).

## Remove Rotating Bed from Trailer

1. Center transport trailer under rotating bed.
2. Retract jacks to lower rotating bed onto trailer.  
Block both ends of rotating bed so it is firmly supported and fully retract jacks.
3. Rotate operator's cab to shipping position and secure with strut (Figure 4-8).
4. Remove jack pads from jacks (Figure 4-6, View C) and store (View B).
5. Rotate jacks to shipping position and secure (Figure 4-7).

## Remove Exhaust Pipes



### **WARNING**

#### **Burn Hazard!**

Exhaust pipes are hot. Take every precaution to prevent being burnt when pipes are removed.

---

*See Figure 4-4 for following procedure.*

1. Remove rear enclosure panels (1, View A).
2. Unhook springs (4, View B) from clips (5) and remove both exhaust pipes (2) from working position.
3. Store exhaust pipes (2) in enclosure frame (View A).
4. Remove both rain caps (3) from working position (View A).
5. Install rain caps in shipping position and connect springs (4, View B) to clips (5).
6. Install rear enclosure panels (1).

A13170




FIGURE 4-25



## BOOM LADDER ASSEMBLY

See Figure 4-25 for following procedure.



### WARNING

#### To Prevent Serious Injury or Death:

- Limit load on ladder to 300 lb (136 kg).
- Avoid improper use. Ladder is intended for use only on Manitowoc #58 boom inserts. Any other use is prohibited.
- Use ladder for boom assembly/disassembly and maintenance only when boom is horizontal.
- Make sure ladder is properly secured to insert.
- Keep hands free of any objects while climbing ladder. Objects which cannot be carried in pockets or tool belts shall be lifted into place onto ladder platform prior to climbing ladder.
- Stand only on platform. Do not stand on cross braces.

### General

Two ladders (2) are stored inside 40 ft (12 m) heavy insert (1) as shown in View A. The ladders are designed for use in assembly/disassembly and maintenance of #58 boom sections and components. Each ladder weighs approximately 15 lb (7 kg).

### Removing Ladders from Boom Butt

It is recommended that two people remove either ladder from the boom insert: one person inside the insert to unlatch and lift the ladder and another person outside the insert to help guide the ladder out of the insert. Use the following procedure:

1. Lower boom onto blocking at ground level. **Boom sections must be horizontal.**
2. Unhook rubber latches (5, View C).
3. Lift ladder (2) up and out of hooks (3, View C).
4. Guide ladder through lacings to outside of insert.

### Installing Ladders on Boom Inserts

Lift ladder (2) to desired outside location on insert so ladder is securely hooked over backside of upper chord and lower pad (6) is firm against lower chord (View D).

**Ladder must hang vertically against boom insert when in use.**

### Storing Ladders in Boom Butt

It is recommended that two people store either ladder in the boom insert: one person outside the insert to help guide the ladder into the insert and another person inside the insert to lift the ladder and latch it in position. Use the following procedure:



### WARNING

#### Falling Load Hazard!

Ladders must be properly stored to prevent them from falling out of insert when boom is raised.

1. Hang ladder rails over hooks (3, View B) inside insert.
2. Pull rubber latches (5) tightly over lower rails and latch in keepers (4, View B).
3. Make sure ladder cannot move once latched.

## BOOM RIGGING

### Assist Crane Requirements

Either the 16000 live mast or an assist crane can be used to handle and assemble the boom section. See Crane Weights in Section 1 for the weights of boom sections.

### Blocked Crawler

To prevent the crane from tipping, some boom and jib lengths must be raised and lowered over the end of blocked crawlers. See capacity charts for blocked crawler requirements and Crawler Blocking Diagram in Capacity Charts Manual for instructions.

Do not attempt to raise or lower boom from or to ground until crawlers are blocked, if required.



### WARNING

#### Tipping Hazard

Block ends of crawlers, if required, before you attempt to raise or lower boom from or to ground.

### Handling Components

Handle boom and jib sections with care to avoid damaging lacing and chords. The boom and jib sections have lifting lugs designed to provide a balanced load and to prevent damage during lifting.



### WARNING

#### Falling Load Hazard!

Lifting lugs on a particular boom or jib section are designed only for lifting that section only. Do not attempt to lift two or more boom or jib sections with lifting lugs only on one section. Lifting lugs may break allowing boom or jib sections to fall.

When lifting lugs are not used:

- *Lift against chords only, never against lacings.*
- Use nylon lifting slings. If wire rope or chain slings are used, install protective covering (such as sections of rubber tire) between slings and chords.

## Boom Assembly Drawing

Boom sections (top, inserts, straps) must be assembled in proper sequence according to Boom Assembly Drawing at the end of this section.



### WARNING

#### Collapsing Boom Hazard!

Boom can collapse if not assembled in correct sequence. Follow assembly sequence in Boom Assembly Drawing.

## Identifying Boom Sections and Straps

Boom and jib sections are marked for proper identification as shown in Figure 4-26, View A.

Straps and links are marked for proper identification as shown in Figure 4-26, View B.





FIGURE 4-26

*THIS PAGE BLANK*

A11388  
A11543  
A10740-24  
A10740-25



Item	Description	Item	Description
1	40 ft (12 m) Insert	11	Lug
2	Wire Rope Guide	12	Inserts
3	Pin with Snap Pins	13	Transition Insert
4	Fixed Horizontal Pin	14	Boom Top
5	Hooked Connector	15	Upper Boom Point Assembly
6	Bottom Connecting Pin	16	Pin with Snap Pins
7	Wire Rope Guide	17	Wire Rope Guide (Working Position)
8	Shipping Lug	18	Wire Rope Guide Struts
9	Pin with Snap Pins	19	Safety Pins
10	Strut		

FIGURE 4-27

**WARNING****Crushing Injury Hazard!**

Never work under or inside boom sections that are not securely blocked.

**WARNING****Falling Load Hazard!**

Luffing jib backstay straps can be stored on boom sections for shipping.

If jib will not be used, remove all jib backstay straps, links, and pins stored on boom sections.

**Assemble Boom Sections**

See Figure 4-27 for following procedure.

**Boom sections must be assembled in proper sequence.**

See Boom Assembly Drawing at the end of this section for assembly sequence.

1. If luffing jib will not be used, remove all jib backstay straps, links, and pins stored on boom sections.
2. Place 40 ft (12 m) insert (1) on blocking approximately 6 in. (152 mm) high. This insert has a sheave frame at top end of insert.

**NOTE:** Each boom section has four lifting lugs in top chords.

**WARNING****Pinch Point Hazard!**

Keep hands clear of openings in wire rope guide frame while raising or lowering wire rope guide in step 3.

3. If required for luffing jib or for auxiliary drum, raise wire rope guide (2, View A) to operating position:

- a. Attach a sling to rope guide pin.
- b. Support wire rope guide with hoist and remove pin (3) from shipping position.
- c. Raise wire rope guide to operating position and install pin (3).

4. Lift next insert into position and engage fixed horizontal pins (4, View D) in insert with hooked connectors (5) in adjacent insert.
5. Lower insert to horizontal and install both bottom connecting pins (6, View E).

**NOTE:** If intermediate suspension is required, standard bottom connecting pins (6) are replaced with longer connecting pins and links (see Figure 4-28 and Boom Assembly Drawing).

6. Block under top end of insert.
7. Repeat steps 4 – 6 for each remaining insert (12) and for boom top (14).

**NOTE:** Transition insert (13) must be installed next to boom top (14).

8. Raise boom top wire rope guide (7, View B) to operating position:
  - a. Attach a sling to hole in rope guide.
  - b. Support wire rope guide with hoist and remove pin (9) from shipping position.
  - c. Raise wire rope guide to operating position.
  - d. Store pin (9).
  - e. Unpin struts (10) from storage lugs (11) and pin to wire rope guide.
9. Raise wire rope guide (17, View G) to working position:
  - a. Remove safety pins (19) from shipping position.
  - b. Rotate wire rope guide up to working position.
  - c. Support guide and secure to struts (18) with safety pins (19).

A11543-1  
A11543-2




FIGURE 4-28

## Connect Boom Straps

See Figure 4-28 for following procedure.

The boom straps and links are shipped on the boom sections as shown in View B.

1. Connect straps (1, View A) at top end of butt and each insert, as follows:
  - a. Remove pins (3, View B) and rotate links (4) to working position (View A).
  - b. Pin links (4, View A) in working position.
  - c. Remove pin (5, View A) from end of each strap (1).
  - d. Rotate links (2a, View B) rearward and pin to adjacent strap with pin (5, View A).

**NOTE:** If intermediate suspension is required (see Boom Assembly Drawing), use links (2b, View C) in place of links (2a, View A).

Store links (2a) on link (10, View C).

## Install Intermediate Suspension

See Figures 4-28 and 4-29 for following procedure.

**NOTE:** Intermediate suspension is required at locations specified in Boom Assembly Drawing.

1. If not already done, replace links (2a, View A) with links (2b, View C).


See View C for remaining steps.

2. If not already done, remove and store standard pin (15a).
3. Using pin (15b), install link (14) and reconnect inserts.
4. Attach pendant (12) to link (14) with pin (13).
5. Connect pendant (12) and either adjustable link (8) or pendant (7a or 7b) to link (10) with pin (11).
6. If adjustable link (8) is required, pin pendant (7a or 7b) to adjustable link with pin (9).

**Pin pendant to proper holes in adjustable link as specified in Figure 4-29.**

7. Pin pendant (7a or 7b) to links (2b) with pin (6).
8. Repeat steps 1 – 7 on other side of insert.

When boom is raised, boom straps will lift intermediate suspension into position and support inserts.



A11388-4,5,6




FIGURE 4-30



## Install Standard Upper Boom Point

See Figure 4-27, View F for following procedure.

Do not install standard upper boom point if an extended upper boom point or luffing jib will be installed.

1. Using nylon lifting slings, lift upper boom point (15) into position at lower boom point.
2. Remove top pin (16) from holes in upper boom point.
3. Align upper holes (A) and install pin (16).
4. Rest upper boom point on ground.
5. Remove slings.
6. Slowly raise boom until bottom holes (B) are aligned.
7. Install pins (16) in holes (B).

---

### CAUTION

#### Avoid Upper Boom Point Damage!

Do not rest weight of entire boom on standard upper boom point. Structural damage will occur.


---

## Install Extended Upper Boom Point

See Figure 4-30 for following procedure.

Do not install extended upper boom point if a standard upper boom point or luffing jib will be installed.

1. Remove lower boom point, as follows:
  - a. Lower boom until sheaves in lower boom point (2) are just clear of ground.
  - b. Attach hooks from assist crane to lifting holes (3, View A) in lower boom point (2).
  - c. Remove lower pins (4, View B).
  - d. Hoist against lower boom point with assist crane until upper pins (5, View A) are loose and remove upper pins.
  - e. Swing lower boom point away from boom top and store.
  - f. Store pins (4 and 5) in lower boom point holes.
  - g. Lower boom top onto blocking at least 12 in (305 mm) high.
2. If installed, remove pins (6 or 6a, View C) with end plates and keeper plates (7) from boom top (1).



3. For past production units, proceed as follows:

See Figure 4-31 for following procedure.

- a. Remove pins (8, View A) to disconnect links (9) from storage position and rotate links (9) to vertical.
- b. Attach equal length lifting slings from assist crane to four lifting lugs (10, View A) on extended upper boom point (11).
- c. Lift extended upper boom point (11) off trailer and into position at boom top (1, View C).
- d. Align connecting holes in links (9, View B) with boom top (1) and install pins (8).
- e. Lower extended upper boom point until bottom holes are aligned.
- f. Install bottom pins (6, View D), keeper plates (7) and end plates.
- g. Lower upper boom point until rollers (12, View E) are on ground and disconnect lifting slings.

- h. If equipped with long top pins (6) in upper holes, store them with end plates (Figure 4-30, View C).
- i. Install short top pins (6a, View D) and outboard end plates.
- j. Securely tighten end plate screws for pins (6 and 6a).
- k. As boom is raised, extended upper boom point rollers (12) will roll along ground until links unfold. Upper point will then lift off ground as boom is raised.

**Make sure roller path is clear of obstructions.**

**WARNING**  
**Crush Hazard!**

Prior to raising boom, warn personnel to stand clear of extended upper boom point rollers.

Legend for Figure 4-31

Item	Description	Item	Description
1	Boom Top	9	Link
6	Pin (long) with End Plates and Hex Screws	10	Lifting Lug
6a	Pin (short) with End Plate and Hex Screws	11	Extended Upper Boom Point
7	Keeper Plate	12	Roller
8	Pin with Cotter Pins		




FIGURE 4-32

4. For current production units, proceed as follows:

See Figure 4-32 for following procedure.

- a. Remove pins (8, View B) to disconnect links (9a) from storage position and rotate links (9a) to vertical.
- b. Remove setup pins (13, View C) from storage lugs (14).
- c. Attach a lifting sling from assist crane to lifting lug (15, View A) on link (9b).
- d. Rotate links (9a and 9b, View A) up until setup pin (13) can be installed in setup lug (16).
- e. Install setup pin (13).
- f. Disconnect lifting sling.
- g. Repeat steps 4c – 4f at other set of links (9a and 9b).
- h. Attach equal length lifting slings from assist crane to four lifting lugs (10, View B) on extended upper boom point (11).
- i. Lift extended upper boom point (11) off trailer and into position at boom top (1, View E).
- j. If equipped with long top pins (6) in upper holes, store them with end plates (View C, Figure 4-30).
- k. Install bottom pins (6, View D), keeper plates (7), and end plates.

- l. Install short top pins (6a, View D) and outboard end plates.
  - m. Securely tighten end plate screws for pins (6 and 6a).
  - n. Rotate extended upper boom point up with assist crane (View G) to align connecting holes in links (9a, View F) with boom top (1).
  - o. Install pins (8).
  - p. Remove setup pins (13, View A) from setup lugs (16) and install pins in storage lugs (14, View C).
- Do not perform step 4q until pins (13) are removed, or damage will result.**
- q. Lower upper boom point until rollers (12, View H) are on ground and disconnect lifting slings.
  - r. As boom is raised, extended upper boom point rollers (12) will roll along ground until links unfold. Upper point will then lift off ground as boom is raised.

**Make sure roller path is clear of obstructions.**



Prior to raising boom, warn personnel to stand clear of extended upper boom point rollers.

Legend for Figure 4-32

Item	Description	Item	Description
1	Boom Top	10	Lifting Lug
6	Pin (long) with End Plates and Hex Screws	11	Extended Upper Boom Point
6a	Pin (short) with End Plate and Hex Screws	12	Roller
7	Keeper Plate	13	Setup Pin with Snap Pins
8	Pin with Cotter Pins	14	Storage Lug
9a	Link	15	Lifting Lug
9b	Link	16	Setup Lug

## Install Load Line

See Load Line Reeving instructions in this section for proper routing and reeving of load lines.

## Connect Boom Wiring

1. Install block-up limit components shown in Figure 4-33 and in Boom Wiring and Limits Electrical Drawing at end of this section.
2. Install wind speed indicator assembly if removed for shipping. Use star washers to attach mounting bracket to boom top to provide a good ground (see Wind Speed Assembly drawing at end of this section).
3. Connect electric cables from cable reel in boom butt to node controller in boom butt and to wireless transceiver in boom top (see Boom Wiring and Limits Electrical Drawing at end of this section).
4. Connect electric cables from block-up limit switches and wind speed transmitters to proper receptacles on boom and jib node controllers.
5. To protect electrical components:
  - a. Attach sealing caps to ends of all unused cables, unused receptacles, and unused terminator plugs.
  - b. If equipped, attach terminator plugs to unused receptacles.

## Perform Pre-Raising Checks

Perform following pre-raising checks and correct any defects before raising boom.

- ☐ Crane on firm, level surface.
- ☐ Crawlers blocked if required per Capacity Chart.
- ☐ All connecting pins installed and properly retained.
- ☐ Boom inserts installed in proper sequence.
- ☐ Boom straps installed in proper sequence.
- ☐ All jib backstay straps, links, and pins removed from boom sections (if luffing jib will not be used).
- ☐ All insert and strap connecting pins installed and properly retained.
- ☐ Mast arms fully lowered.
- ☐ Boom hoist wire rope spooled tightly onto drum and engaged with proper sheaves. Wire rope securely anchored to socket and wedge at mast.
- ☐ Load lines spooled tightly onto drums and engaged with proper sheaves. Load lines securely anchored to sockets at boom points or at load block and weight ball.
- ☐ All blocking, tools, and other items removed from boom.
- ☐ Electronic boom angle indicator properly installed and adjusted.

- ☐ Block-up limit control properly installed and operational.
- ☐ Rated Capacity Indicator/Limiter properly installed and operational.
- ☐ Proper capacity chart selected on configuration screen of RCL display.
- ☐ Automatic boom stop properly installed. Must be adjusted after boom is raised.
- ☐ Crane and attachment properly lubricated.
- ☐ Wind within allowable limits for operation.

## Boom Removal

Boom removal is the reverse of installation.



### WARNING

#### Tipping Hazard!

Prevent crane from tipping. Block ends of crawlers, if required per capacity chart, before raising or lowering boom from or to ground.



### WARNING

#### Crushing Injury Hazard!

Boom inserts can collapse when connecting pins are removed. Block both ends of each boom insert before removing connecting pins.

Never work under or inside boom inserts that are not securely blocked.

1. Prepare crane and boom as follows:
  - a. Position crane in disassembly area.
  - b. If required per capacity chart, travel front crawler rollers onto blocking (at boom end of crane).  
See Crawler Blocking Diagram in Capacity Chart Manual for blocking requirements.
2. Lower boom to ground as follows:
  - **If equipped with a fixed or luffing jib**, see Jib Rigging Guide for procedure.
  - **If equipped with a standard upper boom point**, remove it (reverse assembly steps) before upper point contacts ground. *Upper point cannot support weight of boom.*
  - **If equipped with an extended upper boom point**, make sure ground is clear of obstruction so upper point rollers can roll freely as boom is lowered.

**CAUTION****Pendant Damage!**

Use extreme care while lowering boom equipped with intermediate suspension. Boom straps can land on and crush intermediate suspension pendants.

**WARNING****Crushing Injury Hazard!**

Do not attempt to unpin straps until they are resting firmly in strap brackets.

3. Continue to lower boom onto blocking until boom straps are resting in brackets on boom inserts.

***Push intermediate suspension pendants to inner side of boom as boom is lowered.***

4. Remove and store intermediate suspension pendants, links and pins. *Block under inserts before removing lower connecting pins.*
5. Store insert straps and links.

**NOTE:** It is not necessary to remove the boom straps. The straps can be left on the inserts for shipping.

- a. Rotate links (2a, Figure 4-28, View B) at front end of butt and inserts forward for storage.
- b. Rotate storage links (4, Figure 4-28, View B) to shipping position and pin to secure links and straps.
6. Remove and store block-up limit components (see Boom Wiring and Limits Electrical Drawing at end of this section).
7. Remove and store wind speed indicator assemblies so they cannot be damaged during shipping (see Wind Speed Assembly drawing at end of this section).
8. Disconnect electric cables from cable reel in boom butt at node controller in boom butt and at wireless transceiver in boom top (see Boom Wiring and Limits Electrical Drawing at end of this section).
9. Coil cable onto cable reel.
10. Disconnect electric cables between boom top and upper point or luffing jib.
11. To protect electrical components:

- a. Attach sealing caps to ends of all unused cables, unused receptacles, and unused terminator plugs.
- b. If equipped, attach terminator plugs to unused receptacles.

12. Disconnect load lines from load block and weight ball and spool load lines onto load drums.
13. Remove luffing jib if installed.
14. Remove extended upper boom point if installed (reverse assembly steps).
15. Lower wire rope guide (17, View G) to shipping position:
  - a. Support wire rope guide (17).
  - b. Remove safety pins (19) from struts (18).
  - c. Rotate wire rope guide down to shipping position and install safety pins (19).
16. Store boom top wire rope guide (Figure 4-27, View B):
  - a. Attach a sling to hole in wire rope guide (7).
  - b. Support wire rope guide (7) with hoist.
  - c. Unpin struts (10) from wire rope guide and pin to storage lugs (11).
  - d. Lower wire rope guide (7) to shipping position.
  - e. Using pin (9) pin lug (8) to upper boom point.



**WARNING****Pinch Point Hazard!**

Keep hands clear of openings in wire rope guide frame while lowering wire rope guide in step 17.

17. Store wire rope guide in 40 ft (12 m) heavy insert (Figure 4-27, View A):
  - a. Attach a sling to rope guide pin.
  - b. Support wire rope guide (2) with hoist and remove pin (3) from operating position.
  - c. Lower wire rope guide to shipping position and install pin (3).
18. Disassemble boom sections.
19. Disconnect boom butt from boom. See procedure in this section.

**NOTE:** If shims are used, store shims on boom pins.

Item	Description	Item	Description
1	Wire Rope Guide	5b	Pin
2a	Lower Boom Point	6	Weight
2b	Extended Upper Boom Point (lower sheaves)	7	Lift Plate
3a	Standard Upper Boom Point	8	Load Block
3b	Extended Upper Boom Point (upper sheave)	9	Weight
4	Block-Up Limit Switch	10	Lift Block
5	Chain	11	Weight Ball
5a	Shackle		



Location of Components at Boom Top Shown  
Location of Components at Jib Tops is Similar

See Load Block Reeving Diagrams for  
Suggested Location of Weight with  
Multiple Part Reeving

FIGURE 4-33






FIGURE 4-33 continued

## WIRE ROPE INSTALLATION

**NOTE:** Wire rope manufacturer's recommendations take precedence over information in this section.

### Wire Rope Storage

Store wire rope in coils or on reels off the ground or floor in a clean and dry indoor location. If outdoor storage is necessary, the wire rope must be covered with a protective wrapper. Keep the wire rope away from acids, fumes, and other corrosives. Keep the wire rope away from heat that can dry out the lubricant. If the storage period will be long, lubricate the wire rope and perform periodic inspection given in this section at least monthly.


### Removing Wire Rope from Shipping Reel

#### CAUTION!

##### Wire Rope Damage!


Shipping reel must rotate when wire rope is unwound. Attempting to remove wire rope from a stationary reel can result in a "kinked" wire rope, and wire rope will be ruined.

1. Mount wire rope shipping reel on a shaft supported at both ends by jacks or blocks as shown in Figure 4-34.



**FIGURE 4-34**

2. Provide a brake at shipping reel (see Figure 4-35) so wire rope can be wound tightly onto drum.



**FIGURE 4-35**

3. Avoid a reverse bend when winding wire rope onto drum: wind from top of reel to top of drum or from bottom of reel to bottom of drum as shown in Figure 4-35.
4. Avoid dragging wire rope in dirt or around objects that can scrape, nick, cut, or crush wire rope.

### Seizing and Cutting Wire Rope

Apply tight seizings of annealed wire to the ends of all wire rope. If not done, the rope wires and strands may slacken. This action will result in overloading of some strands and underloading of others. Bird caging and breakage of the wire rope can occur.


Before cutting wire rope, apply seizings on both sides of the point where the cut will be made. Then cut the wire rope with a torch, rope cutter, or abrasive cut-off wheel.

See Figure 4-36 for:

- Number of seizings to be applied to the ends of wire rope and to both sides of the point where a cut will be made.
- Proper application method. Each seizing should be one rope diameter long.


Wire Rope Type	Seizings Required
Preformed	1
Non-preformed	3

Place free end of seizing wire in valley between two stands. Then wind seizing wire over free end as shown. Finally, twist and pull two ends of seizing wire together until seizing is tight.



**View A** — Rope Diameter 1 in (26 mm) and Larger

Wind seizing wire around wire rope as shown. Then twist two ends of seizing wire together at center of seizing. Alternately twist and pull ends until seizing is tight.



**View B** — Rope Diameter Smaller than 1 in (26 mm)

A925

**FIGURE 4-36**

## Anchoring Wire Rope to Drum

See Figure 4-37 for following procedure.

Use the correct wedge part number for the size of wire rope being used; see parts drawing for the boom hoist drums or for the load drum shaft to obtain the correct part number.

1. Assemble wire rope and wedge to drum socket.
2. Tighten wedge, rapping back of wedge with a brass drift pin and hammer.

## Drum Guards

The drums are equipped with guards which cover the dead-end sockets on the outside of the drum flanges.



### WARNING

#### Moving Machinery Hazard!

Guards must be secured to drums during crane operation. When guards are removed for wire rope installation, use extreme care to prevent injury from a moving dead-end socket.




### WARNING!

#### Falling Load Hazard!

Wire rope can be pulled out of drum if following steps are not taken.

- Install straight wedge so corrugated side is against wire rope.
- Install wedge so end of wire rope extends past end of wedge, but not out of drum socket.
- Make sure seizing is not under wedge. Remove seizing if it interferes with assembly.



**FIGURE 4-37**

***THIS PAGE BLANK***

## Winding Wire Rope onto Drum

See Drum and Lagging Chart in Capacity Chart Manual for correct size of drum laggings, if used.

See Wire Rope Specifications Chart in Capacity Chart Manual for correct type, size, and amount of wire rope to be installed on load drums.

See Boom Assembly Drawing at end of this section for correct type, size, and amount of wire rope to be installed on boom hoist drums.

1. Carefully inspect drums and all rope guides, rollers, and sheaves for defects that can cause wire rope to wear or be cut. If defects cannot be fixed, replace faulty parts.
2. Apply tension to wire rope as it is wound slowly onto drum.

First wrap must be tight against drum flange for approximately three-fourths of drum diameter (see Figure 4-38).

3. Tap adjacent wraps against each other with a soft metal or wooden mallet.


Use extreme care not to put twists or turns in wire rope; allow rope to assume its natural lay.

### CAUTION!

#### Wire Rope Damage!

Voids or spaced wraps in first layer (see Figure 4-38, View B) will permit movement and a wedging action with subsequent layers. Wedging action will cause crushing and abrasion of wire rope.

Never allow wire rope to “cross wind” on drums.



**TL (Tail Length)****Standard 6 to 8 Strand Wire Rope**

Minimum of 6 rope diameters,  
but not less than 6 in (152 mm).



**Rotation Resistant Wire Rope**

Minimum of 20 rope diameters,  
but not less than 6 in (152 mm).

**T (Rope Clip Nut Torque)**

	Wire Rope/Clip Size			
inch (mm)	7/8 (22,23)	1 (25,4)	1-1/8 (28,58)	1-1/4 (31,75)
	Torque			
* ft/lbs (kN/m)	225 (0,30)	225 (0,30)	225 (0,30)	360 (0,49)

\* Tightening torque values shown are based on threads  
being clean, dry and free of lubrication.

**ALL ARE DANGEROUS AND PROHIBITED!****FIGURE 4-39**

A925

## Anchoring Wire Rope to Wedge Socket



### WARNING

#### Falling Load Hazard!

- Inspect all parts prior to use. Do not use parts that are cracked or otherwise defective.
- Remove minor nicks, burrs, or rough edges from socket, wedge, or pin by lightly grinding. Do not reduce original dimensions by more than 10%.
- Do not reinstall shipping material (bolt, plastic strap or wire) in hole of wedge or socket after assembling. Discard these materials because they can prevent wedge from tightening in socket.
- Only use a wedge and socket which are correct size for wire rope being used. Do not mix and match parts from one assembly with parts from another assembly. Terminator™ socket and wedge has “go” and “no-go” holes to check for proper rope size.
- Attach wire rope clip to dead end of wire rope after assembling wire rope to wedge and socket.
- If dead end of wire rope is welded, seize end of wire rope and cut off weld before assembling to wedge and socket. Weld will not allow strands of wire rope to adjust around bend of wedge, resulting in high strands and wavy rope. This condition can seriously weaken attachment.

See Figure 4-39 for following procedure.

1. Assemble wire rope and wedge to socket so live end of wire rope is in a straight line with socket pin hole. *Do not assemble WRONG as shown.*
2. Allow dead end of wire rope to extend past end of socket amount shown.
3. Allow wire rope to assume its natural lay.
4. Pull against wedge and live end of wire rope enough to tighten wedge in socket.

Use a brass hammer to seat wedge and wire rope as deep into socket as possible.

5. Attach a wire rope clip to dead end of wire rope using one of the RIGHT methods shown. Rope clip will aid in preventing wire rope from being pulled out of socket.

**NOTE:** Use Right Method A only if wire rope clip is small enough to be securely tightened to dead end. Right Method C is only for a Terminator socket and wedge.

6. After socket is pinned in place, hoist load slowly so wedge seats tight. *Do not shock load socket and wedge.*

## Anchoring Wire Rope to Button Socket



### WARNING


#### Falling Load Hazard!

Wire rope can break if following precaution is not observed:

- Do not attach dead end of wire rope to live end of wire rope with wire rope clip. Wire rope clip will transfer load from live side of wire rope to dead end, seriously weakening attachment.

See Figure 4-40 for following procedure.

1. Remove pin from socket.
2. Install button end of load line in socket.
3. Pin socket to anchor point.
4. Securely tighten locking screw.



**FIGURE 4-40**

## Breaking in Wire Rope

After installing a new wire rope, break it in by operating it several times under light load and at reduced speed. This practice allows the wire rope to form its natural lay and the strands to seat properly.

**NOTE:** Wire rope will stretch during the break-in period, reducing the wire rope's diameter as the strands compact around the core.

The dead wraps of wire rope on the drum can become slack during operation, even if the utmost care is used during installation of the wire rope. This slackening is caused by the normal stretch that occurs in a new wire rope under tension and periodically throughout the wire rope's life from release of the load.

When slackness is noted, tightly wind the dead wraps of wire rope onto the drum. If left uncorrected, a wedging action with subsequent layers will occur, and the resultant abrasion may cause broken wires in the dead wraps.

## DRUM KICKER ADJUSTMENT

### General

A drum kicker (see Figure 4-41) is provided on both flanges of the main load drum (in boom butt) to improve wire rope spooling for long boom lengths with small fleet angles where the wire rope might stack up along either drum flange.

Observe the wire rope during initial break-in and periodically during operation. If the rope stacks up at either end of the drum, adjust the drum kickers.




FIGURE 4-41

### Adjustment

See Figure 4-41 for following procedure.

To move drum kickers (1) into the drum (take up space), proceed as follows:

1. Remove drum guard from both ends of drum.
2. Remove an equal number of washers (3) from both sides of kicker (1), one side at a time. Each washer allows kicker to move 0.098 in (2,5 mm).

3. Loosely reinstall cap screws (2) and remaining washers (3).
4. Loosen lock nuts (4) and adjust set screws (5) to move kickers (1) into drum.
5. Repeat steps 1-3 only enough to improve spooling. **Moving drum kickers in too far can cause premature wire rope wear.**
6. Securely tighten set screws (5) and lock nuts (4).
7. Reinstall drum guards.

## PAD EYE USAGE FOR WIRE ROPE REEVING

See Figure 4-42 for following procedure.

### General

Some rotation-resistant wire rope supplied by Manitowoc is equipped with a No. 1.5 pad eye welded to the leading end of the wire rope or to the button on the end of the wire rope.

A rigging line can be attached to the pad eye to make it easier to reeve the load block.

### Safety

1. For No. 1.5 pad eye, do not exceed 1,000 lb (4,45 kN) single line pull.
2. Make sure rigging line and attaching hardware (clips and rope connectors) are rated for at least 1,000 lb (4.45 kN) line pull.
3. Inspect pad eye prior to each use. **Replace it if:**
  - Any original dimensions have changed.
  - Cracks or breaks exist in metal or weld.



### WARNING

#### Flying Part Hazard!

Pad eye on end of wire rope has been provided **for reeving purposes only**. Any other use is neither intended nor approved.

Pad eye can break and fly apart with considerable force if it is overloaded, not used properly, or not maintained properly.




A1189  
A09310

FIGURE 4-42

## RIGGING WINCH OPERATION

If your crane is equipped with the optional rigging winch (Drum 0) see the Rigging Winch Assembly drawing at the end of this section for wire rope routing.

### Selecting Rigging Winch Mode


See Figures 4-43 and 4-44 in following procedure.

#### TO TURN RIGGING WINCH MODE ON —

1. Go to Function Mode screen in main display.
2. In **level 2**, use the select buttons to enter selected drum screen options. Select rigging winch data box (Figure 4-43).

**NOTE:** The rigging winch data box will only appear if this feature is available.

3. In **level 3**, enter data box and use the select buttons to **turn ON** rigging winch.
4. The yellow box with "I" icon appears when winch is ON.



5. Drum 4 handle (boom hoist) will now control the rigging winch (Drum 0). "0" will appear in the indicator at the boom hoist handle.

#### TO TURN RIGGING WINCH MODE OFF —

1. Go to Function Mode screen in main display.
2. In **level 2**, use the select buttons to enter selected drum options screen. Select rigging winch data box (Figure 4-43).
3. In **level 3**, enter data box and use the select buttons to **turn OFF** rigging winch.

**NOTE:** The rigging mode will automatically turn OFF when power to the control system is turned off.

## Operating Rigging Winch

### Free-Wheel Operation


The winch has a free-wheel clutch which allows the drum barrel to be disconnected from the drive mechanism. This position allows the drum to be turned by hand.

#### TO TURN FREE-WHEEL ON —

1. Pull out locking pin (1) and hold.
2. Pull out knob (2).
3. Release locking pin (1).

#### TO TURN FREE-WHEEL OFF —

1. Pull out locking pin (1) and hold.
2. Push knob (2) in.
3. Release locking pin (1).



### Power Operation

1. Engage free-wheel feature.
2. Turn on rigging winch mode.
3. Pay out rigging line by moving Drum 0 control handle forward.
4. Reeve rigging line through block and boom point and connect to desired load line as shown in Rigging Winch Assembly drawing at end of this section.
5. Use engine throttle to snug up rigging line prior to paying out load line from selected load drum. Faulty operation

will result if there is slack in rigging line before engaging automatic part of operation.

**NOTE:** Use engine throttle to increase and decrease rigging winch line pull.

6. Use engine throttle speed to control line slack at rigging winch.
7. Move Drum 0 control handle to off and push corresponding load drum control handle forward to pay out load line. Rigging winch will haul in rigging line automatically.

**NOTE:** The stall line pull of the rigging winch is regulated with a proportional relief valve controlled by the crane's programmable controller.

---

### CAUTION!

#### Avoid Rigging Winch or Wire Rope Damage!

Rigging winch will not automatically pay out line if selected load drum control handle is pulled back to hoist position.

***Structural damage to winch or rigging line will occur!***

If it is necessary to haul in load line on load drum when load line is connected to rigging line, proceed as follows:

- Pay out rigging line with Drum 0 control handle while hauling in load line with load drum control handle.
  - Keep rigging line slacker than load line with engine throttle.
- 



### WARNING

#### Flying Object Hazard!

Do not attempt to disconnect rigging line from load line until lines are slack.

***Lines could fly apart with explosive force and strike personnel.***

---

8. Once load line is reeved through block and boom point:
  - a. Move load drum control handle to off.
  - b. Pay out rigging line to slacken load line by pushing Drum 0 handle forward.
  - c. Disconnect rigging line from load line.
  - d. Haul in rigging line for storage on rigging winch by pulling Drum 0 control handle back.
  - e. Secure end of rigging line to boom for storage.
  - f. Connect load line to dead-end socket. See instructions in this section.
  - g. Turn OFF rigging winch mode.

## REEVING – LOAD BLOCK

### Load Block Identification

See the Boom Assembly Drawing at the end of this section for a complete list of load blocks and weight balls available for this crane.



### WARNING

#### Falling Load Hazard!

Use only a load block with a capacity equal to or greater than load to be handled.

Avoid overloading load block sheave bearings. Attach load to duplex hook so load hangs straight.

Load block can fail if overloaded, allowing load to fall.

### Wire Rope Specifications

See Wire Rope Specifications chart in Capacity Chart Manual for the following load block reeving information:

- Parts of line required to handle desired load.
- Wire rope length required for various boom lengths and parts of line.
- Maximum spooling capacity of load hoists.

### Wire Rope Installation

See Wire Rope Lubrication in section 5 of this manual for lubricating wire rope.

See Wire Rope Installation this section for instructions:

- Installing wire rope on drums.
- Anchoring wire rope to drums.

### Duplex Hook

Attach the load so it is balanced equally on the hook. Lifting slings must be within angles given in Figure 4-45 to achieve maximum hook capacity. The duplex hook has a hole to which an optional shackle can be attached as shown in Figure 4-45.



### WARNING

#### Falling Load Hazard!

Limit load to be handled with shackle to capacity of load block or shackle, whichever is less.

Load block or shackle can fail if overloaded, allowing load to fall.




FIGURE 4-45

### Guide Sheaves and Drums

See Figure 4-46 for identification of the load drums and guide sheaves.

Once wire rope is routed through the guide sheaves, be sure to install rope guard pins, bars, and rollers to retain the wire rope on the sheaves. **Wire rope and sheaves can be damaged if rope is not properly retained on sheaves.**

### Load Block Reeving


See Figure 4-47 and Figure 4-48 for dead-end locations and components in the lower and upper boom points.

See Figure 4-49 for load block reeving. Reeving the load block in any manner other than shown can result in excessive block twist.

### CAUTION

#### Wire Rope Damage!

Do not hoist load block closer to boom point than shown on Range Diagram in Capacity Chart Manual. Improper fleet angle or contact with other parts can damage wire rope.



Item	Description
1	Main Hoist (Drum 1 in boom butt)
2	Whip Hoist (Drum 2 in crane)
3	Auxiliary Hoist (Drum 3 in boom butt)
4	Wire Rope Guide (on boom butt)
5	Wire Rope Guides (in insert)
6	Wire Rope Guide (on boom top)
7a	To Lower Boom Point
7b	To Extended Upper Boom Point (lower sheaves)
8a	To Standard Upper Boom Point
8b	To Extended Upper Boom Point (upper sheave)

**NOTE:** See Wire Rope Specifications Chart for line pull of drums. Drums 2 and 3 do not have same line pull as Drum 1.

Drum 2 has a high-speed option. This option does not increase line pull – only speed. High-speed is approximately 80% faster than standard speed (depending on load and layer).

**FIGURE 4-46**

A08493





Figure 4-47

A11388




4

Item	Description
1	Lower Boom Point
2	Wire Rope Guide (on boom top)
3	Luffing Hoist Guide Sheave
4	Whip Hoist Guide Sheave
5	Main Hoist Guide Sheave
6	Dead-End Link
7	Pin with Cotter Pin
8	Load Cell – 35,000 lb (13 063 kg)
9	Links
10	Pin with Collar, Retaining Pin, and Cotter Pins
11	Swivel
12	Button Socket – 1-1/8 in (28 mm) with Pin and Cotter Pin

**Battery Side of Wireless Load Cell Anchored to Boom Point Must Face Away from Crane**

FIGURE 4-48

Reeving 1



## LOWER BOOM POINT REEVING

Item	Description
1	Boom Top Guide Sheaves
2	Lower Boom Point
3	Load Block
4	Standard Upper Boom Point
●	Dead-End Socket
■	Two-Block Weight









FIGURE 4-49



Reeving-2

LOWER BOOM POINT REEVING




FIGURE 4-49 continued

Item	Description
1	Boom Top Guide Sheaves
2	Extended Upper Boom Point (lower sheaves)
3	Load Block
●	Dead-End Socket
■	Two-Block Weight

EXTENDED BOOM POINT REEVING  
(Lower Sheaves)




FIGURE 4-50

REEVING – LIVE MAST

General

The live mast wire rope must be reeved between Drum 4 and the mast hoist sheaves as shown in Figure 4-51.

Use *Manitowoc #15836 wedge* for anchoring the wire rope to the drum sockets.

Wire Rope Specification


Manitowoc recommends the following wire rope for the live mast:

*Manitowoc #A05680 —*

1,620 ft (494 m) of 1-1/8 in (28 mm) Constructex  
Minimum Breaking Strength 159,000 lb (707 kN)

Rope diameter at no load:

- 1.160 in (29,46 mm) maximum
- 1.136 in (28,85 mm) minimum



## SECTION 5

### LUBRICATION

#### TABLE OF CONTENTS


Symbol Identification . . . . .	5-1
General Lubrication . . . . .	5-1
Lubrication Intervals. . . . .	5-1
Over-Lubrication . . . . .	5-1
Lubrication Tips . . . . .	5-1
Oil Can Points . . . . .	5-2
Wire Rope Lubrication . . . . .	5-2
Cylinder Rod Lubrication . . . . .	5-2
General . . . . .	5-2
Protecting Cylinder Rods . . . . .	5-2
Environmental Protection. . . . .	5-2
Reference Instructions. . . . .	5-2
CraneLUBE . . . . .	5-2
Approved Lubricants For Normal Operation . . . . .	5-4
Grease . . . . .	5-4
Open Gear Oil. . . . .	5-4
Gear Oil. . . . .	5-4
Hydraulic Oil . . . . .	5-4
Hydraulic Filter Replacement. . . . .	5-5
Lubrication Points . . . . .	5-5
Fluid Capacities . . . . .	5-6
Approved Lubricants For Arctic Operation. . . . .	5-7
Upper and Lower Lubrication Points — Location . . . . .	5-8
Engine Components . . . . .	5-11
Upper and Lower Lubrication Points — Identification . . . . .	5-12
Prior to Use When Crane is Assembled . . . . .	5-12
Every 8 Hours of Operation or Daily (whichever comes first) . . . . .	5-12
Every 8 Hours of Operation or Daily Continued . . . . .	5-13
Every 40 Hours of Operation or Weekly (whichever comes first) . . . . .	5-14
After First 200 Hours of Operation . . . . .	5-14
Every 200 Hours of Operation or Monthly (whichever comes first) . . . . .	5-15
Every 500 Hours of Operation or Quarterly (whichever comes first) . . . . .	5-15
Every 1000 Hours of Operation or Semiannually (whichever comes first) . . . . .	5-16
Boom Rigging Lubrication . . . . .	5-18
Prior to Operation . . . . .	5-19
Every 8 Hours of Operation or Daily (whichever comes first) . . . . .	5-19
Every 40 Hours of Operation or Weekly (whichever comes first) . . . . .	5-19
Every 200 Hours of Operation or Monthly (whichever comes first) . . . . .	5-19
Every 2000 Hours of Operation or Annually (whichever comes first) . . . . .	5-19
Automatic Lubrication System . . . . .	5-20
Operation . . . . .	5-20
Daily Inspection. . . . .	5-20
Automatic Lubrication System Troubleshooting . . . . .	5-22



SECTION 5  
LUBRICATION

SYMBOL IDENTIFICATION

The following symbols are used in decals on the crane to identify lubrication points.



**WARNING**

**Personal Injury Hazard!**

Personal injury can occur if safety precautions which follow are not taken before and after servicing machinery.

- Stop engine and wait until all moving parts have completely stopped (if necessary, position any grease fittings on moving parts at access point; then stop engine).
- Attach WARNING “out-of-order” sign to engine start control in operator’s cab to warn all personnel that crane is being serviced.
- Do not operate crane until all safety guards and covers have been securely reinstalled and all maintenance equipment has been removed.

GENERAL LUBRICATION

This section describes the major lubrication considerations for this crane. Some points requiring lubrication (linkage in control members not equipped with grease fittings) have been omitted, but they should be lubricated in accordance with good maintenance practices (see Oil Can Points).

The lubrication intervals for vendor-supplied parts (engine, light plant, etc.) have also been omitted from this Lubrication Guide; **service vendor-supplied parts according to the original equipment manufacturers’ manuals.**

Depending on the options your crane is equipped with, some lube points given in this section may not apply to your crane.

LUBRICATION INTERVALS

The intervals listed in this Lubrication Guide are for **average operating conditions** based on experience gained by testing lubricants at the factory and on recommendations given by the lubricant suppliers. Severe operating conditions (excessively dusty or corrosive atmosphere, unusually high or low outside temperature, extreme loadings, uncommonly frequent or long operating cycles) may require shortening the lubrication intervals. Follow the intervals given in this Lubrication Guide until adequate experience is obtained to establish intervals which meet your operating conditions.

Bearings and bushings that are too warm, excessive play in moving parts, binding in moving parts, excessive or abnormal wear in gears and chains, and rust accumulation indicate a lack of lubrication. If these conditions are found during regular inspection, the lubrication interval for the faulty parts should be shortened.

**CAUTION**

**Machinery Damage!**

Before lengthening lubrication intervals, check that all parts are receiving an adequate supply of clean lubricant; otherwise, parts will be damaged from a lack of lubrication. Contact your Manitowoc distributor for recommendations on lengthening lubrication intervals.

OVER-LUBRICATION

Over-lubrication is not only wasteful but also harmful:

- Excess lubrication can work its way onto friction surfaces and result in faulty operation.
- Oil or grease which drips onto walkways can cause personnel to slip and be hurt.
- Too high an oil level can cause churning and foaming of the oil and result in excessive heat and over-flow from the reservoir.
- An extra shot of grease, if too stiff or under too much pressure, can pop out a bearing seal.

LUBRICATION TIPS

- Check all oil levels before start-up so the oil has had a chance to run down from the reservoir walls and moving parts.
- Avoid introducing dirt into reservoirs. Carefully clean the area around dipsticks, level plugs, fill plugs, and breathers before removing.

- Replace level plugs, fill plugs, drain plugs, and breathers snugly and wipe up any spillage.
- Keep oil and grease dispensers and containers tightly closed and stored in a dirt and moisture-free locations.
- Clean grease fittings before and after applying grease.
- Apply grease until the bushing or bearing is purged so dirt and water cannot enter. Wipe up excess grease.

## OIL CAN POINTS

Oil **all pins** not equipped with grease fittings with engine oil every 40 hours of operation (even if the crane is not being operated).

## WIRE ROPE LUBRICATION

New wire rope is lubricated during manufacturing, but this lubricant is only adequate for initial storage and the early stages of operation. To prevent the damaging effects of corrosion and to reduce wear, the wire rope must be lubricated at regular intervals.

Contact your wire rope manufacturer/dealer for lubrication recommendations. The lubrication interval and the type of lubricant used depends on the type of wire rope, the severity of duty, and the type of corrosive elements the wire ropes is subjected to.

- The wire rope must be properly protected at all times.
- The lubricant must be fluid enough to fully penetrate the strands and rope core. Use one of the methods shown in Figure 5-2 to lubricate the wire rope.
- For maximum penetration, apply lubricant where the wire rope “opens up” as it travels around a sheave or winds onto a drum.
- The wire rope must be clean and dry before applying lubricant; an air jet, or wire brush are some cleaning methods.

***Do not use grease to lubricate wire rope. Grease will not penetrate rope properly and will buildup in valleys between wires and strands. This buildup will inhibit rope inspection and could trap moisture in rope's interior.***

## CYLINDER ROD LUBRICATION

### General

The cylinder rods on Manitowoc cranes have a layer of chrome plating on their surfaces to help protect them from corrosion.

Inherently, however, the chrome plating has cracks in its structure which can allow moisture to corrode underlying steel. Depending on ambient temperature and the frequency of cylinder operation, the crane's hydraulic oil may not

penetrate these cracks and protect the rods. And, even if the cylinders are operated on a regular basis, many cylinders have portions of exposed rod even when the cylinders are fully retracted.

Exposed cylinder rods on cranes that are stored, transported, or used in inclement environments (high humidity, rain, snow, and salt air) are at high risk of corrosion.

## Protecting Cylinder Rods

All exposed cylinder rods must be protected by applying a thorough coat of cylinder-rod protectant available from Manitowoc in 12 oz. aerosol cans — order part number 9999101803. The cylinder-rod protectant contains solvents and lubricants that penetrate metal pores, displace moisture, dissolve existing corrosion, and then dry to a resilient waxy coating. Cylinder operation and weather will remove the protectant over time. Therefore, inspect all cylinder rods weekly and reapply protectant to exposed rods.

See Crane Service Manual for detailed information on specific maintenance checks and procedures.

## ENVIRONMENTAL PROTECTION

***Dispose of waste properly!*** Improperly disposing of waste can threaten the environment.

Potentially harmful waste used in Manitowoc cranes includes — but is not limited to — oil, fuel, grease, coolant, air conditioning refrigerant, filters, batteries, and cloths which have come into contact with these environmentally harmful substances.

Handle and dispose of waste according to local, state, and federal environmental regulations.

When filling and draining crane components: do not pour waste fluids onto the ground, down any drain, or into any source of water.


- Always drain waste fluids into leak proof containers that are clearly marked with what they contain.
- Always fill or add fluids with a funnel or a filling pump.
- Immediately wipe up any spills.

## REFERENCE INSTRUCTIONS

See Crane Service Manual for detailed information on specific maintenance checks and procedures.

## CraneLUBE

Manitowoc highly recommends the use of CraneLUBE lubricants to increase your crane's reliability and performance. Contact your Manitowoc distributor for detailed information about our CraneLUBE lubrication program.



## APPROVED LUBRICANTS FOR NORMAL OPERATION

### Grease

#### Manitowoc Factory Fill

- See Table 5-1.

Table 5-1 Grease

Turntable Bearing and Crawlers	Temperature Range	Application
CraneLUBE XHP 320 Mine	0°F (-18°C) and above	Automatic Lubrication Systems *
CraneLUBE XHP 322 Mine	0°F (-18°C) and above	Manual Lubrication

\*CraneLUBE XHP 321 Mine can be used for automatic lubrication systems in temperatures 40°F (4°C) and above.

Other Grease Points	Temperature Range	Application
CraneLUBE E.P. # 2	0°F (-18°C) and above	All Other Grease Points

**NOTE** For all operation below 0°F (-18°C) use arctic grease specified in Approved Lubricants for Arctic Operation topic in this section.

### Open Gear Oil

This type oil requires heating or thinning for proper application to gear teeth. Apply a light film of oil to each gear tooth; *do not rely on gear rotation to distribute oil.*

#### Manitowoc Factory Fill

- CraneLUBE 375 NC.

### Gear Oil

#### Manitowoc Factory Fill

- CraneLUBE 75W-90 for all gear boxes except crawler.
- CraneLUBE 80W-140 for crawler gear boxes.

Table 5-2 Gear Oil

SAE Grade Gear Oil	Ambient Temperature Range	Where Used
75W-90	below -10°F (-23°C)	Drums, Swing, Boom Hoist
75W-90	all temperatures to 100°F (38°C)	Pump Drive
80W-90	-10°F to 100°F (-23°C to 38°C)	Drums, Swing, Boom Hoist

SAE Grade Gear Oil	Ambient Temperature Range	Where Used
85W-140	above 100°F (38°C)	Drums, Swing, Boom Hoist, Pump Drive
80W-140	all temperatures	Crawlers

### Hydraulic Oil

Use a shear stable anti-wear hydraulic oil that meets the following viscosity targets.

- Cold Start Viscosity: <1600 cST
- Operating Temperature Viscosity: >12 cST (operating temperature is 100°F [38°C] over ambient temperature)

#### Manitowoc Factory Fill

- Benz Oil Flomite 46SS (MCC Part No 549433) OR
- Mobil 424 (MCC Spec No 6829006444)

The factory fill fluids are zinc based multigrade hydraulic oils which may not be compatible with certain ashless (metal-free) hydraulic oils. Consult with your oil supplier to make sure the oil you select meets the above specification.

**Filter new oil through a 10 micron portable filter.**

**NOTE:** Flomite is an all-weather hydraulic oil suitable for use in ambient temperatures from 0 – 110°F (-18 – 43°C).

Flomite can cloud up (form wax crystals) at ambient temperatures below 0°F (-18°C). *This condition can result in damage to hydraulic components during start-up.*

When the expected ambient temperature will be below 0°F (-18°C), the hydraulic oil must be heated to at least 0°F (-18°C) prior to start-up. Tank heaters are available from Manitowoc.

Cloud point of oil selected must be equal to or less than expected ambient temperature.

#### Field Make-Up

Do not dilute the oil in the hydraulic tank with more than 25% of another brand oil. ***Dilution beyond the 25% maximum could effect the crane's operating performance at certain temperatures.***

If in doubt as to how much make-up oil has been added to the tank on your crane, Manitowoc recommends that a laboratory viscosity test be performed to determine if the oil still meets the viscosity targets given above OR that the system be completely drained and refilled.



## HYDRAULIC FILTER REPLACEMENT

Hydraulic filter elements on this crane are specially designed to withstand high pressure as the elements fill with dirt. This feature prevents the elements from collapsing.

See Table 5-3 for the Manitowoc part numbers of replacement filter elements. See lubrication charts in this section for identification and location of the filter elements.

**Table 5-3 Replacement Filter Elements**

MCC No.	System
A00652	Charge Pumps and In-Tank Return ( <i>Past Production</i> )
A17924	Charge Pumps and In-Tank Return ( <i>Current Production</i> )

### CAUTION

#### Hydraulic System Damage!

Original Equipment Manufacturers' filter elements – available from Manitowoc – must be used on this crane. Substituting with any other brand or type filter element is prohibited.

Filter elements made by other manufacturers may collapse under pressure. This action will allow unfiltered oil to be drawn into hydraulic system — pumps, motors, and valves can be destroyed.

Manitowoc will reject warranty claims for damaged hydraulic components if proper hydraulic filter elements are not used.

## LUBRICATION POINTS

- See Figure 5-3 through Figure 5-6 for location of the lubrication points for the crane.
- See Figure 5-7 for location of the lubrication points for the boom.
- See Figure 5-8 for location of the lubrication points for the automatic lubrication systems.

The letters before the item numbers in the illustrations correspond to the following intervals:

- A = At Assembly
- D = Daily
- W = Weekly
- M = Monthly
- Q = Quarterly
- S = Semiannually
- O = At Overhaul

## FLUID CAPACITIES

Fluid capacities are approximate and should be used only as a guide for ordering sufficient fluid at oil change intervals.

*Always fill each system to level plug opening or to specified point on sight gauge or dipstick.*

System	Capacity		Approved Lubricant
	Gallons	Liters	
Cooling System	30	114	See NOTE 1
Crawler Gearbox - Input/Output (each)	20	76	Gear Oil
Crawler Grease Reservoir	1	3,8	Grease
Drum 1 (Main Load Hoist)	27.5	104	Gear Oil
Drum 2 (Whip Line Hoist — Standard)	25	95	Gear Oil
Drum 2 (Whip Line Hoist — High Speed Drum)	16	61	Gear Oil
Drum 3 (Luffing/Auxiliary Load Hoist)	8	30	Gear Oil
Drum 4 (Boom Hoist)	18	68	Gear Oil
Fuel	250	946	See NOTE 1
Hydraulic System (Initial Fill)	300	1136	Hydraulic Oil
Hydraulic Tank	168	636	Hydraulic Oil
Pump Drive (Approximately)	1.63	6,2	Gear Oil
Swing	5.5	21	Gear Oil
Turntable Bearing Grease Reservoir	1	3,8	Grease

**NOTE 1** See engine manual for fuel, antifreeze, and engine oil specifications.

**NOTE 2** Brake housings for swing, boom hoist, and load drums are filled automatically with oil from gear boxes.

Brake housings for crawlers are flushed with cooling oil from hydraulic system.

APPROVED LUBRICANTS FOR ARCTIC OPERATION

The lubricants listed in Table 5-4 are recommended for use in Manitowoc’s line of hydraulic cranes when operating in an arctic-type climate — ***outside temperature continuously 0°F (-18°C) to -40°F (-40°C).***

Use these lubricants in place of the lubricants listed for normal operation in this section.

Additionally, the crane should have hydraulic tanks heaters available from Manitowoc.

CAUTION  
Machinery Damage!

Do not operate main crane functions (swing, travel, drums, boom hoist) with approved arctic lubricants when ambient temperature is above 60°F (16°C). Crane machinery will be damaged.

When ambient temperature is above 60°F (16°C), limit operation to crane setup functions (i.e. jacking cylinders).

Switch back to standard lubricants listed in lubrication guide when ambient temperature will be above 60°F (16°C).

CAUTION

Hydraulic Pump Damage!

To prevent damage to hydraulic pumps, warm hydraulic oil to at least 60°F (16°C) before operating crane functions during arctic-type conditions.

Structural Damage!

Cold weather can affect structural integrity of crane and attachment. Before operating in cold weather, read Preparation for Cold Weather - Crane Limitations in Crane Operator’s Manual.

Table 5-4 Lubricant for Arctic Operation

System	Approved Arctic Lubricants
Grease Points	Chevron RPM Arctic Grease NLGI 1
All Gear Cases, Pump Drives, and Gear Boxes	Mobil SHC 626
Hydraulic System	See Hydraulic Oil Specification on page 4
Engine Oil System (see NOTE)	Duron XL Synthetic 0W-30 OR Mobil Delvac 1
Engine Fuel (see NOTE)	No. 1 Diesel
Engine Cooling System (see NOTE)	Mix anti-freeze (Ethylene Glycol) and water 60/40 by volume. This mixture will provide coolant protection to -65°F (-54°C). <b><i>Pure antifreeze freezes at -10°F (-23°C).</i></b>

**NOTE** See engine manufacturer’s manual for specifications and cold weather operating guidelines.

## UPPER AND LOWER LUBRICATION POINTS — LOCATION




FIGURE 5-3




FIGURE 5-4





FIGURE 5-5

ENGINE COMPONENTS



Item	Description	Required Service
1	Dipstick	Service according to engine manufacturer's instructions.
2	Fill Cap	
3	Fuel Filter	
4	Coolant Filter	
5	Ether Starting Aid Canister	
6	Oil Filter	

FIGURE 5-6

## UPPER AND LOWER LUBRICATION POINTS — IDENTIFICATION

Item	Description	Required Service
<b>Prior to Use When Crane is Assembled</b>		
A1	Self-Erect Connecting Pins: <ul style="list-style-type: none"> <li>Rotating Bed (1 fitting, 4 places)</li> <li>Crawlers (1 fitting, 4 places)</li> </ul>	Grease each <b>with cylinders retracted</b> .
A2a	Carbody Pedestal (1 fitting, 4 places)	Grease each, if equipped, <b>with screw jacks retracted</b>
A2b	Carbody jacks (1 fitting top and bottom each jack)	Grease each, if equipped.
A3	Jacking Cylinders (3 fittings each rear jack and 1 fitting each front jack)	Grease each, if equipped.
<b>Every 8 Hours of Operation or Daily (whichever comes first) (see NOTE 1)</b>		
D1	Ring Gear	Check for proper lubrication; coat with open gear oil if needed.
D2	Grease Reservoir (2 places at front of rotating bed; 1 for crawlers and 1 for turntable bearing)	Check reservoir level. Fill to proper level with approved grease (see NOTE 2).
D3	Air Cleaner Service Indicator	Check; replace element when indicated.
D4	Radiator Sight Gauge	Check level; should be at full cold mark (see NOTE 4).
D5	Radiator Fill Cap	Fill to proper level with coolant.
D6	Fuel Tank Drain Valve	Drain water (see NOTE 3).
D7	Fuel Tank Level Gauge	Check level; fill to high mark on gauge.
D8	Fuel Tank Fill Cap	Fill to proper level with fuel oil.
D9	Hydraulic Tank Drain Valve	Drain water (see NOTE 3).
D10	Engine (see Figure 5-6)	Service according to engine manufacturer's instructions.
Items D11-D14 Not Used		

**NOTE 1** Inspect crane daily for leaks. If found, determine cause, take corrective action, and refill applicable component with proper fluid.

**NOTE 2** Fill through fitting in base of reservoir using a hand-operated grease gun or pump. Refill reservoir when grease reaches MIN mark. Fill reservoir to MAX mark.

Crawlers and turntable bearing are greased automatically by electric pumps when ignition switch is on.

**NOTE 3** Drain any accumulated water from fuel and hydraulic tanks at **start of each work day**.

Crack open drain valves. Securely close drain valves as soon as water stops draining and a steady stream of fuel or hydraulic oil appears.

**NOTE 4** Check coolant level when **coolant is cold**.



Item	Description	Required Service
<b>Every 8 Hours of Operation or Daily Continued</b>		
D15a	Pump Drive Sight Gauge (Past Production)	Check level; should be at middle of gauge.
D15b	Pump Drive Dipstick (Current Production)	Check level; should be at full mark on dipstick.
D16	Pump Drive Fill Plug/Breather	Fill to proper level with gear oil.
D17	Hydraulic Tank Level	Check level (see NOTE 1).
D18a	Hydraulic Tank Fill	Fill to proper level with hydraulic oil (see NOTE 1).
D18b	Hydraulic Tank Fill	
D19	Hydraulic Tank Return Filter (2 each mounted in tank)	Replace BOTH elements when indicated and at each oil change interval (see NOTE 2).
D20	Hydraulic Charge Filter (2 each)	Replace specified element when indicated and at each oil change interval (see NOTE 2).

**NOTE 1** Check hydraulic tank display on information screen in cab (see Operator's Manual Section 3):

- **FULL COLD LEVEL**  
(approximately 60°F – 16°C)  
Screen should read 87-90%.

- **FULL HOT LEVEL**  
(approximately 180°F – 82°C)  
Screen should read 95%.

***Do not fill tank to 100%. Oil will flow out of breather.***

If oil level drops to 50%, fault alarm will come on and fault symbol will appear on active display screen. HYDRAULIC FLUID LOW icon will appear on fault screen. ***Fill tank immediately.***

Fill tank either through plug opening (D18a) in return manifold or through power fill coupler (D18b). ***Do not fill tank through breather cap port or through top of either filter.***

See Section 2 in Service Manual for fill procedure.

**NOTE 2** When a filter needs replacement, fault alarm will come on and fault symbol will appear on active display screen.

FILTER FAULT icon and corresponding filter number will appear on fault screen. ***Replace BOTH corresponding filter elements immediately.***

FILTERS 1 are charge filters and FILTERS 2 are return filters. See Section 2 in Service Manual for filter replacement procedure.

It is normal for this fault alert to come on at start-up when hydraulic oil is cold. Alert should shut off as oil warms up.



## WARNING

### Burn Hazard!

Oil in hydraulic tank may be under pressure and extremely hot.

Hot oil can escape when you remove either filter cover.


Relieve pressure through air valve on top of hydraulic tank before servicing.

Item	Description	Required Service
<b>Every 40 Hours of Operation or Weekly</b> (whichever comes first)		
W1	Swing Shaft Bearing (1 fitting, 2 places)	Grease each.
W2	Swing Gear Box Fill Cap/Breather (2 places)	Clean each (see NOTE 1).
W3	Batteries	Check electrolyte level.
W4	Pump Drive Fill Cap/Breather	Clean (see NOTE 1).
W5	Drum Pawl and Cam (each drum so equipped)	Apply open gear oil to sliding surfaces.
W6	Hydraulic Tank Breather	Clean (see NOTE 1 and NOTE 2).
W7	Crawler Gear Box Breather (1 each crawler)	Clean each (see NOTE 1).
W8	Drum Gear Box Breather (1 each drum, current production)	Clean each (see NOTE 1).

**NOTE 1** Soak breathers in non-flammable solvent and blow dry with compressed air. For hydraulic tank, this service applies only to the past production metal-type breather.

**NOTE 2** Hydraulic tank on current production cranes has a desiccant breather. The breather does not require servicing until indicated.

Inspect desiccant breather weekly. Replace cartridge with a new one when all of the desiccant beads turn dark green (they are gold when new).



**Current Production  
Desiccant Breather**

Item	Description	Required Service
<b>After First 200 Hours of Operation</b> (see NOTE 1)		
M1	Swing Gear Box Drain Plug (2 places)	Drain and refill each with gear oil.
M2	Pump Drive Drain	Drain and refill with gear oil.
M3a	Drum Gear Box Drain Valve (Drums 1-4)	Drain and refill each with gear oil (see NOTE 2).
M3b	Drum Gear Box Drain Cap (Drums 1-4)	Drain. Drains remaining oil from drum barrel.
M4	Crawler Output Gear Box Drain Plug (1 each crawler)	Drain and refill each with gear oil (see NOTE 3).
M5	Crawler Input Gear Box Drain Plug (1 each crawler)	Drain and refill each with gear oil.

Items M6 through M9 Not Used

**NOTE 1** Service after first 200 hours of operation is required to remove metal particles and other impurities collected during initial run-in of gear boxes.

**NOTE 2** Lower boom so Drums 1 and 3 are horizontal when changing oil.

**NOTE 3** Input and output gear box drives are common.

Item	Description	Required Service
<b>Every 200 Hours of Operation or Monthly</b> (whichever comes first)		
M10	Swing Gear Box Level Plug (2 places)	Check level; should be up to plug opening.
M11	Swing Gear Box Fill Plug (2 places)	Fill each to proper level with gear oil.
M12	Drum Pawl Pin (1 fitting each drum so equipped)	Grease each 1/2 shot.
M13	Drum Journal Bearing (1 fitting, Drums 2 and 3)	Grease (see NOTE 2).
M14	Drum Gear Box Sight Gauge (Drums 1 - 4)	Check level; should be at middle of gauge (see NOTE 2).
M15	Drum Gear Box Fill Plug (Drums 1 - 4)	Fill each to proper level with gear oil.
M16	Engine Clutch Lever and Bearing (3 fittings)	Grease 1 each side and 1 on bottom.
M17	Crawler Output Gear Box Fill Plug (1 each crawler)	Check level; oil should be up to plug opening. Fill each as required with gear oil (see NOTE 3).
M18	Crawler Input Gear Box Level Plug (1 each crawler)	Check level; should be up to plug opening (see NOTE 3).
M19	Cab Support Grease Fittings (2 or 4 fittings)	Grease each 1/2 shot.

**NOTE 1** This grease fitting is removed for Drum 2 when equipped with optional high speed option.

**NOTE 2** Check level of drums 1 and 3 with drums in horizontal position before raising boom each time crane is assembled.

**NOTE 3** Input and output gear box drives are common.

Item	Description	Required Service
<b>Every 500 Hours of Operation or Quarterly</b> (whichever comes first)		
Q1	Crawler Drive Shafts (4 fittings both crawlers)	Grease (see NOTE 1).

**NOTE 1** See manufacturer's instructions for proper greasing.

Must slide guards clear of drive shafts to expose grease fittings. ***Be sure to securely reattach ends of guards in operating position after greasing.***

Item	Description	Required Service
<b>Every 1000 Hours of Operation or Semiannually (whichever comes first)</b>		
S1	Hydraulic Tank Drain Valve	Drain and refill with hydraulic oil.
S2	Swing Gear Box Drain Plug (2 places)	Drain and refill each with gear oil.
S3	Pump Drive Drain	Drain and refill with gear oil.
S4	Suction Screen (2 inside tank)	Inspect and clean at each oil change.
S5	Hydraulic Tank Breather	Replace element or entire breather (see NOTE 1).
S6	Hydraulic Filters	Replace elements when indicated on screen.
S7a	Drum Gear Box Drain Valve (Drums 1-4)	Drain and refill each with gear oil (see NOTE 2).
S7b	Drum Gear Box Drain Cap (Drums 1-4)	Drain. Drains remaining oil from drum barrel.
S8	Radiator Drain Valve	Drain and refill with coolant.
S9	Radiator Vent Valve	Open when filling radiator. Close when coolant appears.
S10	Crawler Output Gear Box Drain Plug (1 each crawler)	Drain and refill each with gear oil.
S11	Crawler Input Gear Box Drain Plug (1 each crawler)	Drain and refill each with gear oil.

**NOTE 1** This service applies only to the past production metal-type breather. For current production desiccant breather, see page 5-14.

**NOTE 2** Lower boom so Drums 1 and 3 are horizontal when changing oil.

*THIS PAGE BLANK*

## BOOM RIGGING LUBRICATION

A10740-3  
A10882  
A11993




FIGURE 5-7

Item	Description	Required Service
<b>Prior to Operation</b>		
A1	Rigging Winch Bearing (1 fitting)	Grease until grease seeps out drum seal.
A2	Rigging Winch	Inspect for oil leaks prior to using. If found, repair and refill unit with gear oil.
A3	Boom Butt Fleeting Sheaves (Rigging Winch)	Grease. Make sure entire length of both shafts is coated with grease.
A4	Extended Upper Point Rollers (1 fitting each end of shaft)	Grease prior to raising boom.
<b>Every 8 Hours of Operation or Daily (whichever comes first)</b>		
D1	Boom Hinge Pin (2 fittings, 2 places)	Grease each.
D2	Whip Line Wire Rope Guide Sheave (1 fitting)	Grease. Entire shaft must be coated with grease.
<b>Every 40 Hours of Operation or Weekly (whichever comes first)</b>		
W1	Swivel (1 fitting each)	Grease each.
W2	Load Block Sheaves (1 fitting, each sheave)	Grease each.
W3	Hook Swivel and Trunnion Bearings	Grease.
W4	Tagline Gears (2 fittings)	Grease each. Gear teeth must be coated with grease.
W5	Tagline Level Plug (3 places)	Check level with tagline horizontal. Oil must be up to plug opening.
W6	Tagline Fill Plug (3 places)	Fill to specified level with SAE 90 heavy duty gear oil.
<b>Every 200 Hours of Operation or Monthly (whichever comes first)</b>		
M1	Block-Up Limit Switch (1 fitting inside each switch)	Grease each.
M2	Live Mast Cylinder Ends (2 fittings each cylinder)	Grease each.
M3	Rigging Winch	Check level. Should be half full. Fill with gear oil.
<b>Every 2000 Hours of Operation or Annually (whichever comes first)</b>		
Y1	Rigging Winch	Drain and refill with 17 oz (0.5 L) of gear oil. Wire rope must be removed before drum can be drained. <ul style="list-style-type: none"> <li>Remove plastic plug and drain plug from bottom of drum barrel to drain oil. Securely reinstall plugs.</li> <li>Remove plastic plug and fill plug from top of drum barrel to add oil. Securely reinstall plugs.</li> </ul>

Sheaves in locations marked (\*) do not require greasing at regular intervals. Repack these sheaves with grease when sheaves are overhauled.

## AUTOMATIC LUBRICATION SYSTEM

The crane has two grease systems which automatically grease points on the turntable bearing and rollers on each crawler. Grease is pumped to each point at the intervals given in Table 5-5 when the ignition switch is on.

**Table 5-5 Automatic Greasing Intervals**

Item	Cycle Time	Interval
Turntable Bearing	Continuous	While Swinging
Crawler Roller Bearings	Continuous	While Traveling
Reservoir Capacity	1 gal (4 L)	
Pump Output:		
Turntable Bearing	0.177 in <sup>3</sup> /min (2,9 cm <sup>3</sup> /min)	
Crawlers	0.488 in <sup>3</sup> /min (8,0 cm <sup>3</sup> /min)	

### Operation

See Figure 5-8 in following procedure.

The crane's programmable controller controls the grease pumps.

- The pumps push grease to the grease points continuously when the crane is swung or traveled.
- The pumps stop pumping when swing or travel is stopped.
- The pumps also stop pumping if the crane's ignition switch is turned off.
- Each divider valve — primary and secondary — has an indicator pin (14) that extends and retracts during a lubrication cycle.

### Daily Inspection

See Figure 5-8 for following procedure.

To ensure maximum reliability and to protect crane components, the **automatic lubrication systems must be inspected daily**.

1. Check grease level in each reservoir.
2. Check and fill reservoirs when the grease level reaches the MIN mark.
3. Fill reservoirs to the MAX mark with a hand operated grease pump through grease fitting on pump housing.  
Use a recommended grease (see Table 5-1 for factory fill).
4. Visually inspect automatic lubrication systems:
  - a. Inspect divider valve inlets, outlets, and lubrication points for leaks.
  - b. Inspect for broken or cut grease lines.
  - c. Inspect terminal ends of each grease line to verify there are no leaks.
  - d. Tighten fittings if grease leakage is detected.
5. With power on, check that pumps are working by moving swing and travel handles.
6. Check to see if indicator pin on each valve is working when system is cycling. Should extend and retract.
7. If grease is pumped out through pressure relief valve, pressure within system is greater than 4,000 ± 250 psi (276 ± 17 bar). An obstructed grease line or divider valve is indicated. Troubleshoot system (see Table 5-6).


## CAUTION

### Crawler/Turntable Bearing Hazard!

In extreme cold weather operation — temperatures down to -40° (-40°C) — pumps may not pump grease through automatic lubrication systems. It will be apparent that the lines are obstructed when the pump pushes grease out the relief valve.

If this occurs, **intermediate rollers and turntable bearing must be greased manually** using grease fittings (5) on divider valves (9 and 11).





Item	Description	Item	Description
1	Grease Pump (Turntable Bearing)	8	Grease Line from Pump
2	Grease Pump (Crawler)	9	Primary Divider Valve (Turntable Bearing Shown)
3	Grease Reservoir	10	Grease Lines to Secondary Divider Valves
4	Grease Fitting for Filling Reservoir	11	Secondary Divider Valve (Turntable Bearing)
5	Grease Fitting for Greasing System Manually	12	Secondary Divider Valve (Crawler)
6	Pressure Relief Valve	13	Grease Lines to Lube Points
7	Electric Power Cable	14	Indicator Pin

FIGURE 5-8

## Automatic Lubrication System Troubleshooting

**Table 5-6**  
**Troubleshooting**

Symptom	Probable Cause	Solution
1. Pump will not operate.	Not receiving 24-volt DC input.  Blocked pump cam.	Check fuses and electrical supply.  Check electrical supply to the pump, by tracing to electrical source. Repair.  If voltage is available to pump, check for blockage. Repair.  Replace pump motor if blockage is not identified.
2. The pump motor is running but there is no grease being discharged.	Air pocket at pump element inlet.	Disconnect main delivery hose from pump outlet.  Run pump until solid grease with no bubbles flows from outlet. If solid grease does not discharge after 20 minutes, pump inlet is blocked.  <b>NOTE 1</b> Depending on operating temperature and grease type, it can take up to 10 minutes to obtain full volume at outlet.
	Blocked pump inlet.	Remove pump element from pump body and check suction inlet port for foreign particles.  Reassemble pump and element, then test pump. If pump element does not discharge grease, replace element.
3. Pump operated with an empty reservoir.	Grease in reservoir is low.	Fill reservoir and test system with grease gun at system manual grease fitting.  Disconnect main delivery hose from pump and watch until solid grease with no bubbles flows from outlet.  Reconnect main delivery hose to pump outlet.
4. Grease is discharged at pressure relief valve.	There is blockage in meter valves, hose, tubing, or at bearing.	Test system with grease gun at system manual grease fitting. Loosen each outlet line at primary valve, one at a time. The blocked outlet line will start flowing grease and indicator pin starts indexing.  Retighten all outlets at primary valve.  Trace hose that flowed to its secondary valve.  Repeat process of loosening each outlet one at a time until blocked line is found.  Retighten all outlets.  Repair bearing blockage.  If a metering valve is causing blockage, replace valve.
5. Indicator pin on primary valve does not move.	See item 4.	See item 4.
6. Lubrication point is not receiving grease.	Cut in hose or tubing.	Replace hose or tubing.

## SECTION 6

### MAINTENANCE CHECKLIST

#### TABLE OF CONTENTS

Inspection and Maintenance Checks . . . . .	6-1
Maintenance Intervals . . . . .	6-1
Maintenance Instructions . . . . .	6-1
Initial Run-In Services . . . . .	6-2
Maintenance Checklist . . . . .	6-2



## SECTION 6

### PREVENTIVE MAINTENANCE CHECKLIST

#### INSPECTION AND MAINTENANCE CHECKS

This section contains a list of inspection and maintenance checks and the *recommended interval* at which each check should be made. Performing the checks at the recommended intervals will help maintain the safety, dependability, and productivity designed into your crane.

**NOTE:** Service and maintain the engine according to the engine manufacturer's instructions.

#### MAINTENANCE INTERVALS

The letters at the top of the checklist columns correspond to the below listed intervals.

Perform the checks either at the hourly interval or at the calendar interval, whichever comes first. At each interval, perform all previous checks in addition to the ones listed.

- A** Every 8 Hours or Daily
- B** Every 40 Hours or Weekly (includes A Checks)
- C** Every 200 Hours or Monthly (includes A - B Checks)
- D** Every 500 Hours or Quarterly (includes A - C Checks)
- E** Every 1000 Hours or Semiannually (includes A - D Checks)
- F** Every 2000 Hours or Annually (includes A - E Checks)

The intervals are based on average operating conditions and should be used only as a guide until adequate experience is obtained to establish intervals which meet the specific operating conditions of your crane (frequency and duration of operation, loadings involved, dusty or corrosive atmosphere, outside air temperature, etc.).

Before lengthening or shortening the recommended intervals, study the crane's performance. Carefully examine previous checklists and service records to determine if past component failures have been caused by inadequate maintenance.

Perform an oil analysis at regular intervals for each fluid used in the crane to determine oil-change intervals.

This checklist covers 200 hours of operation (approximately one month working one shift a day); therefore, a new checklist must be started each time 200 hours of operation or one month is completed.

**NOTE:** Depending on the options your crane has, some checks given in this checklist may not apply.

A black box ■ in any column indicates that the item does not require service at the corresponding interval.

If further service of any item is required, indicate so in the box next to the item. For example: **S** indicates Service Required. Also make a detailed report of the type of service required (parts replacement, adjustment, overhaul, etc.). in the space provided at end of this section.



#### WARNING

To prevent serious or fatal injury while servicing crane:

- Lower all loads to ground.
- Move all controls to off.
- Stop engine and wait until all moving parts stop before servicing crane.

Maintenance checks which require engine to be running are identified with a bold dot (●).

*Use extreme care to avoid contact with moving parts when servicing crane with engine running.*

- Attach WARNING sign to engine start control to warn personnel that crane is being serviced and must not be started.
- Do not operate crane until all safety guards and covers are securely reinstalled and all maintenance equipment is removed.

Do not place crane into service until all defects are corrected.

**NOTE:** Completed checklists and repair receipts may be required for warranty claims. Keep these items on file at all times. Give the checklists to the new owner if the crane is sold.

***This checklist can be reproduced locally, or additional copies can be obtained from Technical Publications Department at factory.***

#### MAINTENANCE INSTRUCTIONS

See Service Manual for specific maintenance and adjustment procedures.

See Section 5 in this Manual for lubrication intervals, types of fluids, and lube point locations.

See the Parts Manual for specific torque values of nuts, bolts, and screws.

**INITIAL RUN-IN SERVICES**

The gear boxes and pump drive must be serviced after the first 200 hours of operation (see Section 5 of this manual).

The turntable bolts must be serviced after the first 50 hours of operation (see Turntable Bearing Adjustments in Section 8 of the Service Manual).

**MAINTENANCE CHECKLIST**

ENGINE HOUR METER READING:	Checkers Initials																							
at Start of Checklist _____																								
at End of Checklist _____																								
SCHEDULE	A	A	A	A	B	A	A	A	A	B	A	A	A	A	B	A	A	A	A	C	D	E	F	
Check for damaged or missing fiberglass covers.																								
Clean and check all windows for cracks.																								
Clean all debris from crane.																								
Check for leaks (fuel, coolant, gear oil, engine oil, hydraulic oil); correct cause and fill faulty unit to proper level.																								
Grease 8 hour lube points.																								
Apply open gear oil to ring gear.																								
Check pump drive oil level.																								
Check fuel tank level and drain water from bottom of tank.																								
Check hydraulic tank level and drain water from bottom of tank.																								
Check radiator coolant level when cold.																								
Service engine (see manufacturer's instructions).																								
Check that fire extinguisher (s) is on crane and fully charged.																								
Check that Operator's Manual and Capacity Charts are in operator's cab.																								
• Check fault alarm for proper operation – should come on for an instant when ignition switch is moved to RUN position.																								
• Check seat switch for proper operation — all control handles and corresponding functions should be inoperable when operator is out of seat.																								
• Check Main display on control console for proper operation.																								
• Replace hydraulic filters if filter fault appears on Main display, Information screen.																								
• Check engine air cleaner service indicator.																								
• Check all crane functions for proper operation.																								
• Check swing lock for proper operation; must hold crane in position when engaged and allow crane to swing when disengaged.																								

<b>ENGINE HOUR METER READING:</b>  <b>Checkers Initials</b> at Start of Checklist _____ at End of Checklist _____ <b>SCHEDULE</b>																								
	A	A	A	A	B	A	A	A	A	B	A	A	A	A	B	A	A	A	A	C	D	E	F	
• Check all drum pawls for proper operation; must fully engage and disengage ratchets. Controlled by park switches.																								
• Check park modes for proper operation — control handle and corresponding function (all drums, swing, travel) must be inoperable when park switch is on.																								
• While slowly hoisting or lowering, move control handle to off. Load must come to complete stop and not slip through brake. Brake must hold load in position.																								
• Test boom hoist brake while slowly raising or lowering boom. Move control handle to off. Boom must come to complete stop and not slip through brake. Brake must hold boom in position.																								
• Test travel brake while slowly traveling in either direction. Move control handles to off. Crane must come to complete stop and not slip through brake. Brake must hold crane in position.																								
• Check that swing holding brake holds rotating bed in position when swing control is off. Swing handle should be inoperable.																								
• Check swing and travel alarm for proper operation (must sound when swing and travel handles are moved in either direction).																								
• Test drum rotation indicators for proper operation.																								
• Check Rated Capacity Indicator/Limiter manual for proper operation.																								
• Check auto lube systems for proper operation (crawlers and turntable bearing).																								
• Check that boom and load hoist wire rope is spooled properly on drums and through sheaves before raising boom and loads from ground.																								

	SCHEDULE	B	B	B	C	D	E	F
Grease 40 hour lube points.								
Oil all pins not equipped with grease fittings.								
Check battery electrolyte level.								
Inspect rotating bed, carbody, and crawlers for cracks or other damage.								
Check that all pins and bolts are in place and tight in rotating bed, carbody, and crawlers (see separate checks for turntable bolts).								
Check crawler treads for proper adjustment.								
Inspect boom and mast for cracked or deformed members.								
Check that all boom and mast pins and bolts are in place and tight.								
Inspect all sheaves for wear and damage.								
Inspect all wire rope for broken wires or excessive wear and for proper spooling on drums and reeving through sheaves; lubricate wire rope if needed.								
Inspect each hook for cracks or deformation.								
Clean breathers on applicable gear boxes and on pump drive.								
• Test all disc brakes (load drums, boom hoist, swing, travel) for proper operation.								
• Test each limit device for proper operation:								
Boom up limit.								
Boom down limit.								
Minimum bail limit.								
Maximum bail limit.								
Block-Up limit.								
Any other limit crane is equipped with.								
Grease 200 hour lube points.								
Check level of each gear box.								
Inspect air cleaner.								
Check engine clutch adjustment.								
Engage and disengage engine clutch several times with engine running to clean discs.								
Inspect hydraulic hoses and tube assemblies for leaks, abrasion, cracks, kinking or other damage.								
Inspect all electrical harnesses and cables for abrasion, cracks, or other damage.								
Inspect CAN nodes and junction boxes for corrosion, loose connectors, and loose mounting hardware.								
Check tension of V-belts (see Engine Manual).								
Service battery (clean and inspect).								
Grease 1000 hour lube points.								
Drain and refill each gear box.								
Drain and refill hydraulic system.								
Replace hydraulic filter elements.								
Drain and refill cooling system.								
Drain and refill pump drive.								
Torque turntable bolts.								
Perform magnetic particle or other suitable crack detecting inspection for each hook.								
Check Rated Capacity Indicator/Limiter manual for proper calibration.								
Replace hydraulic hoses after 4,000 to 8,000 hours as recommended in Section 2 of Service Manual.								
Replace electrical harnesses and cables after 8,000 to 10,000 hours as recommended in Section 3 of Service Manual.								



[illegible]

[illegible]

## ALPHABETICAL INDEX

Accessing Parts . . . . .	4-2
Accidents . . . . .	2-18
Approved Lubricants For Arctic Operation . . . . .	5-7
Approved Lubricants For Normal Operation . . . . .	5-4
Assembly And Disassembly Area . . . . .	4-2
Assembly and Disassembly Notes . . . . .	4-2
Assist Crane Requirements . . . . .	4-2
Automatic Lubrication System . . . . .	5-20
Boom Disassembly Safety . . . . .	2-23
Boom Ladder Assembly . . . . .	4-49
Boom Rigging Lubrication . . . . .	5-18
Boom Rigging . . . . .	4-50
Cab Door Damper Adjustment . . . . .	3-9
Change of Ownership Registration . . . . .	1-1
Circuit Breakers . . . . .	3-65
Cold Weather Heater Package . . . . .	3-65
Cold Weather Mast Operation . . . . .	4-3
Controls Identification And Function . . . . .	3-11
Crane Access Points . . . . .	2-7
Crane Assembly . . . . .	4-7
Crane Data . . . . .	1-1
Crane Disassembly . . . . .	4-41
Crane Orientation . . . . .	1-1
Crane Orientation . . . . .	4-1
Crane Weights . . . . .	4-2
Crane/Attachment Identification . . . . .	1-1
CraneLUBE . . . . .	5-2
Cylinder Rod Lubrication . . . . .	5-2
Displays . . . . .	3-38
Drum Kicker Adjustment . . . . .	4-72
Engine Components . . . . .	5-11
English and Metric Conversions . . . . .	1-6
Environmental ProtectionN . . . . .	2-21
Environmental Protection . . . . .	5-2
Fire Extinguishers . . . . .	2-18
Fluid Capacities . . . . .	5-6
Front Window Operation . . . . .	3-8
General Lubrication . . . . .	5-1
General Safety . . . . .	4-1
Getting On or Off Crane . . . . .	2-7
Handling Components . . . . .	4-2
Hydraulic Filter Replacement . . . . .	5-5
Identification and Location of Components . . . . .	1-2
Initial Run-In Services . . . . .	6-2
Inspection and Maintenance Checks . . . . .	6-1
Introduction . . . . .	1-1
Liftcrane Mast Capacities . . . . .	4-1
Limit Devices . . . . .	3-22
Lubrication Intervals . . . . .	5-1
Lubrication Points . . . . .	5-5
Lubrication Tips . . . . .	5-1
Lubrication . . . . .	5-1
Maintenance Checklist . . . . .	6-2

Maintenance Instructions . . . . .	6-1
Maintenance Intervals . . . . .	6-1
Manitowoc Distributors . . . . .	1-7
Nameplates and Decals . . . . .	2-1
Oil Can Points . . . . .	5-2
Operating Controls And Procedures . . . . .	3-1
Operating Controls . . . . .	3-8
Operating Controls . . . . .	4-5
Operating Near Electric Power Lines and Transmission Lines . . . . .	2-16
Operation . . . . .	3-26
Operator's Manual/Capacity Chart Storage . . . . .	2-8
Optional Attachments . . . . .	4-1
Outline Dimensions . . . . .	1-4
Over-Lubrication . . . . .	5-1
Pad Eye Usage for Wire Rope Reeving . . . . .	4-72
Pedestal/barge Mounted Cranes . . . . .	2-25
Personnel Handling Policy . . . . .	2-24
Preparation for Cold Weather . . . . .	3-64
Preparing Crane for Operation . . . . .	3-26
Pre-Start Checks . . . . .	4-7
Preventive Maintenance Checklist . . . . .	6-1
Reeving – Live Mast . . . . .	4-82
Reeving – Load Block . . . . .	4-76
Reference Instructions . . . . .	5-2
Refueling . . . . .	2-18
Remote Controls . . . . .	3-34
Retaining Connecting Pins . . . . .	4-2
Rigging Drawings . . . . .	4-1
Rigging Winch Operation . . . . .	4-74
Safe Maintenance Practices . . . . .	2-18
Safe Operating Practices . . . . .	2-10
Safety and Information Signs . . . . .	2-29
Safety Information . . . . .	2-1
Safety Messages . . . . .	2-1
Seat Controls . . . . .	3-25
Self-Erecting Equipment . . . . .	4-1
Set-Up and Installation . . . . .	4-1
Shipping Crane Components . . . . .	4-5
Standard Hand Signals for Controlling Crane Operations . . . . .	3-1
Stopping Engine/ Leaving Crane Unattended . . . . .	3-33
Symbol Identification . . . . .	3-3
Symbol Identification . . . . .	5-1
Upper and Lower Lubrication Points — Identification . . . . .	5-12
Upper and Lower Lubrication Points — Location . . . . .	5-8
Wind Conditions . . . . .	3-62
Wire Rope Installation . . . . .	4-66
Wire Rope Lubrication . . . . .	5-2